

Workshop Manual Audi TT 2007 ➤

6-speed manual gearbox 02S, front-wheel drive

Edition 05.2008



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Service

List of Workshop Manual Repair GroupsList of Workshop Manual Repair GroupsList of Workshop Manual Repair Groups

Repair Group

00 - Technical data

30 - Clutch

34 - Controls, housing

35 - Gears, shafts

39 - Final drive - differential



Technical information should always be available to the foremen and mechanics because their careful and constant adherence to the instructions is essential to ensure vehicle road worthiness and safety. In addition, the normal basic safety precautions for working on motor vehicles must, as a matter of course, be observed.

Contents

00 -	ı ecnr	nical data	1
	1	Gearbox identification	1
	1.1	Code letters, allocation, transmission ratios, capacities	
	2	Transmission layout	3
	3	Calculating ratio "i"	4
	4	General repair instructions	ţ
30 -	Clutch	1	Q
	1	Overview - clutch mechanism	ç
	2	Notes on removing and installing clutch master cylinder and slave cylinder	10
	2.1	Function check for clutch master cylinder and slave cylinder Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not	10
	3	Exploded view - pedal cluster relutch master cylinder DIAG does not guarantee or accept any liability.	12
	3.1	Exploded view - pedal cluster rolling comments of information in this document. Copyright by AUDI AG. Removing and installing over-centre spring	13
	3.2	Removing and installing clutch pedal	15
	3.3	Removing and installing mounting bracket	18
	3.4	Removing and installing clutch position sender G476	
	3.5	Removing and installing clutch master cylinder	
	4	Exploded view - hydraulic system (LHD vehicles)	
	4.1	Removing and installing clutch slave cylinder	
	4.2	Removing and installing pipe/hose assembly	
	4.3	Bleeding clutch system	
	5	Exploded view - hydraulic system (RHD vehicles)	
	6	Exploded view - clutch release mechanism	
	7	Overview - servicing clutch	
	7.1	Clutch identification	35
	7.2	Exploded view - Sachs version clutch	37
	7.3	Removing and installing clutch (Sachs version)	38
	7.4 7.5	Exploded view - LuK version clutch	
34 -	Contr	ols, housing	48
	1	Overview - selector mechanism	48
	1.1	Gear knob and covers - exploded view	
	1.2	Removing and installing gear knob with gear lever boot	
	1.3	Exploded view - selector mechanism	52
	1.4	Dismantling and assembling selector mechanism	53
	1.5 1.6	Removing and installing selector mechanism	57 62
	1.7	Removing and installing gear selector cable and gate selector cable	66
	1.8	Adjusting selector mechanism	68
	2	Removing and installing gearbox	7
	2.1	Removing and installing gearbox on vehicles with 1.8 ltr. TFSI engine	72
	2.2	Installing gearbox on vehicles with 1.8 ltr. FSI turbocharged engine	8
	2.3	Transporting gearbox	88
	3	Exploded view - assembly mountings	90
	3.1	Removing and installing gearbox mounting	9
	3.2	Removing and installing pendulum support	94
	4	Checking gear oil level and filling up with gear oil	95
	4.1	Preparations	96
	4.2	Draining off gear oil	96
	4.3	Filling up with gear oil	97

	5	Overview - gearbox	98
	5.1	Exploded view - dismantling and assembling gearbox	99
	5.2	Exploded view - removing and installing gearbox housing cover and 5th/6th gear	100
	5.3	Exploded view - removing and installing gearbox housing and selector mechanism	103
	5.4	Exploded view - removing and installing input shaft, output shaft (pinion shaft), differential	101
	5.5	and selector forks	
	6	Exploded view - gearbox housing and clutch housing	
	6.1	Servicing gearbox housing and clutch housing	
	7 P	re Exploded view or gearbox housing coverses, in part or in whole, is not ermitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability Servicing gearbox housing covers document. Copyright by AUDI AG	127 128
	8	Exploded view - servicing selector unit	131
	8.1	Dismantling and assembling selector unit	
	9	Exploded view - selector forks	134
	9.1	Dismantling and assembling selector forks	
35 -	- Gears	s, shafts	139
	1	Exploded view - input shaft	139
	1.1	Dismantling and assembling input shaft	
	2	Adjusting input shaft	147
	3	Exploded view - output shaft	
	3.1	Dismantling and assembling output shaft	
	4	Adjusting output shaft	
	5	Exploded view - reverse shaft	
	5.1	Dismantling and assembling reverse shaft	
39 -	- Final	drive - differential	172
	1	Renewing flange shaft oil seals with gearbox installed	172
	1.1	Renewing flange shaft oil seal (left-side)	172
	1.2	Renewing flange shaft oil seal and sleeve (right-side; one-piece oil seal and sleeve)	175
	2	Exploded view - differential	179
	2.1	Dismantling and assembling differential	181
	3	Table of adjustments	187
	4	Adjusting differential	188


00 – Technical data

Gearbox identification


 \Rightarrow "1.1 Code letters, allocation, transmission ratios, capacities", page 1

Location on gearbox

- ♦ Code letters and date of manufacture -arrow 1-
- ♦ Manual gearbox 02S -arrow 2-



Manual gearbox 02S -arrow 2-



Code letters and date of manufacture of gearbox


Example:	GLB	18	07	3
	I		Ι	I
	Code letters	Day	Month	Year (2003) of manufacture

Additional data are production-related.



Protected by copyright. Copying for private or commercial purpos permitted unless authorised by AUDI AG. AUDI AG does not gua with respect to the correctness of information in this document

The code letters for the gearbox are also given on the vehicle data stickers.



1.1 Code letters, allocation, transmission ratios, capacities

Manual gearbox		6-speed 02S		
Code letters		JWX	KVT	
Manufactured from		02.08	05.08	
	to			
Allocation	Model	Audi TT 2007 ►	Audi TT 2007 ►	
	Engine	1.8 ltr 118 kW TFSI	1.8 ltr 118 kW TFSI	
Ratio	Final drive	62 : 17 = 3.647	62 : 17 = 3.647	
$Z_2: Z_1 = i$	1st gear	34 : 9 = 3.778	34 : 9 = 3.778	

Manual gearbox		6-speed 02S		
	2nd gear	33 : 16 = 2.063	33 : 16 = 2.063	
	3rd gear	32 : 22 = 1.455	32 : 22 = 1.455	
	4th gear	31 : 28 = 1.107	31 : 28 = 1.107	
	5th gear	28 : 32 = 0.875	28 : 32 = 0.875	
	6th gear	29 : 40 = 0.725	29 : 40 = 0.725	
	Reverse gear	36 : 20 x 18 : 9 = 3.600	36 : 20 x 18 : 9 = 3.600	
Overall ratio i _{OV.} in top gear		2.644	2.644	
Capacity		2.1 litres		
Clutch actuation		Hydraulic		

The following data can be found in the ⇒ Electronic parts catalogue . ♦ Gear oil specification

- Allocation of drive shaft flanges
- Allocation of clutch type



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Transmission layout 2




Note

-Arrows- point in direction of travel.

- 1 Engine
- 2 Clutch
- 3 Manual gearbox
- 4 Input shaft (main shaft)
- 5 Output shaft / pinion shaft
- 6 Differential

- I 1st gear
- II 2nd gear
- III 3rd gear
- IV 4th gear
- V 5th gear
- VI 6th gear
- R Reverse gear
- A Final drive



Calculating ratio "i" 3

Example:

	6th gear	Final drive
Drive gear	ZG ₁ = 38	ZA ₁ = 17
Driven gear	ZG ₂ = 31	ZA ₂ = 62

 $i = Z_2 : Z_1^{1}$

 $i_G = gear \ ratio = ZG_2 : ZG_1 = 31 : 38 = 0.816$

 $i_A = axle ratio = ZA_2 : ZA_1 = 62 : 17 = 3.647$

 i_{OV} = overall ratio

 $i_{OV} = i_{G} x i_{A} = 0.816 x 3.647 = 2.975$

1) Z_1 = No. of teeth on drive gear, Z_2 = No. of teeth on driven gear



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

4 General repair instructions

Proper tools and the maximum possible care and cleanliness are essential for satisfactory gearbox repairs. The usual basic safety precautions also naturally apply when carrying out repair work.

A number of generally applicable instructions for the various repair procedures - which were previously repeated at numerous places in the Workshop Manual - are summarised here. They apply to the work described in this Manual.

Special tools

For a complete list of special tools used in this Workshop Manual ⇒ Workshop equipment and special tools.

Gearbox


- Thoroughly clean all joints and connections and the surrounding areas before dismantling.
- When installing, ensure that the dowel sleeves between the engine and gearbox are correctly located.
- For allocation of bolts and other components, refer to ⇒ Electronic parts catalogue.
- Clean contact surfaces when assembling mounting brackets and waxed components. The contact surfaces must be free of wax and grease.
- After installing a replacement gearbox, check oil level and top up with gear oil as required ⇒ page 95.
- ◆ Capacities and specifications ⇒ page 1

Sealants

- Thoroughly clean joint surfaces on gearbox housing etc. before applying sealing paste.
- Apply sealing paste -AMV 188 200 03- evenly and not too thick.
- Breather holes must remain free of sealing paste.

Oil seals, seals, O-rings and gaskets

- Always renew seals, O-rings and gaskets.
- After removing gaskets and seals, always inspect the contact surface on the housing or shaft for burrs resulting from removal or for other signs of damage.
- Before installing oil seals, lightly oil the outer circumference of the seal and fill the space between the sealing lips -arrowabout half full with grease -G 052 128 A1- .
- The open side of the oil seal should face the side containing the fluid.
- When installing a new oil seal, position the seal in the housing so that the sealing lip does not contact the shaft in the same or co place as the old seal (make use of installation depth toleran. AUDI AG does not guarantee or accept any liability ces). with respect to the correctness of information in this document. Copyright by AUDI AG.
- Lightly lubricate O-rings with oil before installation to prevent them being trapped during assembly.
- Check oil level after installing new gaskets, O-rings and oil seals ⇒ page 95.



Locking elements

- Do not over-stretch circlips.
- Always renew circlips which have been damaged or overstretched.
- Circlips must be properly seated in the base of the groove.
- Renew spring pins. Position: the slit -A- should be in line with the line of force -arrow-.

Nuts, bolts

- Loosen the nuts and bolts in reverse sequence to the specified tightening sequence.
- Nuts and bolts which secure covers and housings should be loosened and tightened in diagonal sequence and in stages if no tightening sequence is specified.
- Renew self-locking nuts and bolts.
- The tightening torques stated apply to non-niled nuts and part or in whole bolts.

 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any
- Threaded holes which take self-locking bolts or bolts coated with locking fluid must be cleaned (using a tap or similar). Otherwise there is a danger of the bolts shearing off the next time they are removed.
- For all threaded connections, ensure that (where applicable) the contact surfaces and the nuts and bolts are not coated with wax until after assembly is completed.


Bearings

- Install new tapered roller bearings as supplied; do not lubricate additionally with oil.
- Lubricate all bearings (except tapered roller bearings) with gear oil before installing in gearbox.
- Use inductive heater -VAS 6414- to heat inner races of tapered roller bearings to approx. 100°C before installing. Press home onto stop when installing so there is no axial clearance.
- Do not interchange inner or outer races of bearings of the same size.
- If required, renew the tapered roller bearings on one shaft together and use new bearings from a single manufacturer.
- Install needle bearings so the lettering (side with thicker metal) faces towards the installing tool.

Shims

- Use a micrometer to measure the shims at several points.
 Tolerance variations make it possible to obtain the exact shim thickness required.
- Check for burrs and damage. Install only shims which are in perfect condition.

Synchro-rings



- Do not interchange synchro-rings. When reusing always fit to the same gear.
- Check for wear; renew if necessary.
- Check the grooves -arrow 1- on synchro-ring -A- and on inner ring for wear (flattened sections in grooves).
- Make sure that the coating of coated synchro-rings is not damaged.
- If an intermediate ring -B- is fitted, check the outer contact surface -arrow 2- and inner contact surface -arrow 3- of the intermediate ring for "scoring", "visible traces of wear" and "blue discolouration (caused by overheating)".
- Check chamfer on selector gear for scoring and visible traces of wear.
- Lubricate with gear oil before installing.


Gear wheels


- Clean before pressing on.
- Use inductive heater -VAS 6414- to heat to approx. 100°C before installing. Press home onto stop when installing so there is no axial clearance.

Selector gears and locking collars


- After installing, check 1st to 6th speed selector gears for minimal axial play and freedom of movement.
- ♦ Abnormal wear on synchro-ring or selector gear:
- A Worn ends of dog teeth on synchro-ring or selector gear.
- A35-0044
- In comparison: intact synchro-ring or selector gear:
- B Intact ends of dog teeth on synchro-ring or selector gear.

Protected by copyright. Copying for private or commercial purp permitted unless authorised by AUDI AG. AUDI AG does not with respect to the correctness of information in this docum





- ♦ Abnormal wear on locking collar:
- C Worn ends of internal splines on locking collar.




- ♦ In comparison: intact locking collar:
- D Intact ends of internal splines on locking collar.

Clutch actuation

- When removing gearbox, remove clutch slave cylinder without disconnecting pipes.
- Do not depress the clutch pedal after removing the slave cylinder if the hydraulic pipe is still connected. Otherwise the piston will be pressed out of the slave cylinder.
- Ensure that the pressure plate is kept straight: loosen and tighten bolts in a diagonal sequence and in several gradual stages.
- If the clutch has burnt out, thoroughly clean the bell housing, flywheel and parts of the engine facing the gearbox in order to prevent odours.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



30 – Clutch

Overview - clutch mechanism





Note

If you suspect that a clutch master cylinder or clutch slave cylinder is defective, observe and perform the following prior to renewing.

- ⇒ "2 Notes on removing and installing clutch master cylinder and slave cylinder", page 10
- ⇒ "2.1 Function check for Clittich master Clinide pariet space mercial purposes, in part or in whole, is not cylinder", page 10. permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability cylinder", page 10 with respect to the correctness of information in this document. Copyright by AUDI AG.
- ⇒ "3 Exploded view pedal cluster, clutch master cylinder", page 12
- ⇒ "3.1 Removing and installing over-centre spring", page 13
- ⇒ "3.2 Removing and installing clutch pedal", page 15
- ⇒ "3.3 Removing and installing mounting bracket", page 18
- ⇒ "3.4 Removing and installing clutch position sender G476", page 20
- ⇒ "3.5 Removing and installing clutch master cylinder", page 21
- II -
- ⇒ "4 Exploded view hydraulic system (LHD vehicles)", page 23
- ⇒ "4.1 Removing and installing clutch slave cylinder", <u>page 25</u>
- ⇒ "4.3 Bleeding clutch system", page 29

⇒ "5 Exploded view - hydraulic system (RHD vehicles)", page 31





Notes on removing and installing clutch master cylinder and slave cylinder

- Before renewing the clutch master cylinder or slave cylinder on the assumption that it is defective you must first carry out a function check
 - \Rightarrow "2.1 Function check for clutch master cylinder and slave cylinder", page 10 .
- If slave cylinder is removed from gearbox with pipe/hose assembly still attached, make sure you do not press clutch pedal. Otherwise, the piston will be pressed out of the slave cylinder and be destroyed.
- After installing the slave cylinder, carefully press the clutch pedal. If you feel an unusually strong point of resistance when depressing the clutch pedal, you must not press it down further. The plunger of the slave cylinder is likely to have been guided past the clutch release lever. The slave cylinder would then be destroyed once pedal force exceeds approx. 300 N.

2.1 Function check for clutch master cylinder and slave cylinder

Before you renew the clutch master cylinder or slave cylinder you must - in the case of the following faults - first carry out the appropriate checks.

Noises when operating the clutch:

- First check the over-centre spring / clutch pedal switch for noise.
- If you hear a noise, remove over-centre spring and repeat check.
- Renew relevant component.

After releasing clutch pedal it still remains depressed / does not return to its initial position.

- Check whether the clutch pedal returns all the way to its initial position, thereby uncovering the vent opening in the master cylinder.
- The vent opening is integrated in the clutch master cylinder. It is not visible from the outside.
- ♦ The vent opening must be uncovered, otherwise the permanent self-bleeding function for the provided unless that the permanent self-bleeding function for the provided unless that the permanent self-bleeding function for the provided unless that the permanent of the provided unless that the permanent of the pe
- Make the customer aware that the driver must NOT rest his/ her foot on the clutch pedal for long periods of time. This could impair the self-bleeding function of the clutch system as the vent opening in the master cylinder can no longer function.
- The self-bleeding function of the clutch system can be impaired if the footwell trim or floor mats get trapped, if the clutch pedal switch jams or if the driver rests his foot on the clutch pedal for long periods of time.

Check the complete hydraulic system for leaks.

- ♦ Check brake fluid level in brake fluid reservoir.
- Check clutch master cylinder and slave cylinder as well as the pipe/hose assembly including connections for external leaks (visual inspection).

- If you identify any leaks you must renew the leaking compo-
- ♦ Bleed clutch system ⇒ page 29.

Pedal forces:

◆ approx. 140 N for complete service life of the clutch

High pedal force:

Mechanically defective pressure plate/clutch plate

Clutch does not disengage or does not disengage fully:

- Air in hydraulic system: bleed clutch system ⇒ page 29 and check hydraulic system for external and internal leaks.
- Clutch plate does not move smoothly on input shaft splines (due to corrosion or dirt, etc.)
- ◆ Foreign body in clutch system
- Mechanically defective pressure plate/clutch plate
- Wrong components used or components forgotten when carrying out repair work (e.g. intermediate plate or dowel



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

3 Exploded view - pedal cluster, clutch master cylinder

1 - Bulkhead

With mounting for mounting bracket

2 - Gasket

- Always renew
- Between mounting bracket and bulkhead
- □ Self-adhesive
- Bond onto mounting bracket

3 - Mounting bracket

- □ For clutch pedal
- Removing and installing

4 - Bolt

5 - Over-centre spring

Removing and installing ⇒ page 13

6 - Bearing bush

7 - Pivot pin

8 - Clutch pedal

Removing and installing ⇒ page 15

9 - Retaining clip

□ For operating rod on master cylinder

10 - Seal

- Always renew
- Between clutch master cylinder and mounting bracket

2 15 6 15 15 17 8 13 Protected by copyright. Copying for private permitted unless authorised by AUDI AG. AUDI AG does not quarantee or accident the confectness of information in this docurrent. Copyright by N30-10067

11 - Clutch master cylinder

□ Removing and installing ⇒ page 21

12 - Clutch position sender -G476-

- □ Removing and installing ⇒ page 20
- Can be checked in "Guided Fault Finding", using vehicle diagnostic, testing and information system -VAS 5051- .

13 - Retaining clip

☐ To remove and install pipe/hose assembly, pull out clip as far as it will go

14 - Supply hose

☐ To brake fluid reservoir

15 - Nut

- □ 20 Nm
- □ 3x
- For securing mounting bracket to bulkhead
- □ Self-locking
- Always renew

16 - Nut

- □ 25 Nm
- □ Self-locking
- □ Always renew


17 - Stop

□ For clutch pedal

Crash bar - tightening torque

- Install crash bar -2- and tighten 1 or 2 bolts (depending on commercial version) -arrows B-.


 Under the correctness of information in this depending to a commercial version of the correctness of information in this depending to a commercial version. with respect to the correctness of information in this do
- M6 10 Nm
- M8 20 Nm



3.1 Removing and installing over-centre spring


Special tools and workshop equipment required

♦ Lever -T10178-



Removing

- · Clutch pedal mounting bracket fitted in vehicle
- Move driver's seat away from pedals.
- Remove storage compartment on driver's side ⇒ Rep. Gr. 68
- Unscrew bolt -arrow A- and remove footwell air outlet (front left) -1-.
- Unclip wiring harness at rear of footwell air outlet -1- and move clear to one side.
- Unbolt crash bar -2- (secured by one or two bolts -arrows B-, depending on version).



Protected by copyright. Copying


Unbolt clutch pedal -1- from mounting bracket -3-yill odo this; orrecremove nut -2- and pull out bolt -5-.



Note

The clutch pedal does not have to be detached from the operating rod on the clutch master cylinder.

 Pivot clutch pedal down slightly and and take over-centre spring -4- out of mounting bracket.



Installing


Tightening torques ⇒ page 12

Installation is carried out in reverse sequence; note the following:




Note

- ♦ Renew self-locking nut.
- Lubricate all bearings and contact surfaces with grease -G 000 450 02-.
- Fit over-centre spring -2- into mounting bracket from above while holding end of spring in correct position with assembly tool -T10178-.




- Socket -arrow- of over-centre spring must be in vertical posi-
- Fit actuator on clutch pedal -A- into corresponding socket in over-centre spring -arrow-.
- Press clutch pedal slightly, push bolt through and tighten selflocking nut.
- Install crash bar ⇒ page 13.
- Install front footwell vent (left-side) ⇒ Rep. Gr. 80 .
- Install storage compartment on driver's side ⇒ Rep. Gr. 68.



3.2 Removing and installing clutch pedal

Special tools and workshop equipment required

♦ Pliers -T10005-




Lever -T10178-

T10178 Protected by copyright. Copying for private or commercial purposes, permitted unless authorised by AUDI AG. AUDI AG does not guaral part or in whole, is not e or accept any liability yright by AUDI AG with respect to the correctness of information in this document. Co


W00-1390

Removing


- · Clutch pedal mounting bracket fitted in vehicle
- Move driver's seat away from pedals.
- Remove storage compartment on driver's side \Rightarrow Rep. Gr. 68 .
- Unscrew bolt -arrow A- and remove footwell air outlet (front left) -1-.
- Unclip wiring harness at rear of footwell air outlet -1- and move clear to one side.
- Unbolt crash bar -2- (secured by one or two bolts -arrows B-, depending on version).



- Unbolt clutch pedal -1- from mounting bracket -3-. To do this, remove nut -2- and pull out bolt -5-.
- Pivot clutch pedal forward slightly and and take over-centre spring -4- out of mounting bracket.



- Release retaining clip for operating rod on clutch master cylinder using pliers -T10005- .
- Remove clutch pedal.



Installing

Tightening torques ⇒ page 12

Installation is carried out in reverse sequence; note the following:



Note

- Renew self-locking nut.
- Lubricate all bearings and contact surfaces with grease -G 000 450 02- .
- Fit retaining clip -2- on operating rod -1- for clutch master cylinder.
- Press retaining clip into mounting on clutch pedal so that it snaps into place audibly.
- Fit over-centre spring -2- into mounting bracket from above while holding end of spring in correct position with assembly tool -T10178- .



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


- Socket -arrow- of over-centre spring must be in vertical posi-
- Fit actuator on clutch pedal -A- into corresponding socket in over-centre spring -arrow-.
- Press top of clutch pedal forwards against spring pressure of over-centre spring, push through bolt and tighten self-locking nut.





Note

It is easier to press the pedal against the spring if you pull back the bottom of the pedal carefully as you bring the top of the pedal into position.

- Install crash bar ⇒ page 13.
- Install front footwell vent (left-side) ⇒ Rep. Gr. 80.
- Install storage compartment on driver's side ⇒ Rep. Gr. 68.








Removing and installing mounting 3.3 bracket

Special tools and workshop equipment required

♦ Hose clamps, up to Ø 25 mm -3094-




Hose clip pliers -VAS 6340-




Removing




Note




Using hose clamp -3094-, clamp off supply hose to master cylinder.






- Disconnect supply hose at clutch master cylinder (if necessary, release spring-type clip -3- using hose clip pliers -VAS 6340-).
- Release retaining clip -2- with a screwdriver and disconnect pipe/hose assembly -1- from master cylinder.
- Unclip and detach clutch pedal position sender -G476- from master cylinder -arrow-. Electrical connector -4- can remain connected.



- Move driver's seat to rear as far as possible and move steering wheel into uppermost position.
- Remove storage compartment on driver's side ⇒ Rep. Gr. 68 .
- Unscrew bolt -arrow A- and remove footwell air outlet (front left) -1-.
- Unclip wiring harness at rear of footwell air outlet -1- and move clear to one side.
- Unbolt crash bar -2- (secured by one or two bolts -arrows B-, depending on version).





Note

When performing work in the footwell, put cloths on the carpet to protect it from possible brake fluid spills.

- Remove nuts -2-.
- Take out mounting bracket -1-.

Installing


Installation is carried out in reverse, sequence; note the following: in who e, is not

permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept at Tightening torques to accept and accept accept and accept and accept accept accept and accept accept and accept accept accept and accept accep




Note

- ♦ Renew self-locking nuts.
- ◆ Secure all hose connections with the correct hose clips (as original equipment); refer to ⇒ Parts catalogue.



- Fit mounting bracket -1- and tighten nuts -2-. Tightening torque
 ⇒ Item 15 (page 12).
- Connect pipe/hose assembly ⇒ page 25.
- Bleed clutch system ⇒ page 29.
- Install crash bar ⇒ page 13.
- Install front footwell vent (left-side) ⇒ Rep. Gr. 80 .
- Install storage compartment on driver's side ⇒ Rep. Gr. 68.
 Copyright Copyright

permitted unless authorised by Al with respect to the correctness



3.4 Removing and installing clutch position sender -G476-


Removing

- Unplug electrical connector -4-.
- Unclip clutch position sender -G476- at clutch master cylinder in direction of -arrow- and remove.



Note

Items -1 ... 3- can be disregarded.



Installing


Perform installation in reverse sequence of removal.

- Fit clutch position sender -G476- at clutch master cylinder and engage -arrow-.
- Attach electrical connector -4-.



Note

Items -1 ... 3- can be disregarded.



3.5 Removing and installing clutch master cylinder


Special tools and workshop equipment required


♦ Pliers -T10005-

Removing




- Remove mounting bracket ⇒ page 18
- Release retaining clip for operating rod on clutch pedal using to pliers - 170005- 0





- Insert a spacer -A- between clutch pedal and stop, and press clutch pedal forward.
- Length of spacer = approx. 40 mm (e.g. $^{1}/_{2}$ " socket)
- Release retaining clip -B- and pull clutch master cylinder out of mounting bracket -arrows 1 and 2-.





Installing

- · Clutch pedal in "released" position.
- Install retaining clip -2- on operating rod -1- for clutch master cylinder.




- Insert a spacer -A- between clutch pedal and stop, and press clutch pedal forward.
- ◆ Length of spacer = approx. 40 mm (e.g. ¹/₂" socket)
- Lock clutch master cylinder on mounting bracket -arrows 1 and 2-.





- Press operating rod -1- for clutch master cylinder in direction of -arrow- so that retaining clip -2- snaps into place in clutch pedal.
- Install mounting bracket ⇒ page 18.



Exploded view - hydraulic system (LHD vehicles) 4

1 - Brake fluid reservoir

2 - Hose clip (spring-type clip)

■ Not fitted in all vehicles

3 - Supply hose

- Made of rubber or plastic, depending on version
- Plastic supply hose with additional seals ⇒ page 24

4 - Clutch master cylinder

□ Removing and installing ⇒ page 21

5 - Clip

□ To remove and install pipe/hose assembly, pull out clip as far as it will go

6 - Retaining clip

- □ For operating rod for clutch master cylinder
- To remove and install retaining clip first detach clutch master cylinder from clutch pedal ⇒ page 15

7 - Clutch pedal

□ Removing and installing ⇒ page 15

8 - Nut

- ☐ Tightening torque ⇒ Item 15 (page 12)
- Secures mounting bracket to body
- Always renew

9 - Seal or O-ring

- ☐ Whether a seal or an O-ring is used depends on the type of connection <u>⇒ page 24</u>
- ☐ For correct version, refer to ⇒ Electronic parts catalogue
- □ Renew damaged O-rings
- Push onto pipe connection
- ☐ Lubricate O-rings with brake fluid

10 - Pipe/hose assembly


- With frequency modulator
- □ Removing and installing ⇒ page 27
- ☐ Disconnecting from clutch master cylinder and slave cylinder ⇒ page 25

11 - Bracket

- ☐ For pipe/hose assembly ⇒ Item 10 (page 23)
- Secured on body

12 - Seal or O-ring

Whether a seal or an O-ring is used depends on the type of connection ⇒ page 24



- ☐ For correct version, refer to ⇒ Electronic parts catalogue
- □ Renew damaged O-rings
- ☐ Push onto pipe connection
- ☐ Lubricate O-rings with brake fluid

13 - Clip

☐ To remove and install pipe/hose assembly, pull out clip as far as it will go

14 - Clutch slave cylinder

□ Removing and installing ⇒ page 25

15 - Bolt

- Protecte20yNmright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with 25 ect to the correctness of information in this document. Copyright by AUDI AG.

16 - Bleeder valve


- □ 6 Nm
- ☐ Bleeding clutch system ⇒ page 29
- 17 Dust cap
- 18 Gearbox
- 19 Bracket
 - □ For pipe/hose assembly

20 - Bolt

□ 20 Nm


Vehicles with plastic supply hose -1-

Seals -2- must be fitted in supply hose.



Seal/O-ring for pipe/hose assembly

- 1 O-ring
- ◆ Connection with annular groove -arrow 1-
- ♦ Check O-ring for damage and renew if necessary
- 2 Seal
- ♦ Connection with shoulder -arrow 2-
- Position seal -2- onto connection -arrow 2- before fitting



Disconnecting/connecting pipe/hose assembly from/to clutch master cylinder or clutch slave cylinder

To remove, release clip -3- with a screwdriver and disconnect pipe/hose assembly -1- from clutch master cylinder or clutch slave cylinder -4-.


Installing



Note

Observe distinction between seals -2- and O-rings ⇒ page 24

- Press pipe/hose assembly -1- into connection on clutch slave cylinder or clutch master cylinder -4- until clip -3- snaps into place.
- Pull on pipe to check it is secure.



Removing and installing clutch slave 4.1 cylinder


Special tools and workshop equipment required

♦ -V.A.G 1331- Torque wrench

Protected by copyright. Copying for private or commercial purposes, in par permitted unless authorised by AUDI AG. AUDI AG does not guarantee o with respect to the correctness of information in this document. Copyrig




♦ Hose clamps, up to Ø 25 mm -3094-




Removing


- Detach cable support bracket from gearbox -arrows-.




- Remove securing clip -1-.
- Pull gear selector cable -2- off pin.



- Pull locking mechanism forwards in direction of -arrow 1- onto stop and then turn to left in direction of -arrow 2- to lock.
- Press relay lever forwards (in direction of -arrow 3-) and pull out gate selector cable.
- Tie back gear selector cable and gate selector cable.



- Detach gearbox support -arrows A-.
- Remove clutch slave cylinder -arrows B-.





Note

Make sure that no brake fluid escapes onto the gearbox. If this does happen, clean the affected area thoroughly.

- Place a lint-free cloth under the clutch slave cylinder.
- Using hose clamps, up to Ø 25 mm -3094-, clamp off pipe/ hose assembly to clutch master cylinder.
- Pull out clip -1- as far as it will go, move pipe/hose assembly -2- clear at bracket and disconnect from clutch slave cylinder.



Caution


Do not operate clutch pedal after disconnecting pipe/hose assembly.


SW 3094 A30-0155

Installing

Installation is carried out in the reverse order; note the following:

- Connect pipe/hose assembly to clutch slave cylinder ⇒ page 25 ...
- Lubricate end of plunger with MoS₂ grease.
- Fit clutch slave cylinder and tighten bolts -1- and -2-. Tightening torque <u>⇒ Item 15 (page 24)</u>.
- Clip pipe/hose assembly into bracket -arrow-.
- Remove hose clamp 3094.
- Fit gearbox support and tighten bolts -arrows-. Tightening torques ⇒ Item 1 (page 90)
- Bleed clutch system ⇒ page 29.
- Assemble selector mechanism ⇒ page 62.
- Adjust selector mechanism ⇒ page 68.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

4.2 Removing and installing pipe/hose assembly

Special tools and workshop equipment required

♦ Hose clamps, up to Ø 25 mm -3094-




Removing


- Remove air cleaner housing completely ⇒ Rep. Gr. 24.
- Remove bolts -arrows- and detach bracket for air cleaner housing.




Note

- ♦ In the following steps make sure that no brake fluid escapes onto the longitudinal member or onto the gearbox below. If this does happen, clean the affected area thoroughly.
- ♦ Place a cloth underneath to catch escaping brake fluid.







permitted unless aut

with respect to the

- Release clip -3- with a screwdriver and disconnect pipe/hose assembly -1- from clutch master cylinder and clutch slave cyl-
- Detach pipe/hose assembly -1- from bracket and remove.

Installing


Installation is carried out in reverse sequence; note the following:




Note

Observe distinction between seals -2- and O-rings ⇒ page 24

- Press pipe/hose assembly -1- into connection on clutch slave cylinder and master cylinder -4- so that clip -3- snaps into place.
- Pull on pipe to check it is secure.
- Clip pipe/hose assembly into bracket -arrow-.
- Remove hose clamp 3094.
- Bleed clutch system ⇒ page 29.
- Install complete air cleaner housing ⇒ Rep. Gr. 24.






Protected by copyright. Copying for private or commercial purposes, in p authorised by AUDI AG. AUDI AG does not guarantee or accept any liability Bleeding relutch systems of information in this document. Copyright by AUDI AG.

Special tools and workshop equipment required

-VAS 5234- Brake filling and bleeding equipment






4.3

- The clutch system must be bled after performing work on the hydraulic clutch mechanism.
- In the following steps make sure that no brake fluid escapes onto the longitudinal member or onto the gearbox below.
- Prefilling the system is not necessary.
- Brake fluid specification ⇒ Rep. Gr. 47.

- Pull clutch pedal back to its normal rest position.
- Connect brake filling and bleeding equipment -VAS 5234- or -V.A.G 1869- .
- To bleed system, use bleed hose -V.A.G 1238/B- 3 670 mm long, if necessary.
- Then connect bleeder hose to collector bottle of brake bleeding unit.
- Connect bleed hose to bleeder -arrow-.
- Now switch on bleeding equipment.
- Operating pressure 2.0 bar
- Open bleeder valve.
- Bleed off about 100 cm³ of brake fluid.
- Close bleeder valve.

permitted unless authorised by AUDI with respect to the correctness of i Rapidly operate pedal from stop to stop 10 to 15 times.

- Open bleeder valve once again.
- Bleed off an additional 50 cm³ of brake fluid.
- Tighten bleeder valve ⇒ Item 16 (page 24).
- Disconnect bleeder hose and fit protective cap.
- Detach bleeder unit from brake fluid reservoir.
- Depress clutch pedal several times after bleeding process is completed.
- Repeat bleeding procedure if necessary.



5 Exploded view - hydraulic system (RHD vehicles)

1 - Brake fluid reservoir

2 - Seal

- ☐ For plastic supply hose
- Seals must be fitted in supply hose.

3 - Supply hose

- Made of rubber or plastic, depending on version
- ☐ Plastic supply hose with additional seals ⇒ Item 2 (page 31)

4 - Clutch master cylinder

□ Removing and installing ⇒ page 21

5 - Clip

□ To remove and install pipe, pull out clip as far as it will go

6 - Seal or O-ring

- □ Renew damaged Orings
- Push onto pipe connec-
- Lubricate with brake fluid before installing
- ☐ Whether a seal or an Oring is used depends on the type of connection ⇒ page 24
- ☐ For correct version, refer to ⇒ Electronic parts catalogue

2 2 3 8 20 16 17 N30-10205

7 - Retaining clip

- ☐ To remove and install retaining clip first detach clutch master cylinder from clutch pedal
- ☐ To remove and install retaining clip first detach clutch master cylinder from clutch pedal ⇒ page 15

8 - Clutch pedal

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not 9 - Nut permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG

For securing mounting bracket to bulkhead

10 - Retainer

Secured on body

11 - Pipe

- ☐ For correct version, refer to ⇒ Electronic parts catalogue
- ☐ Prior to removal, remove battery and battery tray ⇒ Rep. Gr. 27

12 - Seal or O-ring

- □ Renew damaged O-rings
- Push onto pipe connection
- ☐ Lubricate with brake fluid before installing

☐ Whether a seal or an O-ring is used depends on the type of connection ⇒ page 2
□ For correct version, refer to ⇒ Electronic parts catalogue
13 - Pipe/hose assembly
□ For correct version, refer to ⇒ Electronic parts catalogue
□ Prior to removal, remove battery and battery tray ⇒ Rep. Gr. 27
14 - Retainer
☐ Secured to bracket for ABS/EDL
15 - Bracket
☐ For ABS/EDL
16 - Seal or O-ring
☐ Renew damaged O-rings
Push onto pipe connection
☐ Lubricate with brake fluid before installing
☐ Whether a seal or an O-ring is used depends on the type of connection <u>⇒ page 2</u>
☐ For correct version, refer to ⇒ Electronic parts catalogue
17 - Clip
☐ To remove and install pipe/hose assembly, pull out clip as far as it will go
18 - Clutch slave cylinder
□ Removing and installing ⇒ page 25
19 - Bolt
☐ Tightening torque ⇒ Item 15 (page 24)
20 - Bleeder valve
☐ Tightening torque ⇒ Item 16 (page 24)
☐ Bleeding clutch system ⇒ page 29
21 - Dust cap
22 - Gearbox
23 - Bracket
24 - Bolt
$\square \Rightarrow \text{Item } 20 \text{ (nage } 24)$



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

6 Exploded view - clutch release mechanism

1 - Gearbox

2 - Ball head stud

- □ 25 Nm
- Remove existing grease from contact surface of release lever
- Lubricate with grease -G 000 100-

3 - Input shaft oil seal

- Pressed into guide sleeve
- □ Removing ⇒ page 34
- Installing ⇒ page 34

4 - Guide sleeve

- With vulcanised O-ring and oil seal for input shaft
 - ⇒ Item 3 (page 33)
- □ Renew guide sleeve if O-ring is damaged
- □ Lubricate guide sleeve in area of release bearing with MoS₂ grease

5 - Retaining spring

Secure to clutch release lever

6 - Socket head bolt

□ 20 Nm

7 - Clutch release lever

- Remove and install together with release bearing ⇒ page 34 and ⇒ page 34
- Remove existing grease
- ☐ Lubricate surface which contacts ball head stud with MoS₂ grease

8 - Release bearing

- Do not wash out bearing; wipe clean only
- Renew bearing if noisy
- ☐ Lubricate surfaces which contact release lever with MoS₂ grease

9 - Bolt

- ☐ Tightening torque ⇒ Item 15 (page 24)
- □ 2x

10 - Clutch slave cylinder


□ Removing and installing ⇒ page 25

11 - Plunger

☐ Lubricate end of plunger with MoS₂ grease

12 - Assembly bolt

☐ Secures the clutch release lever while installing gearbox





Unscrew after gearbox has been installed




Note

If the assembly bolt (*⇒ Item 12 (page 33)*) is not available, an M8 x 35 bolt can be used instead.

Removing and installing clutch release lever together with release bearing


- Unhook spring -arrow 1-.
- Pull off clutch release lever -arrow 2- and clutch release bear-

Perform installation in reverse sequence of removal.




Removing and installing release bearing


- Press locking lugs -arrows- together on reverse side of clutch release lever and remove release bearing -A- from clutch re-Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AG does lease lever.
- To install, press release bearing Aprinto clutch release lever in this do until locking lugs -arrows- engage.



Driving oil seal out of guide sleeve



Driving oil seal into guide sleeve (drive in onto stop)



- ♦ ⇒ "7.1 Clutch identification", page 35
- ♦ ⇒ "7.2 Exploded view Sachs version clutch", page 37
- ♦ ⇒ "7.3 Removing and installing clutch (Sachs version)", page 38
- ◆ ⇒ "7.4 Exploded view LuK version clutch", page 43
- ◆ ⇒ "7.5 Removing and installing clutch (LuK version)", <u>page 44</u>

Clutch identification 7.1




Note

The clutch fitted in the vehicle is supplied by either "Sachs" or "LuK".

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability


With gearbox installed, the clutch version fitted can be distinent. Copyright by AUDI AG. guished as follows:

- Remove noise insulation panels -1- and -2- ⇒ Rep. Gr. 66.



A number of recesses -arrows- are located in lower area of sump between engine -A- and gearbox -B-.

- Check the contour of the flywheel visible through the recesses.




A - round contour -arrows- = Sachs version clutch

Exploded view - Sachs version clutch ⇒ page 37


B - square contour -arrows 1- and annular groove -arrow 2- = LuK version clutch

Exploded view - LuK version clutch ⇒ page 43



B - round contour -arrows 1- and annular groove -arrow 2- = LuK version clutch

Exploded view - LuK version clutch <u>⇒ page 44</u>





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

7.2 Exploded view - Sachs version clutch



Note

The dual-mass flywheel, pressure plate and clutch plate are matched together; components from another manufacturer must not be installed on the same vehicle.

1 - Dual-mass flywheel

- □ Removing and installing ⇒ Rep. Ğr. 13
- Ensure that dowel pins fit tightly
- □ Contact surface for clutch lining must be free of grooves, oil and grease
- Observe instructions for removal <u>⇒ page 38</u>

2 - Clutch plate


- Removing and installing
- □ Always renew pressure plate as well
- ☐ Installation position ⇒ page 41
- ☐ For diameter of clutch plate, refer to ⇒ Electronic parts catalogue

3 - Pressure plate

- With adjustment mechanism
- □ Identification
 - ⇒ page 38
- Removing and installing ⇒ page 38
- ☐ Checking ends of diaphragm spring ⇒ page 41
- □ Checking spring connections and rivets ⇒ page 41
- □ Always renew clutch plate as well
- ☐ For correct version, refer to ⇒ Electronic parts catalogue Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not

4 - Bolt


- ☐ M6 13 Nm
- ☐ M7 20 Nm
- □ Loosen and tighten bolts consecutively in steps of 90°



permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Identification of self-adjusting Sachs version clutch

 Pressure plate with stop mechanism (position sensor) -arrow-.




Instructions for removing dual-mass flywheel



Note


Do not use an impact wrench or pneumatic wrench to remove bolts -B-: this would severely damage the dual-mass flywheel. The bolts must always be removed by hand.


- Rotate dual-mass flywheel -A- so that the bolts are aligned to the contrally behind the holes -arrows-.
- When removing the bolts, make sure that none of the bolt heads contacts the dual-mass flywheel, as this would damage the flywheel when the bolts are unscrewed further.



Special tools and workshop equipment required


◆ Counterhold tool -3067-





♦ Centring mandrel -3190 A-





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

Grease for clutch plate splines: G0000100-n in this document. Copyright by AUDI AG.

Removing

- Gearbox removed
 ⇒ "2 Removing and installing gearbox", page 71 .
- Remove gearbox.

To prevent the pressure plate from becoming distorted during removal (causes clutch grab when driving off), always adhere to the following procedure when unbolting the pressure plate:

- Apply counter-hold tool -3067- in order to loosen bolts.
- Working clockwise, loosen all six bolts consecutively in steps of 90° (¹/₄ turn) until the pressure plate is released.
- Stop -2- with pin -1- should come loose when the bolts are slackened.
- If the stop does not come loose, push the pin towards the dualmass flywheel.
- Take off pressure plate and clutch plate.

Installing


Tightening torque ⇒ page 37.

Installation is carried out in reverse sequence; note the following:



Note

- The dual-mass flywheel, pressure plate and clutch plate are matched together; components from another manufacturer must not be installed on the same vehicle.
- ◆ Always renew clutch plate and pressure plate together and select the correct parts according to engine code ⇒ Electronic parts catalogue.
- If the clutch has burnt out, thoroughly clean the bell housing, flywheel and parts of the engine facing the gearbox in order to prevent odours.
- ♦ Clean input shaft splines and (in the case of a used clutch plate) the hub splines. Remove corrosion and apply only a very thin coating of grease -G 000 100- to the splines. Then move clutch plate backwards and forwards on input shaft until hub moves freely on shaft. It is important to remove excess grease.
- Pressure plates have an anti-corrosion coating and are greased. Only the contact surface may be cleaned, otherwise the service life of the clutch will be considerably reduced.
- Pressure plate contact surface and clutch plate lining must make full contact with flywheel. Only then insert bolts.
- Check that dowel sleeves for centralising engine/gearbox are in the cylinder block; install if necessary.
- ♦ If the dowel sleeves are not fitted, this will lead to gear-change problems, clutch malfunction and in some cases gearbox noise (gears will make rattling noises).





Installation position of clutch plate


Marking "Getriebeseite" (gearbox side) and the protruding spring cage face towards gearbox.




Checking ends of diaphragm spring

permitted unWear up to half the thickness of the diaphragm spring with respect to the correctness of information.


ses, in part or in whole, is not






Checking spring connections and rivets

- Check spring connections between pressure plate and cover for cracks and make sure rivets are seated tightly.
- Renew pressure plate if spring connections are damaged or rivets are loose -arrows-.




- Use counter-hold tool -3067-.
- Fit pressure plate onto dowel pins.
- Use centring mandrel -3190 A- to centralise clutch plate.



To prevent the pressure plate from becoming distorted during installation (causes clutch grab when driving off), always adhere to the following procedure when installing the pressure plate:

- Make sure that the stop pin (position sensor) -arrow- is free to move.
- Screw in all 6 bolts evenly by hand until bolt heads make contact with pressure plate.
- Working clockwise, tighten all six bolts consecutively in steps of 90° (¹/₄ turn) until the housing makes contact with the flywheel.
- The stop pin -arrow- should then lift away from the pressure plate.
- Working clockwise, tighten all 6 bolts to final torque consecutively. Tightening torque ⇒ Item 4 (page 37).
- Install gearbox ⇒ page 71.

Protected by copyright. Copying for private or compermitted unless authorised by AUDI AG. AUDI AG with respect to the correctness of information in





7.4 Exploded view - LuK version clutch



Note

The dual-mass flywheel, pressure plate and clutch plate are matched together; components from another manufacturer must not be installed on the same vehicle.

1 - Dual-mass flywheel

- □ Removing and installing ⇒ Rep. Ğr. 13
- Ensure that dowel pins fit tightly
- □ Contact surface for clutch lining must be free of scoring, oil and grease
- Observe instructions for removal <u>⇒ page 44</u>

2 - Clutch plate


- Removing and installing
- □ Always renew SAC pressure plate as well
- ☐ Installation position: marking "Getriebeseite" (gearbox side) faces towards gearbox
- □ For diameter of clutch plate, refer to ⇒ Electronic parts catalogue

3 - SAC pressure plate

- "SAC" = self adjusting clutch
- □ Always renew clutch plate as well
- Removing and installing ⇒ page 44
- ☐ Checking position of adjuster ring on new SAC pressure plate ⇒ page 46
- Only fits on flywheel in one position
- □ Checking ends of diaphragm spring ⇒ page 45
- □ Checking spring connection and rivets ⇒ page 46

4 - Bolt

- ☐ M6 13 Nm
- ☐ M7 20 Nm
- □ Loosen and tighten bolts consecutively in steps of 90°




Removing dual-mass flywheel



Note

Do not use an impact wrench or pneumatic wrench to remove bolts -B-: this would severely damage the dual-mass flywheel. Bolts -B- must always be removed by hand.


- Rotate flywheel -A- so that bolts -B- are aligned centrally behind the holes -arrows-.
- When unscrewing bolts -B-, make sure the bolt heads do not contact the flywheel -arrows- because this would damage the flywheel when the bolts are turned further.




7.5 Removing and installing clutch (LuK version)

Special tools and workshop equipment required

◆ Counterhold tool -3067-



Centring mandrel -3190 A-



♦ Grease G 000 100



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Removing

- Remove gearbox ⇒ "2 Removing and installing gearbox", page 71.
- Attach counterhold tool -3067- before loosening bolts.

To prevent the pressure plate from becoming distorted during removal (causes clutch grab when driving off), always adhere to the following procedure when unbolting the pressure plate:

- Working clockwise, loosen all six bolts consecutively in steps of 90° (1/4 turn) until the pressure plate is released.
- Take off pressure plate and clutch plate.

Installing

Installation is carried out in reverse sequence; note the following:





Note

- The dual-mass flywheel, pressure plate and clutch plate are matched together; components from another manufacturer must not be installed on the same vehicle.
- Always renew clutch plate and pressure plate together and select the correct parts according to engine code ⇒ Electronic parts catalogue .
- Checking position of adjuster ring on new pressure plate
- If the clutch has burnt out, thoroughly clean the bell housing, flywheel and parts of the engine facing the gearbox in order to prevent odours.
- Clean input shaft splines and (in the case of a used clutch plate) the hub splines. Remove corrosion and apply only a very thin coating of grease -G 000 100- to the splines. Then move clutch plate backwards and forwards on input shaft until hub moves freely on shaft. It is important to remove excess grease poses, in part or in whole, is not
- t guarantee or accept any liability Pressure plates have an anti-corrosion coating and are is document. Copyright by AUDI AG greased. Only the contact surface may be cleaned, otherwise the service life of the clutch will be considerably reduced.
- Pressure plate contact surface and clutch plate lining must make full contact with flywheel. Only then insert bolts.
- Check that dowel sleeves for centralising engine/gearbox are in the cylinder block; install if necessary.
- If the dowel sleeves are not fitted, this will lead to gear-change problems, clutch malfunction and in some cases gearbox noise (gears will make rattling noises).

Checking ends of diaphragm spring


Wear up to half the thickness of the diaphragm spring -arrows- is permissible.





Checking spring connections and rivets

- Check spring connections -arrows A- for damage and make sure riveted joints -arrows B- are seated tightly.
- Renew pressure plate if spring connections are broken or badly bent, or if riveted joints are loose.




Checking position of adjustment mechanism (new SAC pressure plates only)

- The two edges -A- of the adjuster ring should be located between the two notches -arrows B-.
- If the adjuster ring is in a different position on a new pressure plate, the pressure plate and clutch plate must not be installed.
- The position of the adjuster ring can be outside the notches on used clutches.




Protected by copyright. Copying for private or commercial purposes, in part of permitted unless authorised by AUDI AG. AUDI AG does not guarantee or acceptible with respect to the correctness of information in this document. Copyright by



Installation position of clutch plate:


The marking "Getriebeseite" (gearbox side) faces towards the gearbox



- Use counter-hold tool -3067- .
- Position pressure plate on dowel pins.
- Use centring mandrel -3190 A- to centre clutch plate.

To prevent the pressure plate from becoming distorted during installation (causes clutch grab when driving off), always adhere to the following procedure when installing the pressure plate:

- Screw in all 6 bolts evenly by hand until bolt heads make contact with pressure plate.
- Working clockwise, tighten all six bolts consecutively in steps of 90° (¹/₄ turn) until the housing makes contact with the flywheel.
- Working clockwise, tighten all 6 bolts to final torque consecutively. Tightening torque ⇒ Item 4 (page 43).
- Install gearbox ⇒ page 71.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Controls, housing

Overview - selector mechanism

- ⇒ "1.1 Gear knob and covers exploded view", page 49
- ⇒ "1.2 Removing and installing gear knob with gear lever boot <u>", page 50</u>
- ⇒ "1.3 Exploded view selector mechanism", page 52
- ⇒ "1.4 Dismantling and assembling selector mechanism", <u>page 53</u>
- ⇒ "1.5 Removing and installing selector mechanism",
- ⇒ "1.6 Exploded view gear selector cable, gate selector cable and gearbox selector lever", page 62
- ⇒ "1.7 Removing and installing gear selector cable and gate selector cable", page 66
- ⇒ "1.8 Adjusting selector mechanism", page 68

A - Gear selector cable (gear selection movement)

B - Gate selector cable (gate selection movement)

C - Heat shield


Detach before removing selector mechanism.

-Arrow A- gear selection move ment

-Arrow B- gate selection movement

1 - Gearbox selector lever

2 - Relay lever



1.1 Gear knob and covers - exploded view

1 - Gear knob with gear lever

- Cannot be separated from each other
- □ Always renew as one unit
- Removing and installing ⇒ page 50
- □ Detaching from cover for centre console ⇒ page 50
- □ Disconnecting from se- F curing frame ⇒ page 50

2 - Clip

- □ Secures gear knob to gear lever
- Secure with hose clip pliers -V.A.G 1275-

3 - Trim panel for centre console

- □ Remove and install together with gear knob ⇒ page 50
- Detaching from gear lever boot ⇒ page 50

4 - Securing frame

- ☐ Detaching from trim panel for centre console ⇒ page 50
- □ Detaching from gear lever boot ⇒ page 50

5 - Washer

□ 4x

6 - Bolt


- ☐ 1.5 Nm
- □ 4x

7 - Noise insulation plate

8 - Noise insulation


9 - Gear lever

Adjusting selector mechanism ⇒ page 68




Detaching trim panel for centre console and securing frame for gear lever boot

- Remove bolts -arrows-.
- Detach trim panel from securing frame



Detaching securing frame and gear lever boot


 Carefully release tabs -arrows- and lift off securing frame -1from gear lever boot -2-.




1.2 Removing and installing gear who with Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Special tools and workshop equipment required

♦ Removal wedge -3409-



♦ Hose clip pliers -V.A.G 1275-



Removing

 The gear knob is removed together with the gear lever boot and the cover for the centre console.

- Open ashtray.
- Carefully lever off trim panel from centre console -arrows-.




- Unplug electrical connector on trim panel.
- Pull trim panel -3- up and over gear knob.
- Open clip -1- and pull off gear knob -2- together with gear lever boot and trim panel -3-.
- Detach gear lever boot and trim panel for centre console -3-⇒ page 50 .

Installing

Installation is carried out in reverse sequence; note the following:

- Push gear knob onto gear lever until it contacts stop.
- Secure gear knob to gear lever with a new clip -1-, using hose clip pliers -V.A.G 1275- .





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

AUOI

Exploded view - selector mechanism



1.3

Note

Lubricate bearings and moving surfaces with grease -G 000 450 02-.

1 - Floor plate

- Bend tabs open to remove
- Always renew

2 - Gasket

Always renew

3 - Gear lever

□ Can be removed and installed without removing gear lever guide

⇒ Item 15 (page 53)

4 - Damping washer

☐ Push onto gear lever as far as stop -arrow-

5 - Securing clip

- ☐ Take care not to damage selector cables when removing.
- Always renew

6 - Gate selector cable

- □ Lever off gate selector lever
- Press onto gate selector lever inside selector mechanism
- ☐ Installation position ⇒ page 48
- □ Removing and installing⇒ page 66

7 - Bush

8 - Gear selector cable

- ☐ Lever off gear lever guide
- Press onto gear lever guide inside selector mechanism
- ☐ Installation position ⇒ page 48
- □ Removing and installing ⇒ page 66

9 - Damper


10 - Bearing shell

- Will be damaged during removal
- Always renew

11 - Bush

12 - Securing clip

□ Removing and installing ⇒ page 53



- 13 Spring
- 14 Bush
- 15 Gear lever guide
- 16 Nut
- M6 8 Nm
- M8 25 Nm
 - □ 4x

17 - Gasket

- Between selector housing and floor
- □ Self-adhesive
- ☐ Glue onto selector housing


18 - Selector housing

- With spring and gate selector lever
- Spring and gate selector lever cannot be detached

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Removing and installing securing clip


- Hold gear lever -2- in position.
- Press spacer bush -3- in direction indicated (arrow).
- Take off securing clip -1-.



Dismantling and assembling selector 1.4 mechanism


Special tools and workshop equipment required


♦ Thrust block -T10083-




Dismantling

- Remove selector mechanism ⇒ page 57
- Using a screwdriver, bend open tabs -arrows- on all sides of floor plate and remove floor plate.
- Remove gasket from selector housing.
- Remove gear selector cable and gate selector cable from selector housing ⇒ page 66.
- Lift top spring arm -A- over tab on gate selector lever.
- Using a screwdriver, press lugs -arrows- on ball socket towards ball on gear lever guide; if necessary, break off lugs.





- Prise ball socket -A- out of selector housing together with gear lever guide and gear lever -B-.
- Then press ball socket -A- off ball on gear lever guide and remove.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Note

- Note guides -A- when performing the following steps.
- They must not break off.
- Swivel bottom spring arm -arrow 1- onto stop on shoulder of gate selector lever.



Caution

During the following steps, the bottom spring arm (-arrow 1-) can become dislodged and snap downwards off the shoulder of the gate selector lever.


- Pull gear lever guide upwards as far as stop and at the same time pull ball-head pin -arrow 2- out of gate selector lever.
- Press spring -arrow 1- carefully off the shoulder of the gate selector lever.


The spring arms will then compress "diagonally".

- Then turn gear lever guide in direction of -arrow 1-.
- The pin -arrow 2- should be positioned in the recess on the selector housing.
- Next, swivel gear lever guide out in direction of -arrow 3- together with gear lever.

 Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not a commercial purposes, in part or in whole, is not a commercial purposes.


permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liab with respect to the correctness of information in this document. Copyright by AUDI AG.






Assembling selector mechanism

- Release spring arms -A- and -B-.
- Spring arms -A- and -B- must point in opposite directions. (Shown here with gear lever guide installed.)




- Insert gear lever guide into selector housing together with gear
- Pin -arrow 1- should be positioned just inside recess on selector housing.
- Turn gear lever guide in direction of -arrow 2- until ball-head pin -A- is above recess on selector housing.



Protected by copy whole, is not permitted unless ept any liability AUDI AG.

- Position selector housing with gear lever guide onto thrusth respect to block -T10083- .
- The gear lever guide rests in the larger recess -arrow- in the thrust block -T10083- .
- Gear lever guide should protrude out of selector housing as far as stop.




- Insert arm -A- of spring in guide from above.
- Pull arm -B- of spring downwards and insert it next to the guide (towards ball head).




Note

For illustration purposes, only part of the gate selector lever is shown.


- Carefully take selector housing off thrust block -T10083- together with gear lever guide.
- Move gate selector lever rearwards as far as stop in direction of -arrow 1-.
- Grease ball-head pin.
- Press ball-head pin into hole in gate selector lever -arrow 2-.
- Guides -A- and tabs -B- must not be damaged.









- Now insert gear lever guide (which is now fitted in selector housing) into larger recess -arrow- in thrust block -T10083again.
- Gear lever guide should now protrude out of selector housing as far as stop.



- Lift top spring arm -A- over pin on gate selector lever.
- Use a new ball socket -B-.
- Grease ball socket and ball of gear lever guide.
- Press ball socket onto ball of gear lever guide as far as stop.
- Remove selector housing from thrust block -T10083-.
- Press ball socket into selector housing in direction of -arrows-.



- All four lugs -arrows- must engage.
- Lift top spring arm -A- over pin on gate selector lever into guide.
- Insert bottom spring arm into guide.
- Fit gear lever, gear selector cable, gate selector cable and floor plate.
- Install selector mechanism ⇒ page 60.




1.5 Removing and installing selector mech-


anismotected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

Special tools and workshop equipment requiredation in this document. Copyright by AUDI AG.

◆ Engine and gearbox jack -V.A.G 1383 A-



♦ Torque wrench -V.A.G 1331-




♦ Grease -G 000 450 02-


Removing

- Remove gear knob together with trim panel for centre console
 ⇒ page 50
- Remove centre console ⇒ Rep. Gr. 68.
- Remove noise insulation above selector mechanism.
- Remove nuts -arrows-.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Detach cable support bracket from gearbox -arrows-.




- Remove securing clip -1-.
- Pull gear selector cable -2- off pin.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


Release gate selector cable as follows:

- Pull locking mechanism forwards in direction of -arrow 1- onto stop and then turn in direction of -arrow 2- to lock.
- Press relay lever forwards (in direction of -arrow 3-) and pull out gate sélector cable.





- Unbolt bracket for exhaust system and tunnel brace -arrows-.







Note

To prevent damage, the flexible joints in the front exhaust pipe must not be bent further than 10°.

- Support front exhaust pipe and catalytic converter with engine and gearbox jack -V.A.G 1383 A- $\,$.
- Disconnect exhaust system at clamp -arrows-.




- Remove bolts -arrows-.
- Lower front exhaust pipe with catalytic converter slightly.
- Unclip Lambda probe wire and remove heat shield towards
- Remove selector housing with selector cables.



Installing selector mechanism

Installation is carried out in reverse sequence; note the following: Fit and secure selector housing ⇒ Item 16 (page 53).




- Route cables -1- from selector mechanism -2- to gearbox as follows:
- The cables must run parallel and must not be crossed.
- The cables must be routed in the slot provided in heat shield -3-.




Note


The enlargement shows the heat shield from above.



Secure heat shield -arrows-.



Assemble exhaust system so it is free of stress and install tunnel brace -arrows- ⇒ Rep. Gr. 26.





Secure cable support bracket -arrows-. Tightening torque ⇒ Item 6 (page 62) .



Protected by copyright. Copying for private or commercial purpos permitted unless authorised by AUDI AG. AUDI AG does not gua with respect to the correctness of information in this document

- Apply a small quantity of grease -G 000 450 02- to pin of gearbox selector lever.
- Position gear selector cable -2- on pin of gearbox selector lever and secure with new securing clip -1-.
- Insert gate selector cable in cable end-piece.
- Adjust selector mechanism ⇒ page 68.
- Fit noise insulation above selector mechanism and install centre console ⇒ General body repairs, interior; Rep. Gr. 68 .
- Install gear knob together with boot ⇒ page 50.





1.6 Exploded view - gear selector cable, gate selector cable and gearbox selector lever



Note

Lubricate all bearings and moving surfaces with grease -G 000 450 02- .

1 - Gear selector cable

- ☐ Installation position

 ⇒ page 48
- Removing and installing⇒ page 66
- Adjusting ⇒ page 68
- □ Secure to gate selectord cable with cable upon the sault space of t

2 - Gate selector cable

- ☐ Installation position ⇒ page 48
- □ Removing and installing⇒ page 66
- Adjusting ⇒ page 68
- Secure to gear selector cable with cable tie⇒ page 64

3 - Bush

4 - Selector housing

Dismantling and assembling ⇒ page 52

5 - Retaining clips

- ☐ Take care not to damage selector cables when removing.
- Always renew

6 - Bolt

- □ 20 Nm
- □ 3x
- For support bracket

7 - Support bracket

■ With cable guide


8 - Grommet

☐ For support bracket mounting on gearbox

9 - Bush

10 - Cable end-piece

- Secures gear selector cable to gearbox selector lever
- □ Do not interchange; cable end-pieces for gate selector cable and gear selector cable are different ⇒ Fig. " A Identification according to diameter of bore in cable end-piece ", page 63
- □ Release to adjust selector mechanism ⇒ page 69



11 - Securing clip

12 - Cable end-piece

- □ Secures gate selector cable to relay lever
- Do not interchange; cable end-pieces for gate selector cable and gear selector cable are different ⇒ Fig. "A - Identification according to diameter of bore in cable end-piece ", page 63
- □ Detaching from gate selector cable ⇒ page 65
- □ Detaching from relay lever ⇒ page 65
- ☐ Pressing onto relay lever ⇒ page 66
- □ Release to adjust selector mechanism ⇒ page 69

13 - Relay lever

- □ Installation position ⇒ page 64
- □ Removing and installing ⇒ page 65

14 - Slide block

15 - Gearbox selector lever

- With damper weight
- ☐ Install so that gap in splines aligns with selector shaft ⇒ page 64
- ☐ After installing, adjust selector mechanism ⇒ page 68
- ☐ Installation position ⇒ page 64

16 - Nut


- □ 25 Nm
- Self-locking
- Always renew



A - Identification according to diameter of bore in cable end-piece ying for


The holes in the cable end-pieces have different diameters he correctness

Cable end-piece for:	Distance "a"
Gear selector cable to gearbox selector lever	8.5 mm
Gate selector cable to relay lever	10 mm



Installing gearbox selector lever


 When installing gearbox selector lever, make sure that the gap in the splines -arrow A- aligns with the wider spline -arrow Bon the selector shaft.



Installation position of gearbox selector lever and relay lever


- 1 Gearbox selector lever with damper weight
- 2 Arrow marking
- Points to pin on relay lever (in neutral position)
- 3 Relay lever
- Locates in guide rail of gearbox selector lever via slide block
 -arrow-.

 Protected by copyright. Copying for private permitted unless authorised by AUDI AG. with respect to the correctness of inform



Position of cable tie securing selector cables

 Wrap cable tie round selector cables in a "figure-of-eight" -arrow- and secure cable tie as shown in illustration.



A34-10572

Disconnecting cable end-piece from gate selector cable



Note

- Cable end-piece must be detached from gate selector cable before removing relay lever.
- Do not detach cable end-piece from relay lever until relay lever has been removed.
- Pull locking mechanism forwards in direction of -arrow 1- onto stop and then turn to left in direction of -arrow 2- to lock.
- Then press relay lever forwards (in direction of -arrow 3-).

Removing and installing relay lever

Press detent -arrow 1- down onto stop and remove relay lever together with cable end-piece. Move relay lever in normal direction of operation.



Note

-Arrow 2- can be disregarded.

Installing relay lever




Note


To install, lubricate bearings and moving surfaces with grease -G 000 450 02- .


- Press cable end-piece onto relay lever ⇒ page 66.
- Insert relay lever with cable end-piece as far as stop.
- Relay lever is secured by detent -arrow 1-.
- Cable end-piece is secured by detent -arrow 2-.
- Ensure that components engage securely.

Levering cable end-piece for gate selector cable off plastic relay lever

- Relay lever is removed.
- Insert a plain slot screwdriver -A- between bush -B- and relay lever.









Protected by copyright. Copying for private or commercia permitted unless authorised by AUDI AG. AUDI AG does with respect to the correctness of information in this d

Pressing cable end-piece onto plastic relay lever

- · Relay lever is removed.
- · Press on cable end-piece only at bush -arrow-.




- Cable end-piece must protected by appring to private or commercial purpo
 Cable end-piece must protected by appring to private or commercial purpo
- Cable end-piece must be behind detent -arrow 2-.
- · Ensure that components engage securely.




1.7 Removing and installing gear selector cable and gate selector cable

Removing

- Remove selector mechanism ⇒ page 57
- Using a screwdriver, bend open tabs -arrows- for selector mechanism on floor plate and remove floor plate.
- Remove gasket.




- Pull off securing clips -1 ... 2-.
- Lever off gate selector cable -3- / gear selector cable -4- with a screwdriver and pull cable out of selector housing.




Release cable end-piece -A- as follows:

- Push sleeve forwards onto stop -arrow 1-.
- Turn sleeve clockwise onto stop -arrow 2- so that it engages.
- Detach cable end-piece -A- from cable -B-.



- Pull off securing clips -1- and -2-.
- Detach support bracket from cables.


Protected by copyright. Copying for private or commercial purposes, in part or in who permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept an with respect to the correctness of information in this document. Copyright by AUD




Installing

Installation is carried out in reverse sequence; note the following:

- Secure gear selector cable and gate selector cable to selector housing with securing clips -1 ... 2-.
- Press gate selector cable -3- onto relay lever.
- Press gear selector cable -5- onto gearbox selector lever. Make sure sleeve -4- engages securely.




- Fit gasket and secure floor plate to selector mechanism by bending over tabs -arrows-.
- Install selector mechanism ⇒ page 60.
- Adjust selector mechanism ⇒ page 68.



1.8 Adjusting selector mechanism

Special tools and workshop equipment required

♦ Locking pin -T10027A-



Requirements for adjustment pyright. Copying for private or commercial purposes, in part or in whole, is not

- Gear selector linkage must be in proper condition and undam-opyright by AUDI AG. aged.
- Selector mechanism must move freely.
- Gearbox, clutch and clutch mechanism must be in proper condition.
- Gearbox in neutral.

Adjusting

- Open ashtray.
- Carefully lever off trim panel from centre console -arrows-.
- Pull trim panel up and over gear knob.



permitted unless authorised by AUDI AG


N34-1857

- With gearbox in neutral, guide gear lever to the left into 1st/ 2nd gear gate.
- Lift noise insulation plate and lock gear lever in position with locking pin -T10027A-.



Note

The noise insulation panels are removed to give a better illustra-



Release cable end-pieces for gate selector cable and gear selector cable as follows: Protected by copyright. Copying for private

- Push locking sleeves on gear selector cable and gate selector finform cable forward as far as they will go -arrow 1-.
- Turn locking sleeve as far as it will go in direction of arrow -2- so that it engages.



Note

It should now be possible to move the cables in the cable endpieces.

Gearbox in neutral.

Lock the selector shaft as follows:

Push gearbox selector lever down into 1st/2nd gear gate -arrow 1-. At the same time, turn locking pin -2- in direction of arrow -B- until it engages.

The selector shaft is then locked and can no longer be moved.


- Ensure that the gate selector cable and the gear selector cable are located free of tension in the cable end-pieces.
- Now turn locking sleeves on gear selector cable and gate selector cable as far as they will go in the direction indicated (arrow).


The spring presses the locking sleeve back into the original position.




Note

Cable adjustment is now complete.








Protected by copyright. Cop

permitted unless authorised

- Now turn locking pin -A- back to original position (direction of arrow).
- Pull locking pin -T10027A- out of selector mechanism.



Check gear lever setting as follows:


- The gear lever should rest in the 3rd/4th gear gate when the gearbox is in neutral.
- Depress clutch.
- Select all gears several times. Pay particular attention to the operation of the reverse gear locking mechanism.

Should a gear fail to engage smoothly after repeated selection, check the play (lift movement) of the selector shaft as follows:

- Engage 1st gear.
- Push gear lever as far as it will go to the left and release.
- At the same time observe selector shaft on gearbox (2nd mechanic).
- The selector shaft should move up and down approx. 1 mm (in direction of -arrow-) when the gear lever is moved.

If this is not the case, adjust selector mechanism again ⇒ page 68.

- Fit gear lever boot.



Removing and installing gearbox 2

- \Rightarrow "2.1 Removing and installing gearbox on vehicles with 1.8 ltr. TFSI engine", page 72 .
- ⇒ "2.2 Installing gearbox on vehicles with 1.8 ltr. FSI turbocharged engine", page 81
- ⇒ "2.3 Transporting gearbox", page 88





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

2.1 Removing and installing gearbox on vehicles with 1.8 ltr. TFSI engine

Special tools and workshop equipment required

- Support bracket -10 222
 A-
- ♦ Gearbox support -3282-
- ♦ Adjustment plate -3282/39-
- Engine and gearbox jack -V.A.G 1383 A-
- ◆ Engine support -3300 A-
- ♦ Support -T10036-
- ♦ Bolt M6×20 (2x)
- ♦ Bolt M10×20
- ♦ Grease for clutch plate copyright splines -G 000 pt 00 ted unless aut with respect to the





W00-0212



Caution


When disconnecting the battery there is a risk of serious damage to electronic components:


- Observe the correct procedure for disconnecting the battery ⇒ Electrical system; Rep. Gr. 27.
- Take out luggage compartment floor cover.
- Release retaining clips -arrows- and remove cover for negative terminal.




Note

Remove rear cross panel trim if necessary for access to negative terminal of battery ⇒ Rep. Gr. 70.









- Remove engine cover panel -arrows-.
- Remove air cleaner housing completely ⇒ Rep. Gr. 24.






Remove bolts -arrows- and detach bracket for air cleaner housing.




- Detach cable support bracket from gearbox -arrows-.
- Remove bracket -B- from gearbox and disconnect from pipe/ hose assembly -A-.



Protected by copyright. Copying for private or commercial p permitted unless authorised by AUDI AG. AUDI AG does not be a commercial provided by AUDI AG. with respect to the correctness of information in this docu



- Detach securing clip -arrow 1- and pull off gear selector cable.
- Press detent -arrow 2- down onto stop and remove relay lever together with cable end-piece. Move relay lever in normal direction of operation.
- Tie cables with cable support bracket to one side.
- Remove nut -arrow 3- and detach gearbox selector lever -A-.



- Remove brace -1-.
- Move clear hydraulic line going to clutch slave cylinder.
- Unbolt clutch slave cylinder -arrows- and place to one side; do not disconnect pipe.





Caution

Do not depress clutch pedal after removing slave cylinder.




- Disconnect B+ wire from starter solenoid -2-.
- Disconnect earth wire -3- and remove top bolt securing starter.
- Unplug electrical connector -4- at reversing light switch -F4-.






Remove engine/gearbox securing bolts -1 and 2- (accessible from above).




- Remove the two bolts (top) on radiator cowl -1-.




Protected by copyright. Copying for private or conpermitted unless authorised by AUDI AG. AUDI A with respect to the correctness of information is


- Assemble support bracket -10 222 A- and place onto wing panel flange, as shown in illustration.
- Engage hook of spindle in engine lifting eye (left-side).
- Take up weight of engine/gearbox assembly with spindle; do




- Raise vehicle.
- Remove noise insulation (centre) -1- ⇒ Rep. Gr. 66.




- Remove front left wheel.
- Remove left noise insulation -arrows-.




Remove frame for noise insulation -arrow- ⇒ Rep. Gr. 50.



- Remove nut -arrow- and detach bracket for electrical wiring.
- Remove bottom bolt securing starter and take out starter.




Slightly lift retaining clip -1- and loosen hose clip -2- to remove air hose.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- Detach electrical connector -2-.
- Remove bolts -3- and take out radiator cowl from below.




- Unbolt heat shield for drive shaft (right-side) -arrows-.
- Unbolt drive shafts (left and right) from flange shafts on gear-
- Lift drive shafts (left and right) up and secure with cable tie.




Note

Make sure you do not damage surface coating on drive shafts.

Remove bolts -1 ... 3- and detach pendulum support.






- Spay rust remover onto studs on turbocharger -arrows-. Protected by copyright. Cop
- Remove nuts -arrows-.
- with respect to the correct Detach catalytic converter from turbocharger and secure catalytic converter to prevent it from falling to the ground.




Note


- To prevent damage, the flexible joints in the front exhaust pipe must not be bent further than 10°.
- -Item 1- and -item 2- can be disregarded.



Remove bolts -arrows- on gearbox mounting.




- Lower engine/gearbox assembly using spindle of support bracket -10 222 A- until distance -a- is obtained between gearbox housing and gearbox mounting.
- Dimension -a- = 50 mm




- Unbolt gearbox bracket -A- from gearbox -arrows-.



Protected by copyright. Copying for private or commercial purposes, in par permitted unless authorised by AUDI AG. AUDI AG does not guarantee or with respect to the correctness of information in this document. Copyrig




Unclip bracket -2- for electrical wiring leading to oil level and oil temperature sender -G266- at subframe.




A10-10025


If fitted, unbolt heat shield for power steering control unit -J500- from subframe -arrows-.



- Drill two 7 mm diameter holes in support -T10036- , as illustrated (if holes have not already been drilled).
- Dimension -a- = 70 mm
- Dimension -b- = 98 mm
- Dimension -c- = 11 mm




Bolt support -T10036- onto subframe -arrows- using two M6×20 bolts.




Bolt engine support -3300 A- onto support -T10036-.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




- Press engine towards front of vehicle using spindle of engine support -3300 A- . Pay special attention to the following points:
- The air conditioner compressor -2- must not contact refrigerant line -1- -arrow-.
- Alternator must not make contact with refrigerant line.
- Pressure pipe must not make contact with radiator.




Set up gearbox support -3282- with adjustment plate -3282/39and mount on engine and gearbox jack -V.A.G 1383 A-.

- Align arms of gearbox support according to holes in adjustment plate -3282/39- .
- Bolt on support elements -A- and -C-, as illustrated on adjustment plate .
- The arrow symbol -B- on the adjustment plate points in the direction of travel.




- Place engine and gearbox jack -V.A.G 1383 A- underneath
- Align gearbox support -3282- parallel with gearbox.
- Screw pin -3282/29- into gearbox.
- Insert the two remaining support elements in gearbox as illustrated.
- Support gearbox from underneath by raising engine and gearbox jack -V.A.G 1383 A-




Remove remaining engine/gearbox securing bolts -5 and 6-.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




Push the gearbox off the dowel sleeves and swing carefully towards the subframe.



Then guide flange shaft (right-side) -1- past recess -arrow- in intermediate plate.


- Incline gearbox via spindles of gearbox support -3282- .
- The differential must face upwards.
- Pivot gearbox downwards in area of 6th gear.



- Guide gearbox with differential past subframe -A- and swivel
- When lowering the gearbox, change position of gearbox using the spindles on gearbox support -3282-..

Transporting gearbox ⇒ page 88.

Installing gearbox ⇒ page 81



Installing gearbox on vehicles with 1.8 2.2 Itr. FSI turbocharged engine

Installation is carried out in reverse sequence; note the following:

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not

Tightening torques > page 88 ermitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Note


- Renew self-locking nuts and bolts when performing assembly work.
- Renew oil seals, gaskets, O-rings and bolts which are tightened by turning through a specified angle.
- ◆ Secure all hose connections with the correct hose clips (as original equipment); refer to ⇒ Parts catalogue.
- ♦ All cable ties which are released or cut open during removal must be fitted in the same position when installing.
- Clean input shaft splines and (in the case of a used clutch plate) the hub splines. Remove corrosion and apply only a very thin coating of grease -G 000 100- to the splines. Then move clutch plate backwards and forwards on input shaft until hub moves freely on shaft. It is important to remove excess grease.
- When renewing the gearbox, the gearbox selector lever must be transferred to the new assembly.
- Use thread tap to remove any remaining locking fluid from all threaded holes which will accommodate self-locking bolts.
- Check that dowel sleeves for centralising engine/gearbox are in the cylinder block; install if necessary.
- If the dowel sleeves are not fitted, this will lead to gear-change problems, clutch malfunction and in some cases gearbox noise (gears will make rattling noises).
- Make sure that the intermediate plate is engaged on the sealing flange and fitted on the dowel sleeves -arrows-.
- Check release bearing for wear. Renew slave cylinder and release bearing if necessary ⇒ page 25.
- Check that clutch plate is centralised ⇒ page 44.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is no permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


is not ability a.

9

- Incline gearbox via spindles of gearbox support -3282- .
- · The differential must face upwards.
- · Pivot gearbox downwards in area of 6th gear.
- Then raise gearbox carefully.
- Guide gearbox with differential past subframe -A- and swivel in direction of -arrow-.




Make sure longitudinal member -B- is not in the way.




- Guide flange shaft (right-side) -1- past recess -arrow- in intermediate plate.
- Align gearbox with engine in installation position and install.
- Bolt gearbox onto engine. Tightening torques ⇒ page 88
- Detach gearbox jack with gearbox support -3282- from gearbox after bolting gearbox to engine.
- N34-11127

Remove engine support -3300 A- and support -T10036- .



- Secure gearbox bracket -A- to gearbox with new bolts -arrows-. Tightening torque ⇒ Item 8 (page 90).
- Pull gearbox up to support arm of gearbox mounting with spindle on support bracket -10 - 222 A- .





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Aud

 Align engine/gearbox in installation position. To do so, raise engine/gearbox until gearbox bracket makes full contact with gearbox mounting.



Note

Gearbox mounting and gearbox bracket must be parallel to avoid causing damage to thread of gearbox bracket.

 Use new bolts -arrows- to secure gearbox mounting to gearbox bracket. Tightening torque ⇒ Item 12 (page 90)




WARNING

Do not remove support bracket -10 - 222 A- until all bolts securing the left-hand engine/gearbox mounting have been tightened to the specified torque.


- Fit pendulum support with new bolts -1 ... 3- in accordance with installation instructions ⇒ page 94 . Tightening torques ⇒ page 90
- Check adjustment of engine/gearbox mountings Projected by Copyright. Copyright. On the copyright of the copyright.


A10.1634




- Fit radiator cowl and and tighten bottom bolts -3-.
- Attach electrical connector -2-.

 Install air intake hose. Make sure retaining clip -arrow- snaps onto retaining lug -A-.






Secure catalytic converter to turbocharger -arrows- ⇒ Engine, mechanics; Řep. Gr. 26.



- Secure drive shafts (left and right) to gearbox ⇒ Rep. Gr. 40.
- Secure guard plate for drive shaft (right-side) -arrows-.





- Install starter ⇒ Rep. Gr. 27.
- Fit bracket and secure with nut -arrow-.
- Connect earth strap at upper engine/gearbox securing bolt.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


- Tighten top bolts for radiator cowl -1-.





- Install clutch slave cylinder -arrows-. Tightening torque ⇒ Item 15 (page 24)
- Install brace -1-. Tightening torque ⇒ Item 1 (page 90).








Note

To install, lubricate bearings and moving surfaces with grease -G 000 450 02-.


- Tighten hexagon nut -4- to specified torque ⇒ Item 16 (page 63) .
- Insert relay lever -5- with cable end-piece as far as stop. Installation position ⇒ page 64
- Attach gear selector cable -1- to gearbox selector lever and secure with securing clip -2-.
- Ensure that components engage securely.
- Cable end-piece is secured by detent -arrow 1-.
- Cable end-piece must be behind detent -arrow 1-.
- Relay lever is secured by detent -arrow 2-.




3 A34-10574




- Secure cable support bracket -arrows-. Tightening torque ⇒ Item 6 (page 62)
- Fit bracket -B- to gearbox. Tightening torque ⇒ Item 20 (page 24) .
- Push pipe/hose assembly -A- into bracket -B- on gearbox.




- Unplug electrical connector arrow at reversing light switch erical pur permitted unless authorised by AUDI AG. AUDI AG does not guarantee or a with respect to the correctness of information in this document. Copyright
- Adjust selector mechanism ⇒ page 68.




- Fit bracket -1- for air cleaner housing -arrows-.
- Install complete air cleaner housing ⇒ Rep. Gr. 24.
- Install engine cover panel.




- Raise vehicle.
- Check gear oil level in gearbox ⇒ page 95.
- Install noise insulation frame -arrow- ⇒ Rep. Gr. 50; Removing and installing noise insulation frame.



Install left noise insulation -arrows-.



- Install noise insulation (centre) -1- ⇒ Rep. Gr. 66.
- Connect battery ⇒ Electrical system; Rep. Gr. 27.




Tightening torques

Securing gearbox to 1.8 ltr. TFSI engine

Item	Bolt	Nm
1, 2	M12x65	80
3 1)2)	M12x150	80
4 1)2)	M12x165	80
5	M10x50	40
6	M12x85	80
Α	Dowel sleeves for centralising	
43	<u> </u>	



2) Also starter to gearbox




Component with	respect to Nm correctnes
Bracket for electrical wiring at bottom starter bolt	23
Heat shield for drive shaft to cylinder block	25

ing for private or commercial purposes, in part or in whole, is not by AUDI AG. AUDI AG does not guarantee or accept any liability ness of information in this document. Copyright by AUDI AG.


2.3 Transporting gearbox

Special tools and workshop equipment required

◆ Gearbox lifting tackle -3336-




♦ Workshop hoist -VAS 6100-



Bolt gearbox lifting tackle -3336- to clutch housing.






Set support arm on sliding bracket by means of locking pin -arrow-.

Number of holes visible = 5

- Lift gearbox using workshop hoist -VAS 6100- and gearbox lifting tackle 3336.
- Set down gearbox as required (for example in transport container).



3 Exploded view - assembly mountings

1 - Bolt

- □ 20 Nm + 90°
- Gearbox support to gearbox and gearbox bracket
- ☐ Tightening sequence ⇒ page 91
- Always renew

2 - Gearbox support

☐ To gearbox bracket and gearbox

3 - Engine mounting with engine support

- □ Removing and installing⇒ Rep. Gr. 10
- ☐ Tightening torques ⇒ Rep. Gr. 10

4 - Bolt

- □ 100 Nm + 90°
- Pendulum support to subframe
- Always renew

5 - Pendulum support

□ Removing and installing⇒ page 94

6 - Bolts

- □ 50 Nm + 90°
- ☐ Pendulum support to gearbox
- □ Always renew

7 - Bolts

- □ 50 Nm + 90°
- Pendulum support to gearbox
- Always renew

8 - Bolt

- □ 40 Nm + 90°
- ☐ Gearbox bracket to gearbox
- Always renew


9 - Gearbox bracket

10 - Gearbox mounting

- □ Removing and installing ⇒ page 91
- ☐ Fit to gearbox bracket

11 - Bolt

- □ 40 Nm + 90°
- ☐ Gearbox mounting to body
- ☐ Tightening sequence ⇒ page 91
- □ Always renew




12 - Bolt

- □ 60 Nm + 90°
- ☐ Gearbox mounting to gearbox bracket
- □ Always renew


Attaching gearbox mounting to gearbox bracket

- Renew bolts.
- Tighten all bolts hand-tight.
- Tighten bolts to specified torque.



Gearbox support to gearbox bracket and gearbox


- Renew bolts.
- Initially tighten both bolts -arrows- hand-tight.
- Tighten bolts to specified torque.



Removing and installing gearbox 3.1 mounting


Special tools and workshop equipment required ate or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

♦ Support bracket -10 wi222pAt to the correctness of information in this document. Copyr




Removing


- Remove engine cover panel -arrows- ⇒ Rep. Gr. 10.
- Remove air cleaner housing completely ⇒ Rep. Gr. 24.



Remove bolts -arrows- and detach bracket for air cleaner housing.




- Set up support bracket -10 222 A- with adapters -10 222 A/ 1- on wing mounting flanges.
- Engage hook of spindle -10 222 A /11- in lifting eye.
- Take up weight of engine evenly with spindles; do not lift.




Remove bolts -arrows-.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Open retainers for wiring duct -arrows-.
- Cut open cable tie -1- and push electrical wiring to one side.
- Unclip wiring duct.




- Remove bolts -1- and detach gearbox mounting -A-.

Installing

Installation is carried out in reverse sequence; note the following:

- Tightening torques <u>⇒ page 90</u>
- Fit gearbox mounting -A- with new bolts -1- to longitudinal member.






Caution

The threads in the gearbox bracket can be damaged if the bolts are not inserted straight.

- Before fitting the bolts -arrows-, the gearbox bracket and the support arm of the gearbox mounting must be aligned absolutely parallel. If necessary, push the gearbox up at the rear with a trolley jack.
- Pull gearbox up with spindle on support bracket until gearbox bracket contacts support arm of gearbox mounting.
- Adjust assembly mountings ⇒ Rep. Gr. 10.
- Bolt support arm of gearbox mounting to gearbox bracket -arrows-.
- Detach support bracket -10 222 A- from engine.
- Install engine cover panel ⇒ Rep. Gr. 10.

Install air cleaner housing ⇒ Rep. Gr. 24 .


Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



3.2 Removing and installing pendulum support

Removing

Remove noise insulation (centre) -1- ⇒ Rep. Gr. 66.




- Unscrew bolts -1 ... 3- and remove pendulum support.


Installing pendulum support

Installation is carried out in reverse sequence; note the following:

Tightening torques ⇒ page 90



- First secure pendulum support to gearbox -arrow B- and -arrow C-, then on subframe -arrow A-.
- Install noise insulation (centre) ⇒ Rep. Green by copyright. Copying for prive permitted unless authorised by AUDI A with respect to the correctness of inf




Checking gear oil level and filling up 4 with gear oil



Caution


It is not possible to check the gear oil level by removing the oil filler plug.

> Protected by copyright. Copying for private or commercial purposes, in permitted unless authorised by AUDI AG. AUDI AG does not guarante with respect to the correctness of information in this document. Cop




Due to the inclination of the engine/gearbox assembly, the oil level -arrow 2- will be above the lower edge of the filler hole

The gear oil level can only be checked by draining the gear oil completely and then filling up again:




Special tools and workshop equipment required

♦ Used oil collection and extraction unit -V.A.G 1782-







- Hose (length approx. 600 mm, outer circumference 10 mm) with funnel (commercially available)
- Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not per private or commercial purposes, in part or in whole, is not per private parallel by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Gear oil for direct shift gearbox ⇒ Electronic parts catalogue

- Remove air cleaner housing ⇒ Rep. Gr. 24.
- Remove noise insulation (centre) -1- ⇒ Rep. Gr. 66.

Clean gearbox.




Caution


A pivot pin for the selector forks in the gearbox must be removed in order to drain the gear oil.

The selector shaft must be locked to prevent the position of the selector forks from being changed, e.g. due to accidental operation of the selector mechanism.

Lock the selector shaft as follows:



- Press selector shaft down (direction of -arrow 1-).
- While pressing selector shaft down, move angled rod -A- upwards in direction of -arrow 2-. At the same time press angled rod carefully into selector shaft until it engages.




4.2 Draining off gear oil


Use a clean container (capacity 3.0 ltr.) with a graduated scale to collect gear oil.

Selector shaft must be locked ⇒ page 96

- Remove oil drain plug -arrow 1-, then remove pivot pin -arrow 2- and drain off gear oil.
- Install pivot pin -arrow 2- with a new O-ring ⇒ Item 7 (page 103)



- Fit oil drain plug -arrow 1- ⇒ Item 17 (page 122).
- Now turn angled rod -A- back to original position (direction of -arrow-) so that selector shaft can move freely again.




4.3 Filling up with gear oil

Add gear oil to container until amount of gear oil in container is 1.9 ltr.

For gear oil specification, refer to ⇒ Electronic parts catalogue.

- Remove reversing light switch -F4- -arrow-.
- Fit hose (length approx. 600 mm, outside diameter 10 mm) to funnel (commercially available)
- Insert hose in mounting hole of reversing light switch -F4- and fill gearbox with gear oil (2nd mechanic required).
- Re-install reversing light switch -F4- -arrow-⇒ Item 2 (page 131)
- Install complete air cleaner housing ⇒ Rep. Gr. 24
- Install noise insulation ⇒ Rep. Gr. 66.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

5 Overview - gearbox


- 1 1st gear
- 2 2nd gear
- 3 3rd gear
- 4 4th gear
- 5 5th gear
- 6 6th gear
- 7 Gearbox housing cover
- 8 Gearbox housing
 - □ Servicing ⇒ page 121
- 9 Selector mechanism
 - □ (Selector forks)
 - ☐ Dismantling and assembling ⇒ page 134
- 10 Reverse gear wheel
- 11 Clutch housing
 - ☐ Servicing <u>⇒ page 121</u>
- 12 Input shaft
 - ☐ Dismantling and assembling ⇒ page 139
- 13 Output shaft
 - ☐ Dismantling and assembling ⇒ page 151
- 14 Differential



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Exploded view - dismantling and assembling gearbox 5.1





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

I - Removing and installing gearbox housing cover and 5th/6th gear ⇒ page 100

- II Removing and installing gearbox housing and selector mechanism ⇒ page 103
- III Removing and installing input shaft, output shaft, differential and selector forks ⇒ page 104

5.2 Exploded view - removing and installing gearbox housing cover and 5th/6th gear

1 - Gearbox housing

Servicing ⇒ page 121

2 - 5th gear wheel

□ Removing and installing⇒ page 104

3 - Sleeve

4 - 6th gear wheel

Removing and installing⇒ page 104

5 - Roller bearing inner race


- For output shaft
- Mark before removing
- Do not interchange with roller bearing inner race for input shaft
- Larger outer diameter on gearboxes manufactured from 21 08 6 onwards
- □ Allocation ⇒ page 102

6 - Bolt

- □ For output shaft
- Up to gearbox manufacturing date 20 08 6:
 - □ 40 Nm + 180°
- From gearbox manufacturing date 21 08 6:
 - □ 80 Nm + 90°
 - Allocation of bolts⇒ page 102
 - Self-locking
 - Always renew
 - ☐ Use thread tap to remove any remaining locking fluid from threaded holes for bolts securing 5th/6th gear synchronising hub and 6th gear wheel. Otherwise there is a risk that the bolts will shear off

7 - Gearbox housing cover

- With roller bearings for input and output shafts
- □ Roller bearings for input and output shafts with larger outer diameter on gearboxes manufactured from 21 08 6 onwards ⇒ page 129
- Servicing ⇒ page 127





If the gearbox housing cover is installed with the gearbox in the vehicle, check and top up oil

	<i>⇒ page 95</i> .
8 - B	olt
	18 Nm
	5x
	For gearbox housing cover
9 - B	olt
	For input shaft
	3 · · · · · · · · · · · · · · · · · · ·
	Allocation of bolts <u>⇒ page 102</u> Self-locking
	Use thread tap to remove any remaining locking fluid from threaded holes for bolts securing 5th/6th gear
	synchronising hub and 6th gear wheel. Otherwise there is a risk that the bolts will shear off
10 -	Roller bearing inner race
	For input shaft
	Mark before removing
	, = v ··································
rotected by	On gearboxes manufactured from 21 08 6 onwards, thrust washer and roller bearing inner race are one component the Item 12 (page 101)s, in part or in whole, is not less authorised by AUDI AG. AUDI AG does not quarantee or accept any liability
with respe	less authorised by A ODI AG. AODI AG does not guar antee or accept any liability ct Allocation of roller bearing inne ntrace நாகும் <mark>நடி page i 102</mark>
11 -	Thrust washer
	On gearboxes manufactured up to 20 08 6
12 -	Roller bearing inner race with thrust washer
	For input shaft
	3. 3. 4. 4. 4. 4. 4. 4. 4. 4. 4. 4. 4. 4. 4.
	Sleeve
_	For 6th gear needle bearing
	3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3
	Larger diameter on gearboxes manufactured from 21 08 6 onwards Select correct components from ⇒ Electronic parts catalogue
44	
	Needle bearing For 6th gear
٥	
_	
15 -	6th speed selector gear
	Modified according to sleeve and needle bearing on gearboxes manufactured from 21 08 6 onwards
	Select correct components from ⇒ Electronic parts catalogue
16 -	6th gear synchro-ring
17 - 1	Locking collar with synchronising hub for 5th and 6th gear
	Removing and installing <u>⇒ page 104</u>
	Dismantling and assembling ⇒ page 139

- ☐ Locking collar modified on gearboxes manufactured from 12 06 6 onwards <u>⇒ page 145</u>
- Adjusting on gearboxes manufactured up to 11 06 6 ⇒ page 118
- Adjusting on gearboxes manufactured from 12 06 6 onwards ⇒ page 119
- ☐ Installing offset springs for locking pieces <u>⇒ page 146</u>

18 - 5th gear synchro-ring


- ☐ Will be damaged when input shaft is removed
- □ Always renew
- 19 5th speed selector gear
- 20 Needle bearing
 - □ For 5th gear
- 21 Socket head bolt
 - □ 25 Nm
 - ☐ For pivot pin to gearbox housing
- 22 Pivot pin
- 23 5th/6th gear selector fork
- 24 5th/6th gear selector jaw
- 25 Bolt
 - □ 25 Nm



Protected by copyright. Copying for private or commercial


Allocation of securing bolts and roller bearing inner races for input of AG d

Gearbox manufac- turing date	Dimension "a" (mm)	Dimension "b" (mm)
Up to 20 08 6	21	31
From 21 08 6 on- wards	23.4	 37 In addition: inner race and thrust washer are combined as one component -arrow-



Allocation of securing bolts and roller bearing inner races for output shaft

Gearbox manufac- turing date	Dimension "a" (mm)	Dimension "b" (mm)
Up to 20 08 6	21	31
From 21 08 6 on- wards	23.4	37



5.3 Exploded view - removing and installing gearbox housing and selector mechanism

1 - Countersunk bolt

□ 25 Nm

2 - Flange shaft (left-side) with spring

- □ Removing and installing
 - ⇒ page 172
- Assembling ⇒ page 179

3 - Torx socket head bolt

- □ 25 Nm
- ☐ For reverse shaft support
- □ Self-locking
- Always renew

4 - Torx socket head bolt

- □ 30 Nm
- ☐ For reverse shaft support
- □ Self-locking
- Always renew

5 - O-ring

- □ Always renew
- 6 Pivot pin

7 - Bolt

- ☐ 25 Nm Protected by copyright. Copyright. permitted unless authoris
- 8 Bolt

with respect to the corre

- □ 25 Nm
- 9 Sealing cap

10 - Multi-point socket head bolt

- □ 25 Nm
- □ For reverse shaft support
- □ Always renew

11 - Gearbox housing

□ Servicing ⇒ page 121

12 - Clutch housing

□ Servicing ⇒ page 121

13 - Bolt


- □ 25 Nm + 90°
- □ Always renew

14 - Selector mechanism

Servicing ⇒ page 134

15 - Multi-point socket head bolt

□ 25 Nm



Audi TT 2007 ➤

5.4 Exploded view - removing and installing input shaft, output shaft (pinion shaft), differential and selector forks

1 - Differential □ Dismantling and assembling ⇒ page 179 2 - Seal □ 4x □ Always renew 3 - Output shaft

Dismantling and assembling ⇒ page 151

4 - Reverse shaft supportDismantling and assem-

bling ⇒ Item 8 (page 168)

5 - Reverse shaft

☐ Dismantling and assembling ⇒ page 168

6 - Input shaft

Dismantling and assembling ⇒ page 139

7 - Reverse gear selector fork

- Dismantling and assembling ⇒ page 134 spect to the
- ☐ Installation position ⇒ page 112

8 - Torx socket head bolt

□ 25 Nm

9 - Selector mechanism

- □ (Selector forks)
- ☐ Dismantling and assembling ⇒ page 134

10 - Clutch housing

Servicing ⇒ page 121

11 - Nut

- □ 25 Nm + 90°
- 4 nuts for bearing mounting
- Always renew

12 - Flange shaft (right-side) with spring


- ☐ Removing and installing ⇒ page 175
- □ Assembling ⇒ page 179

13 - Countersunk bolt

□ 25 Nm


5.5 Dismantling and assembling sequence

Removing and installing cover for gearbox housing, clutch housing, selector shaft with selector cover, input shaft, output shaft (pinion shaft), differential and selector mechanism



Special tools and workshop equipment required


- ◆ Support plate -VW 309-
- Gearbox support -VW 353-
- ♦ Drift -VW 295-
- Drift sleeve -VW 244 B-
- ♦ Hot air blower -V.A.G 1416-
- Torque wrench -V.A.G 1331-
- -Stehbolzen M 8 x 100 mm-






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- Support bridge -30-211A-
- Thrust piece -32 111-
- Thrust piece of assembly tool -T10030/4-
- Tube -VW 416 B-
- Puller -T10309-
- Two-arm puller -T10040-
- With claw -T10040/2-




Special tools and workshop equipment required

• or for 6th gear wheel




Two-arm puller -1 Kukko 20/10-

♦ Thrust plate -40 - 105-




♦ Torque wrench -V.A.G 1332-




Dismantling 5.5.1


- Mount gearbox on assembly stand.
- Drain off gear oil.
- Remove clutch release lever and release bearing ⇒ page 33.
- Remove guide sleeve ⇒ page 33.



- Unbolt gearbox housing cover -arrow-.
- Take off cover. If necessary carefully lever up all round and alternating between sides on the protruding flanges, being careful not to damage sealing surfaces.



- Remove 5th/6th gear selector fork as follows:
- Cover openings in gearbox with a cloth.
- Engage 5th gear (arrows -1- and -2-).
- Remove 5th/6th gear selector jaw (bolt -A-).
- Then remove both bolts -B- for pivot pins.
- Pull out pivot pins.
- Take out 5th/6th gear selector fork.




- Remove bolts -A- for inner bearing races on input and output shafts. To do this, engage 5th gear -arrow 1- and 1st gear -arrows 2 and 3-.
- The input and output shafts are both locked when these two gears are engaged. The two bolts can now be loosened.



Note

If the shafts are not being renewed, clean residual locking compound out of tapped holes using a thread tap.




- Pull off 6th gear wheel and roller bearing inner race for output
- A Two-arm puller -1 Kukko 20/10-
- B Hexagon bolt M10 x 20



Note


- 6th gear wheel and roller bearing inner race can also be pulled out using two-arm puller -T10040- and claw -T10040/2-.
- If necessary, heat gear wheel using hot air blower or accept any liabil V.A.G 1416-before pulling off.




Pull off 6th speed selector gear together with roller bearing inner race for input shaft and thrust washer or pull off together with 5th/ 6th gear synchronising hub with inner race for 6th gear needle bearing and 5th gear synchro-ring.

Use puller -T10309- .

- First insert shell half -T10309/1- between output shaft -A- and mounting for 5th/6th gear selector fork -B-.
- Shell half -T10309/1- must be positioned underneath synchro-
- Turn shell half -T10309/1- to opposite side in direction of -arrow-.
- Introduce thread insert -T10309/3- into shell half.
- Now fit second shell half-T10309/1- and slide tube -T10309/2onto tool.
- Please check synchronising hub for damage after removal.
- Renew synchro-ring for 5th gear.
- Remove 5th speed selector gear with needle bearing.






- Now take off sleeve from 5th gear wheel.
- Pull off 5th gear wheel.



Note


Ensure that the claws -T10040/2- do not bend outwards when pulling off the gear wheel. Check 5th gear wheel for damage after removal.




Remove flange shafts together with springs, thrust washers and tapered rings.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.







Remove both bolts -arrows- for reverse shaft support.




Now remove 3rd bolt -arrow- for reverse shaft support.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liab with respect to the correctness of information in this document. Copyright by AUDI AG.



Remove selector shaft with selector mechanism cover. To do this, set selector shaft in neutral position. Then remove bolts -arrows- and pull selector shaft out of gearbox housing.



- Remove sealing cap -A- from gearbox underside.
- Remove pivot pins -B- from top and underside of gearbox.




Remove bolts -A- securing gearbox housing from inside clutch housing.




Note

Do not remove nuts -B- for output shaft bearing mounting.




Remove pivot pins -A- on top side of gearbox and bolts -Bsecuring gearbox housing to clutch housing (near differential).


> Protected by copyright. Copying for private or comm permitted unless authorised by AUDI AG. AUDI AG with respect to the correctness of information in the is document. Copyright by AUDI AG.




Take off gearbox housing, if necessary carefully lever up all round and alternating between sides on the protruding housing flanges -arrows-, taking care not to damage sealing surfaces.




- Remove selector forks -A- together with selector plates.
- Unscrew bolt for reverse gear selector mechanism -B-.



Remove nuts -B- for output shaft bearing mounting.



- Remove reverse gear -A-, input shaft-B- and output shaft -Cone after the other from clutch housing.
- Take out differential.



5.5.2 **Assembling**


- Insert differential.
- Always renew seals -arrows- for output shaft bearing mount-



Note

The illustration only shows 3 of the 4 seals.


Install reverse gear selector mechanism.




- Insert input shaft -1- and output shaft -2- together.
- Tighten nuts for output shaft bearing mounting to torque ⇒ Item 11 (page 104)
- Place reverse gear wheel -3- on needle bearing in clutch housing.

Shoulder -arrow- faces away from clutch housing ving for private or commercial permitted unless authorised by AUDI AG. AUDI AG does


- Check that reverse shaft -4- is complete page 168 godo not this do fit reverse shaft support onto reverse shaft yet.
- Insert reverse shaft in clutch housing.
- Clean locking fluid residue from all tapped holes in reverse shaft support (residue can be removed using a tap).
- Fit reverse shaft support on reverse shaft.



Fit reverse gear selector fork -1- with support for reverse gear selector fork -2-, spring -3- and slide -4-.




Installation position: reverse gear



- Tighten bolt for reverse gear selector mechanism -A- to torque ⇒ Item 8 (page 104)
 .
- Install selector forks -B- together with selector plates.

Pin -C- on reverse shaft support is located in front of selector plates.




- Screw M8 x 100 mm stud -A- into reverse shaft support so that the shaft is aligned after fitting gearbox housing.
- Align selector plates.



Note

The detent segments must be positioned in the grooves on the locking collars.

- Apply sealant -AMV 188 200 03- evenly to sealing surface of clutch housing.
- Fit and secure gearbox housing.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


Install bolts for reverse shaft support -arrow- as follows:

- Fit bolt -a-.
- Remove stud -A- (⇒ top illustration).

Tightening sequence:

- Fit bolt -c- hand-tight.
- 2 -Tighten bolt -a- to 30 Nm.
- Tighten bolt -c- to 25 Nm.
- Install pivot pins -arrow- for selector forks. To do this align selector mechanism using a screwdriver so that the relevant pivot pin can be inserted.
- Apply sealant -AMV 188 200 03- evenly to sealing surface of cover plate.
- Fit selector shaft cover plate.






Install selector shaft and selector mechanism cover as follows:

- Set selector plates in neutral position.
- Apply sealant -AMV 188 200 03- evenly to sealing surface of cover plate.
- Put selector shaft in neutral position.

Protected by copyright. Cor permitted unless authorise

- Position selector shaft so that selector finger -arrow is rent to the corre gaged in selector plates.
- Tighten selector shaft cover ⇒ Item 15 (page 103).




VW 309 N34-1809

Fit support bridge -30- 211A-.



Note

- Support the input shaft with the thrust piece -32 111- to make it easier to drive on components at a later stage.
- Otherwise there is a risk that the input shaft bearing will be damaged.
- Secure bolt of support bridge -30- 211A- with lock nut -A-.




Installation position of 5th gear wheel


The groove running round the gear wheel -arrow- faces to the gearbox housing.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

Drive on 5th gear wheeles of information in this document. Copyright by AUDI AG.





Checking 5th and 6th gear synchro-rings

Before re-installing selector gears and synchro-rings for 5th and 6th gears, press synchro-rings onto tapered seats of selector gears and measure gap -a- with a feeler gauge.

Gap -a-	Installation depth	Wear limit
5th/6th gear	1.1 1.7 mm	0.5 mm


- Install 5th speed selector gear with needle bearing.
- Fit 5th gear synchro-ring on selector gear.
- If previously dismantled, assemble 5th/6th gear synchronising hub/locking collar before installing ⇒ page 146, ⇒ page 146 and ⇒ page 146
- Also pay attention to modifications on 5th/6th gear locking collar on gearboxes manufactured from 12 06 6 onwards


These modifications are particularly important when adjusting 5th/6th gear at a later stage.

Installation position of 5th/6th gear synchronising hub/locking collar

Collar -arrow 1- faces towards 6th gear.


The synchronising hub mountings -arrow 2- align with the cast locking pieces on the synchro-ring (arrows in the illustration below).





5th and 6th gear synchro-rings with cast locking pieces -arrows-

 Cover all openings with a cloth to prevent dirt etc. from entering the gearbox.




- Knock on 5th/6th gear synchronising hub.



Note

When driving on, ensure clearance for synchro-ring.



 Heat roller bearing inner race for 6th speed selector gear to 100°C (maximum) and drive onto input shaft.




WARNING

Wear protective gloves.

- Fit 6th gear synchro-ring.
- Install 6th speed selector gear with needle bearing.





On gearboxes manufactured up to 20 08 6

Fit thrust washer -A-.



Note


Do not interchange roller bearing inner races of input and output shafts.

 Heat roller bearing inner race -B- to 100°C (maximum) and drive onto input shaft.



WARNING

Wear protective gloves.



On gearboxes manufactured from 21 08 6 onwards


Roller bearing inner race -B- and thrust washer -A- are one component

Heat roller bearing inner race to 100°C (maximum) and drive onto input shaft.




WARNING

Wear protective gloves.




Continued for all vehicles:

Loosen support for input shaft (nut -A-).



Installation position of 6th gear wheel:

- Fit sleeve -A- on 5th gear wheel opyright. Copying for private or commercial purpose
- Groove -B- points towards druft-sleeve or WW 244 nB mation in this document.



"or"


- Groove -arrow 1- in area of shoulder -arrow 2- points towards drift sleeve -VW 244 B- (see previous illustration).
- Heat 6th gear wheel to 100°C (maximum) and press on.



WARNING

Wear protective gloves.

- Set locking collar for 5th/6th gear to neutral position to allow 6th speed selector gear to turn while pressing on 6th gear wheel.
- Drive on 6th gear wheel, making sure that it meshes properly with 6th speed selector gear.



Heat roller bearing inner race -A- to 100°C (maximum) and drive onto output shaft.




WARNING


Wear protective gloves.

Remove residual locking fluid from threaded holes for securing bolts -A- using a thread tap. Otherwise there is a risk that the bolts will shear off.

Note allocation of securing bolts ⇒ page 102 and ⇒ page 102


- Tighten securing bolts for synchronising hub and 5th/6th gear wheels to torque ⇒ page 100 .
- Engage 2 gears -arrows 1 ... 3- before tightening securing bolts -A-.
- Install 5th/6th gear selector fork.





Adjusting 5th/6th gear up to gearbox manufacturing date 11 06 6

- Engage 5th gear.
- Loosen bolt -1-.
- Insert two feeler gauges -A- of 0.5 mm above the two detent segments -arrows- (for 6th gear) into locking collar.
- Press down selector jaw and locking collar -arrows- and tighten bolt -1- to 25 Nm.




Protected by copyright. Copying for priv permitted unless authorised by AUDI A

with respect to the correctness of information in this document. Copyright by AUDI AG.

- The 5th gear is engaged.
- Checking adjustment: it must just be possible to insert one feeler gauge 0.5 mm each between locking collar and the two detent segments -arrow- for 6th gear.
- Repeat adjustment if necessary.
- First engage 5th and then 6th gear.
- There must be slight play between 5th/6th gear selector fork and selector jaw with 5th or 6th gear engaged.
- Disengage gear.
- Locking collar should now be in the neutral position. Synchroring should move freely.
- Select all gears.

Adjusting 5th/6th gear from gearbox manufacturing date 12 06 6

- Engage 5th gear.
- Loosen bolt -1-.
- Press down selector jaw and locking collar -arrows- and tighten bolt -1- to 25 Nm.




Protected by copyright. Copying for private or commercial purposes, in part permitted unless authorised by AUDI AG. AUDI AG does not guarantee or with respect to the correctness of information in this document. Copyrigh

- The 5th gear is engaged.
- Checking adjustment: it must not be possible to insert a feeler gauge 0.2 mm between locking collar and the two detent segments -arrow- for 6th gear.
- Repeat adjustment if necessary.
- First engage 5th and then 6th gear.
- There must be slight play between 5th/6th gear selector fork and selector jaw with 5th or 6th gear engaged.
- Locking collar should now be in the neutral position. Synchroring should move freely.
- Select all gears.


Continued for all vehicles:

- Apply sealant -AMV 188 200 03- evenly to sealing surface of cover for gearbox housing.
- Install gearbox housing cover. ⇒ page 100





- Install both flange shafts with springs, thrust washers and tapered rings.
- Install release bearing guide sleeve ⇒ page 33 .
- Install clutch release lever and release bearing <u>⇒ page 33</u>.
- Fill up with gear oil ⇒ page 95.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Exploded view - gearbox housing and clutch housing 6

1 - Gearbox housing

☐ If renewed: Adjust input shaft and differential ⇒ page 187

2 - Needle bearing

- □ For output shaft
- □ Removing ⇒ page 124
- Installing and securing ⇒ page 125

$\bf 3$ - $\bf Oil$ filler plug rotected by copyright. permitted unless autho

- □ 30 Nm
- Gear oil level cannot be checked by removing oil filler plug
- If gearbox was dismantled, fill with gear oil before installing

Capacity ⇒ page 1

4 - Tapered roller bearing outer

- □ For output shaft
- Removing and installing ⇒ page 157
- ☐ If renewed: Adjust output shaft ⇒ page 165

5 - Shim

- □ For output shaft
- □ Table of adjustments ⇒ page 187

6 - Shim

- □ For input shaft
- ☐ Table of adjustments <u>⇒ page 187</u>

7 - Tapered roller bearing outer race

- □ For input shaft
- □ Removing and installing ⇒ page 142
- ☐ If renewed: Adjust input shaft ⇒ page 147

8 - Tapered roller bearing outer race

- □ For input shaft
- □ Removing and installing ⇒ page 145
- ☐ If renewed: Adjust input shaft ⇒ page 147

9 - Needle bearing


□ Removing and installing ⇒ page 170

10 - Dowel sleeve

□ 2x

11 - Clutch housing

☐ If renewed: table of adjustments ⇒ page 187




12 - 0	Guide sleeve	
	With input shaft oil seal and vulcanised O-ring	
	Knocking out oil seal <u>⇒ page 125</u>	
	Driving in oil seal <u>⇒ page 125</u>	
	Remove guide sleeve in order to renew oil seal	
	Renew guide sleeve if O-ring is damaged	
13 - S	Socket head bolt	
	20 Nm	
	Self-locking	
	Always renew	
14 - C	Dil seal	
	Cannot be renewed separately on this version	
	One-piece oil seal and sleeve <u>⇒ Item 16 (page 122)</u>	
	Sleeve	
	Cannot be renewed separately on this version	
	One-piece oil seal and sleeve <u>⇒ Item 16 (page 122)</u>	
	One-piece oil seal and sleeve	
	If oil seal is damaged, renew both sleeve and oil seal	
	Removing ⇒ page 125	
	Installing <u>⇒ page 126</u>	
	Dil drain plug	
 - -		
	Without magnet	
	Tapered roller bearing outer race	
	For differential	
	Pressing out and pressing in ⇒ page 179 If reproved: Adjust differential a page 189 and a page 189	
	If renewed: Adjust differential ⇒ page 188 and ⇒ page 188	
_	Magnet	
.	Held in place by joint surface of housing ercial purposes, in part or in whole, is repermitted unless authorised by AUDI AG. AUDI AG does not quarantee or accept any liabi	
	permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liabi Collector Properties of Collecto	
	Installing oil collector in gearbox housing ⇒ page 126	
	Fapered roller bearing outer race	
	For differential	
	Pressing out and pressing in <u>⇒ page 179</u>	
	If renewed: Adjust differential <u>⇒ page 188</u> and <u>⇒ page 188</u>	
22 - S	Shim	
	For differential	
	Table of adjustments <u>⇒ page 187</u>	
23 - Oil seal		
	For flange shaft (left-side)	
	Renewing ⇒ page 172	

Servicing gearbox housing and clutch housing 6.1

Special tools and workshop equipment required


- ♦ Drift -VW 295-
- ♦ Adapter -VW 295 A-
- ♦ Thrust pad -VW 447 H-
- Thrust pad -VW 512-
- Tube -VW 415 A-
- Thrust piece -VW 454-



with respect to the correctness of information in this document. Copyright by AUDI AG.


Special tools and workshop equipment required


- Puller -VW 228 B- (not used on this gearbox)
- Drift -VW 222 A- (not used on this gearbox)
- Assembly device -3066-(assembly device spindle)
- Thrust piece -3124-
- -VW 771- Multi-purpose Copyright. Copy with respect to the correc
- -VW 771/37- Puller hook



Special tools and workshop equipment required

Thrust piece -T10148-







Driving out needle bearing

Driving in needle bearing onto stop


Secure needle bearing in gearbox housing at three points (120° offset) with a punch.



Driving oil seal out of guide sleeve




Driving oil seal into guide sleeve (drive in onto stop)



Pulling out sleeve and oil seal

A shoulder is located on inside diameter of sleeve.

- To pull out oil seal and sleeve, apply puller hook -VW 771/37behind shoulder inside sleeve.
- During this operation, press puller hook -VW 771/37- firmly in against sleeve.



Drawing in sleeve and oil seal

- Clean seat for oil seal in gearbox.
- Screw spindle -A- of assembly device -3066- into threaded piece in differential.
- Turn nut -B- and pull sleeve in onto stop with thrust piece -T10148-.





Note

If gearbox has been dismantled, press in sleeve onto stop using thrust piece -T10148-.

Installing oil collector -A- in gearbox housing

Insert oil collector simultaneously into bore -arrow 1- and groove -arrow 2-.







Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Exploded view - gearbox housing cover 7

1 - Roller bearing

- For input shaft
- Do not interchange with roller bearing for output shaft
- □ Pulling out ⇒ page 128
- □ Larger diameter on gearboxes manufactured from 21 08 6 onwards ⇒ page 129
- □ Pressing in on gearboxes manufactured up to 20 08 6: ⇒ page 129
- ☐ Pressing in on gearboxes manufactured from 21 08 6 onwards: ⇒ page 129
- Securing ⇒ page 130

2 - Roller bearing


- ☐ For output shaft
- □ Do not interchange with roller bearing for input shaft
- □ Larger diameter on gearboxes manufactured from 21 08 6 onwards <u>⇒ page 129</u>
- □ Pulling out ⇒ page 129
- ☐ Pressing in on gearboxes manufactured up to 20 08 6: <u>⇒ page 129</u>
- Pressing in on gearboxes manufactured from 21 08 6 onwards:

⇒ page 129 Securing ⇒ page 130 3 - Gearbox housing cover

■ Modified according to roller bearings on gearboxes manufactured from 21 08 6 onwards ⇒ page 129




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



7.1 Servicing gearbox housing cover

Special tools and workshop equipment required


- Thrust plate -VW 401-
- Thrust plate -VW 402-
- Press tool -VW 407-
- Support bridge -2011-
- Internal puller -1 Kukko 21/5-
- Counter-support -4 Kukko 22/1-
- In addition for gearboxes manufactured from 21 08 6 onwards: assembly tool -3348/2-



Pulling roller bearing out of gearbox housing cover


A - Internal puller 30 ... 37 mm, e.g. -Kukko 21/5-

B - Counter-support, e.g. -Kukko 22/1-




Pulling roller bearing out of gearbox housing cover

- A Internal puller 30 ... 37 mm, e.g. -Kukko 21/5-
- B Counter-support, e.g. -Kukko 22/1-



Allocation of roller bearings

Gearbox manufac- turing date	Dimension "a" (mm)	Dimension "b" (mm)
Up to 20 08 6	43	43
From 21 08 6 on- wards	47	47



Pressing roller bearings into gearbox housing cover on gearboxes manufactured up to 20 08 6

- Heat area round bearing seats in gearbox housing cover to approx. 100°C using hot air blower -V.A.G 1416- .
- Insert roller bearing after heating housing and push into position under workshop press until heat exchange has taken place.



Note

Roller bearings must be pressed fully home into cover.

VW 402 VW 407 N34-1799 VW 401


Pressing roller bearings into gearbox housing cover on gearboxes manufactured from 21 08 6 onwards

- Heat area round bearing seats in gearbox housing cover to approx. 100°C using hot air blower -V.A.G 1416- .
- Insert roller bearing after heating housing and push into position under workshop press until heat exchange has taken place.




Note

Roller bearings must be pressed fully home into cover



permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Secure roller bearings in gearbox housing cover by peening -arrows-.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

8 Exploded view - servicing selector unit

1 - Selector shaft with selector mechanism cover

- Dismantling and assembling <u>⇒ page 132</u>
- 2 Reversing light switch -F4-
 - □ 20 Nm
 - Lightly coat lug with MoS₂ grease

3 - Locking pin

- □ For adjusting selector mechanism
- □ Removing ⇒ page 132
- Pressing in ⇒ page 133

4 - Relay lever

- Installation position ⇒ page 64
- □ Removing and installing ⇒ page 65

5 - Oil seal

- □ Lever out using extractor tool -T20143/1-
- ☐ Installing <u>⇒ page 133</u>

6 - Nut

- ☐ Tightening torque ⇒ Item 16 (page 63)
- □ Self-locking
- □ Always renew

7 - Gearbox selector lever. Copy

- ☐ Install so that gap in splines aligns with selector shaft ⇒ page 133
- ☐ Can be renewed with selector mechanism installed
- ☐ Installation position ⇒ page 64


8 - Cap

□ For gearbox breather

9 - Cover plate

10 - Spring


■ Not fitted on all versions




8.1 Dismantling and assembling selector unit


Special tools and workshop equipment required

-T10203- Tube






Extractor tool -T20143/1-



-VW 423- Tube



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


Removing locking pin -A- from selector mechanism cover

- Remove outer part of locking pin.
- Then lever out locking pin carefully using a screwdriver.

Pressing locking pin -A- into selector mechanism cover


Installation position:

Marking -arrow- points to upper section of selector shaft.




Installing oil seal (insert onto stop)

- Lever out using extractor tool -T20143/1-



Installing gearbox selector lever

When installing gearbox selector lever, make sure that the gap in the splines -arrow A- aligns with the wider spline -arrow Bon the selector shaft.



Protected by copyright. Copying for private or commercial purposes, in part permitted unless authorised by AUDI AG. AUDI AG does not guarantee of with respect to the correctness of information in this document. Copyr

9 Exploded view - selector forks



Note

The selector fork cluster (⇒ Item 7 (page 134)) does not have to be dismantled in order to remove and install detent segments, lock washers and angular contact ball bearings.

1 - 5th/6th gear detent segment

- ☐ Identification ⇒ page 136
- Detent segment should turn freely after lock washer is installed

2 - Lock washer

- □ Always renew
- □ Removing ⇒ page 137
- ☐ Installing <u>⇒ page 137</u>

3 - 5th/6th gear selector fork

- □ Adjusting ⇒ page 119
- 4 Bolt
 - □ 25 Nm
- 5 5th/6th gear selector jaw
- 6 Angular contact ball bearing
 - □ 4x
 - □ Removing ⇒ page 137
 - □ Pressing inner race into outer race ⇒ page 137
 - □ Installing ⇒ page 138

7 - Selector fork cluster with selector plates

8 - 1st/2nd gear detent segment

- ☐ Identification⇒ page 136
- ☐ The segment must rotate freely after installing the lock washer.

Protected by copyright. Copying for private or commercial phroses, in part or in whole, is 22 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any stollity with respect to the correctness of information in this document. Copyright by AUDI AG. 11 12 3 11 10 4 10 N34-1702


9 - 3rd/4th gear detent segment

- ☐ Identification ⇒ page 136
- ☐ The segment must rotate freely after installing the lock washer.
- 10 Sliding piece
- 11 Spring
- 12 Reverse gear selector fork
- 13 Support for reverse gear selector fork
- 14 Circlip


Dismantling and assembling selector forks 9.1


Special tools and workshop equipment required

- ♦ Thrust plate -VW 402-
- Assembly tool -3290/1-
- Assembly tool -3301-
- Press tool -VW 431-
- Spacer sleeve -VW 472/2-
- Assembly mandrel -10 206-




Removal lever -80-200-






Assembly mandrel -10 - 508-



Tensioning device -2070-




Identification of detent segments

Distance -a-

- 1 Detent segments, 1st/ 2nd gear = 11.4 mm
- 2 Detent segments, 3rd/4th gear = 7.7 mm
- 3 5th/6th gear detent segments = 12.1 mm

- Secure selector fork in vice with soft jaws -B-.
- Lever off lock washer -A- in direction of arrow.



Installing lock washer

Push lock washer into groove in detent segment using socket driver.



Note

Detent segment should turn freely after lock washer is installed.

-A-- Socket driver, P10 mmy copyright. Copying for private or commercial purposes, in part or

nless authorised by AUDI AG. AUDI AG does not guarantee or acc -B-- Protective jaw covers et to the correctness of information in this document. Copyright b




Removing angular contact ball bearing




Note

Do not bend selector forks when removing and installing the ball bearing.




Pressing inner race -A- of angular contact ball bearing into outer race

Inner race must engage positively in outer race.



Pulling angular contact ball bearing into selector fork (insert onto stop)


Recess in thrust piece -3290/1- points towards ball bearing.



Selector forks with detent segments installed

	Dimension -a- (mm)
1st/2nd gear selector fork	87.2 87.4
3rd/4th gear selector fork	93.6 93.8

For identification of detent segments <u>⇒ page 136</u>





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

25

23

22

21

20

19

18

17

16

15

14

13

12

N35-10153

35 – Gears, shafts

Exploded view - input shaft

1 - Clutch housing

2 - Tapered roller bearing outer race

- Pressing out
 - ⇒ page 142
- Pressing in ⇒ page 143
- 3 Tapered roller bearing inner
- Pressing off
 - <u>⇒ page 143</u>
 - Pressing on ⇒ page 143
- 4 Input shaft
 - Adjusting ⇒ page 147
- 5 3rd gear wheel
 - ☐ Installation position: Collar faces 4th gear
 - Pressing off ⇒ page 144
 - Pressing on ⇒ page 144
- 6 Circlip
 - Always renew

7 - 4th gear wheel

- Pressing off with tapered roller bearing outer race and sleeve ⇒ page 143
- Pressing on ⇒ page 144
- ☐ Installation position:

Collar faces 3rd gear 8 - Tapered roller bearing inner race

3

- □ Pressing off with 4th gear wheel and sleeve ⇒ page 143
- □ Pressing on ⇒ page 144

9 - Thrust washer

10 - Tapered roller bearing outer race

- □ Pressing out ⇒ page 145
- □ Pressing in ⇒ page 145

11 - Shim

- □ Determining thickness ⇒ page 147
- 12 Gearbox housing

13 - Sleeve

- ☐ For needle bearing
- ☐ Press off with 4th gear wheel and tapered roller bearing inner race ⇒ page 143

	Needle bearing
	5th speed selector gear
_	5th gear synchro-ring
17 -	Locking collar with synchronising hub for 5th and 6th gear
u	Protected by copyright, Copyright or private or commercial purposes, in part or in whole, is not
<u> </u>	with reapost to the correctness of information in this desument. Convigint by ALIDLAC
	6th gear synchro-ring
19 -	6th speed selector gear
	Modified according to sleeve and needle bearing on gearboxes manufactured from 21 08 6 onwards
	Select correct components from ⇒ Electronic parts catalogue
20 -	Needle bearing
	For 6th gear
	1 1 1 0 0 0 1 1 1 1 1 1 1 1 1 1 1 1 1 1
_ _	
_	Sleeve
_ _	
	Select correct components from ⇒ Electronic parts catalogue
	Thrust washer
	On gearboxes manufactured up to 20 08 6
	Roller bearing inner race
	For input shaft
24 -	Roller bearing inner race with thrust washer
	Allocation ⇒ page 102
	For input shaft
	On gearboxes manufactured from 21 08 6 onwards
25 -	Bolt
	0 0 1 =
	'
	3
	Always renew




Use thread tap to remove any remaining locking fluid from threaded holes for bolts securing 5th/6th gear synchronising hub and 6th gear wheel. Otherwise there is a risk that the bolts will shear off


Dismantling and assembling input shaft 1.1

Special tools and workshop equipment required

- ♦ Press tool -VW 407-
- Thrust plate -VW 447 H-
- Press tool -VW 412-
- Tube -VW 422-
- Thrust plate -VW 401-
- Thrust plate -VW 402-
- Press tool -VW 408 A-



- Drift sleeve -41 501-
- Thrust plate -VW 447 i-
- Drift sleeve -30 100-
- Thrust pad -VW 510-
- Splitter -3 Kukko 17/1-







Note

- Refer to ⇒ Electronics parts catalogue and technical data ⇒ page 1 when installing new gears.
- The input shaft must be re-adjusted if the position of tapered roller bearings is affected when renewing parts. Refer to table of adjustments <u>⇒ page 187</u>

Pressing out tapered roller bearing outer race




Pressing in tapered roller bearing outer race



Pressing off tapered roller bearing inner race


A - Splitter -Kukko 17/1-




Pressing on tapered roller bearing inner race




Protected by copyright. Copying for private or commercial purposes, in part or in wh permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept a with respect to the correctness of information in this document. Copyright by AU




Pressing off 4th gear wheel with tapered roller bearing and sleeve



Pressing off 3rd gear wheel




Pressing on 3rd gear wheel




Pressing on 4th gear wheel


Shoulder faces towards 3rd gear.




Pressing on tapered roller bearing inner race



Pressing on sleeve for needle bearing




Pressing out tapered roller bearing outer race




Pressing in tapered roller bearing outer race

Install with shim after adjusting input shaft.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability




Dimension -a- (side of 6th gear)	On gearboxes man- ufactured up to 11 06 6	On gearboxes manu- factured from 12 06 6 onwards
	1.5 mm	1.8 mm
Dimonsion h	On goorboyee man	On geerhoves manu

Dimension -b- (side of 5th gear)	On gearboxes man- ufactured up to 11 06 6	On gearboxes manu- factured from 12 06 6 onwards
	1.5 mm	2.0 mm

Refer to ⇒ Electronic parts catalogue to allocate locking collars and 5th/6th gear synchronising hub.

Modified adjustment procedure on 5th/6th gears due to the deeper recesses:


- Adjusting 5th/6th gear on gearboxes manufactured up to $11\,06\,6 \Rightarrow page\,118$
- Adjusting 5th/6th gear on gearboxes manufactured from 12 06 6 onwards <u>⇒ page 119</u>



Dismantling and assembling 5th/6th gear locking collar and synchronising hub

- Spring
- 2 -Locking piece
- Synchronising hub
- Locking collar
- Push locking collar over synchronising hub.


The deeper recesses -arrow A- for the locking pieces in the synchronising hub must align with the recesses -arrow B- in the locking collar.



Assembling 5th/6th gear locking collar/synchronising hub

- Locking collar is pushed over synchronising hub.
- Insert locking pieces in the deeper recesses -arrows- and install springs 120° off-set. Angled end of spring must locate in hollow locking piece.


Protected by copyright. Copying for private permitted unless authorised by AUDI AG. with respect to the correctness of inform



Springs with ends -A- angled upwards are fitted on some gearbox versions.

The modified springs are fitted on both sides.

- On gearboxes of the earlier type, the modified springs can only be installed in combination with hollow locking pieces.
- Fit locking pieces.




Installation position of springs:

- Insert springs offset by 120°.
- Angled end -A- of spring must locate in hollow locking piece.

Spring must be fitted under lug -B- of locking pieces.

The offset end must always point away from synchronising hub (in direction of -arrow-).




2 Adjusting input shaft

(Determining thickness of shim for input shaft)

Special tools and workshop equipment required

- Universal dial gauge bracket -VW 387-
- End measuring plate -VW 385/17-
- ♦ Thrust pad -VW 510-
- Thrust plate -VW 447 i-
- Press tool -VW 407-
- Torque wrench -V.A.G 1331-
- Dial gauge



Procedure

The input shaft must be re-adjusted when the following components are renewed:

- Gearbox housing
- Clutch housing
- ♦ Input shaft
- ♦ 4th gear wheel

◆ Tapered roller bearings

Table of adjustments <u>⇒ page 187</u>


Requirement:

Sealing surfaces of clutch and gearbox housings must be free of sealant.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Press tapered roller bearing outer race without shim onto stop in clutch housing.



- Press tapered roller bearing outer race without shim onto stop in gearbox housing.
- Install input shaft in clutch housing and put on gearbox housing. Tighten hexagon bolts to 25 Nm, then turn 90° further.




- Fit measuring appliance and dial gauge in clutch housing (large tapered roller bearing in gearbox housing).
- Before measurement, rotate input shaft to allow tapered roller bearings to settle. Set dial gauge to "0" with 1 mm preload.



Note

This procedure must be repeated for each subsequent measurement, as otherwise the dial gauge will not return to its original setting.

> Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Push input shaft towards dial gauge in direction of -arrow-.
- Read off and note play indicated on dial gauge (in this example: 1.21 mm).



Note

Dial gauge does not return to original setting by itself.


- Select shim of required thickness according to table ⇒ page 149 (in this example: 1.175 mm).
- Remove input shaft and press tapered roller bearing outer race out of gearbox housing using VW 447i.
- Press tapered roller bearing outer race together with the 1.175 mm shim into gearbox housing using -VW 510- .
- Assemble gearbox housing and tighten hexagon bolts to 25 Nm and then turn 90° further.

Table of shims



Note

Select correct shims from ⇒ Electronic parts catalogue. permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Bearing clearance	Shim	
Measured value (mm)	Thickness (mm)	
0.6710.699 0.7000.724 0.7250.749	0.650 0.675 0.700	
0.7500.774 0.7750.799 0.8000.824	0.725 0.750 0.775	
0.8250.849 0.8500.874 0.8750.899	0.800 0.825 0.850	
0.9000.924 0.9250.949 0.9500.974	0.875 0.900 0.925	
0.9750.999 1.0001.024 1.0251.049	0.950 0.975 1.000	
1.0501.074 1.0751.099 1.1001.124	1.025 1.050 1.075	AUOI
1.1251.149 1.1501.174 1.1751.199	1.100 1.125 rotected by co 1.150 with respect	byright. Copying for private or commercial purposes, in part or in whole, is not s authorised by AUDI AG. AUDI AG does not guarantee or accept any liability to the correctness of information in this document. Copyright by AUDI AG.
1.2001.224 1.2251.249 1.2501.274	1.175 1.200 1.225	
1.2751.229 1.3001.324 1.3251.349	1.250 1.275 1.300	
1.3501.374 1.3751.399 1.4001.424	1.325 1.350 1.375	
1.4251.449 1.4501.474 1.4751.499	1.400 1.425 1.450	
15001.524 1.5251.549 1.5501.574	1.475 1.500 1.525	
1.5751.599 1.6001.624 1.6251.649	1.550 1.575 1.600	
1.6501.674 1.6751.699 1.7001.724	1.625 1.650 1.675	


Checking adjustment

- Install measuring appliance and dial gauge.
- Rotate input shaft to allow tapered roller bearings to settle.
- Press input shaft in direction of -arrow-.
- Bearing clearance should be min. 0.01 ... max. 0.09 mm.



Note

If the bearing clearance cannot be measured, but input shaft play is perceptible and the input shaft turns freely, the adjustment is acceptable.



3 Exploded view - output shaft



Note

- The output shaft is dismantled as follows:- Position splitter under 2nd speed selector gear (⇒ Item 21 (page 152)) and press off as described in ⇒ page 158 . Remove circlip ⇒ Item 17 (page 152) . Then press off locking collar and synchronising hub for 1st and 2nd gear as shown in *⇒ page 158* .
- Refer to ⇒ Electronics parts catalogue and technical data ⇒ page 1 when installing new gears or a new output shaft.
- Always renew both tapered roller bearings together.

1 - Nut

- □ 25 Nm + 90°
- 4 nuts for bearing mounting
- Always renew

2 - Clutch housing

3 - Shim

- ☐ For output shaft
- Table of adjustments ⇒ page 187

4 - Small tapered roller bearing outer race

- Removing ⇒ page 157 P
- □ Pressing in ⇒ page 157

5 - Small tapered roller bearing inner race

- □ Pulling off ⇒ page 157
- Pressing on ⇒ page 158

6 - Output shaft

Adjusting ⇒ page 165

7 - Large tapered roller bearing inner race

- □ Pulling off ⇒ page 158
- Pressing on ⇒ page 159

8 - Seal


☐ Place seals (4x) on bolts for bearing mounting

9 - Bearing mounting

- ☐ With large tapered roller bearing outer race and bolts
- Only renew outer race together with large tapered roller bearing and bearing mounting

10 - Thrust washer

☐ Shoulder on thrust washer faces towards tapered roller bearing



11 - 1st speed selector gear

12 - Needle bearing

□ For 1st gear

13 - Synchro-ring

- ☐ (Inner ring for 1st gear)
- ☐ Installation position ⇒ page 159
- □ Checking for wear ⇒ page 159
- □ Check lugs for scoring

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

14 - Outer ring for 1st gear

- □ Installation position ⇒ page 159
- ☐ Checking for wear ⇒ page 159
- Renew if scored or if there are visible traces of wear

15 - 1st gear synchro-ring

- ☐ Installation position ⇒ page 159
- □ Checking for wear ⇒ page 159

16 - Locking collar with synchronising hub for 1st and 2nd gear

- □ Press off together with bearing mounting ⇒ Item 17 (page 152) after removing circlip ⇒ page 158
- □ Dismantling ⇒ page 160
- ☐ Assembling locking collar/synchronising hub <u>⇒ page 160</u>, <u>⇒ page 160</u> and <u>⇒ page 160</u>
- ☐ Installation position ⇒ page 161
- □ Pressing on ⇒ page 161

17 - Circlip

18 - 2nd gear synchro-ring

- ☐ Checking for wear ⇒ page 159
- Assemble so that the recesses engage on the locking pieces on the locking collar ⇒ Item 16 (page 152)

19 - Outer ring for 2nd gear

- ☐ Insert in synchro-ring ⇒ Item 18 (page 152)
- ☐ Installation position ⇒ page 161
- Renew if scored or if there are visible traces of wear

20 - Synchro-ring

- ☐ (Inner ring for 2nd gear)
- □ Checking for wear ⇒ page 159
- □ Check lugs for scoring
- ☐ Installation position ⇒ page 161

21 - 2nd speed selector gear

□ Installation position ⇒ page 162

22 - Needle bearing

For 2nd gear

23 - Thrust washer

24 - Sleeve for 3rd gear needle bearing

- □ Pressing off with 2nd speed selector gear ⇒ page 158
- □ Pressing on ⇒ page 162

25 - Needle bearing

☐ For 3rd gear

26 - 3rd speed selector gear


27 - 3r	rd gear synchro-ring
	Checking for wear <u>⇒ page 162</u>
28 - Lo	ocking collar with synchronising hub for 3rd and 4th gear
	Pressing off with 2nd speed selector gear ⇒ Item 21 (page 152) and 3rd speed selector gear ⇒ Item 26 (page 152) ⇒ page 158 Dismantling ⇒ page 162
	Assembling locking collar/synchronising hub <u>⇒ page 162</u> , <u>⇒ page 163</u> and <u>⇒ page 163</u>
	Installation position: Locking collar/synchronising hub <u>⇒ page 163</u>
	Pressing on ⇒ page 163
29 - SI	leeve
	For needle bearing
	Pressing off with locking collar and synchronising hub for 3rd and 4th gear ⇒ Item 28 (page 153) ⇒ page 158
	Pressing on ⇒ page 164
	eedle bearing
	For 4th gear
	th gear synchro-ring
	Checking for wear <u>⇒ page 162</u>
	th speed selector gear
33 - TI	hrust washer
	eedle bearing
	For output shaft
	Removing and installing <u>⇒ page 124</u>
	earbox housing
36 - SI	
	For needle bearing/output shaft
	Pressing off ⇒ page 158 Pressing off ⇒ page 164
	Pressing on ⇒ page 164
	th gear wheel
	Removing and installing ⇒ page 104 Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not
38 - SI	permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.
	th gear wheel
	Removing and installing <u>⇒ page 104</u>
	oller bearing inner race
	For output shaft
	Larger outer diameter on gearboxes manufactured from 21 08 6 onwards
	Allocation ⇒ page 102 Mark before removing
	Do not interchange with roller bearing inner race for input shaft
— 41 - В	·
	Oit Tightening torque <u>⇒ Item 6 (page 100)</u>
	Allocation of bolts ⇒ page 102
	For output shaft
	Self-locking
	Always renew




3.1 Dismantling and assembling output shaft

Special tools and workshop equipment required

- Press tool -VW 407-
- Press tool -VW 412-
- Thrust pad -VW 512-
- Puller -V.A.G 1582-
- Adapter -V.A.G 1582/4-
- Adapter -V.A.G 1582/5-




- ♦ Thrust plate -VW 402-
- Thrust piece -32 111-
- Press tool -VW 409-
- Support rails -VW 457-
- Tube -VW 519-





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


- Drift sleeve -30 100-
- Tube -VW 415 A-
- Thrust plate -VW 447 H-
- Press tool -VW 454-
- Tube -2040-
- Drift sleeve -41 501-






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Internal puller -1-Kukko 21/8-






- Counter-support -4-Kukko 22/2-
- ♦ Splitter -3- Kukko 17/2-

Pulling out small tapered roller bearing outer race

A - Internal puller 37 ... 46 mm, e.g. -Kukko 21/8-


B - Counter-support, e.g. -Kukko 22/2-

Pressing in small tapered roller bearing outer race




Pulling off small tapered roller bearing inner race

- A Soft jaws/vice
- Fit adapter and apply tension to it behind the bearing rollers, then turn bearing and re-tension adapter.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Pressing on small tapered roller bearing inner race



VW 412

VW457

A35-10100

liability

AG

Pressing off 3rd and 4th gear synchronising hub/locking collar; 2nd, 3rd and 4th speed selector gears with needle bearing sleeve for output shaft

- A Splitter 22...115 mm, e.g. -Kukko 17/2-
- B Hexagon bolt, 17 mm M10 x 20




Note

Protected by copyright. permitted unless author with respect to the co VW457

Support splitter so that the 1st and 2nd gear locking collar is not pulled off at the same time.


Pressing off locking collar with synchronising hub and bearing mounting

- First remove circlip -arrow-.




Pulling off large tapered roller bearing inner race

- A Soft jaws
- Before applying puller insert a M10 x 20 hexagon bolt in output shaft hole.



Pressing on large tapered roller bearing inner race

- -A- Thrust washer
- Fit thrust washer before pressing on inner race. Shoulder faces towards inner race.



Installation position of inner ring, outer ring and synchro-ring for 1st gear

Place inner ring -A- on 1st speed selector gear.

The angled tabs -arrow 1- point towards the outer ring -B-.

Fit outer ring -B-.

The tabs -arrow 2- lock in the recesses -arrow 3- of the selector gear.


Fit synchro-ring -C-.

The recesses -arrow 4- locate on the tabs -arrow 1- of the inner ring -A-.




Note

If components are not being renewed, make sure they are reinstalled on the same gear.



Press inner ring onto tapered seat on selector gear and measure gap -a- using a feeler gauge.

Gap -a-	Installation depth	Wear limit
1st and 2nd gear	0.75 1.25 mm	0.3 mm




Protected by copyright. Copying for priva or commercia irposes, in part or in whole, is not AUDI AG does not guarantee or accept any liability permitted unless authorised by AUDI AG with respect to the correctness of information in this

Checking 1st and 2nd gear synchro-ring for wear

Press synchro-ring, outer ring and inner ring onto tapered seat on selector gear and measure gap -a- using a feeler gauge.

Gap -a-	Installation depth	Wear limit
1st and 2nd gear	1.2 1.8 mm	0.5 mm



Dismantling and assembling 1st and 2nd gear locking collar and synchronising hub

1 - Spring

Select correct spring from ⇒ Electronic parts catalogue.

Assembling version used together with hollow locking pieces (with internal recess) ⇒ page 160

Assembling version used together with solid locking pieces (no internal recess) <u>⇒ page 160</u>

- 2 Locking collar
- 3 Synchronising hub
- 4 Locking piece

Select locking pieces from ⇒ Electronic parts catalogue.

Shoulders on synchronising hub are of equal width on both sides.


The shoulder on one side is chamfered -arrow B-.


When assembled, the chamfer on the shoulder of the synchronising hub and the external teeth on the locking collar -arrow Aface in the same direction.

The recesses for the locking pieces on synchronising hub and locking collar -arrow C- must align.

Assembling locking collar/synchronising hub for 1st and 2nd gear (version with hollow locking pieces)

- · Locking collar is pushed over synchronising hub.
- Insert locking pieces and install springs offset at 120°. Angled end of spring must locate in hollow locking piece.







Assembling locking collar/synchronising hub for 1st and 2nd gear (version with solid locking pieces: no internal recess)

- Locking collar is pushed over synchronising hub.
- Insert locking pieces and install springs offset at 120°. Angled ends of spring must be in front of locking pieces -arrows-.

Protected by copyright. Copyir permitted unless authorised b with respect to the correctn




Splines on locking collar -arrow- point to splines for 3rd/4th gear synchronising hub -A-.




Pressing on 1st and 2nd gear locking collar/synchronising hub

Turn synchro-ring so that grooves align with locking pieces.




Installation position of outer ring for 2nd gear

The lugs -arrows- face towards 1st gear -A-.




Installation position of synchro-ring (inner ring for 2nd gear) -A-

The lugs -arrow 1- locate in the recesses -arrow 2- in the synchroring -B-.




with respect to the correctness of information in this document. Copyright by AUDI AG.




Installation position of 2nd speed selector gear

The higher shoulder -A- faces towards 1st gear -B-. The recesses in the shoulder -arrows- engage on the lugs on the outer ring ⇒ page 161




Pressing on sleeve for 3rd gear needle bearing



Checking 3rd and 4th gear synchro-ring for wear

 Press synchro-ring onto tapered seat on selector gear and measure gap -a- with a feeler gauge.

Gap -a-	Installation depth	Wear limit
1st gear 3rd gear 4th gear	1.01.7 mm 1.01.7 mm 1.01.7 mm	0.5 mm



Dismantling and assembling 3rd and 4th gear locking collar and synchronising hub

1 - Spring

Select correct spring from ⇒ Electronic parts catalogue.

Assembling version used together with hollow locking pieces (with internal recess) ⇒ page 163

Assembling version used together with solid locking pieces, (no copying for internal recess) ⇒ page 163


permitted unless authorised by A with respect to the correctness

2 - Locking piece

Select locking pieces from ⇒ Electronic parts catalogue.

- 3 Locking collar
- 4 Synchronising hub
- Push locking collar over synchronising hub.


Recesses for locking pieces in synchronising hub and locking collar must align.



Assembling locking collar/synchronising hub for 3rd and 4th gear (version with hollow locking pieces)


Locking collar is pushed over synchronising hub.

Insert locking pieces and install springs offset at 120°. Angled end of spring must locate in hollow locking piece.




Assembling locking collar/synchronising hub for 3rd and 4th gear (version with solid locking pieces: no internal recess)

- Locking collar is pushed over synchronising hub.
- Insert locking pieces and install springs offset at 120°. Angled ends of spring must be in front of locking pieces -arrows-.



Installation position of 3rd and 4th gear locking collar/synchronising hub


Chamfer -arrow- faces towards 4th gear.




Pressing on 3rd and 4th gear synchronising hub with locking col-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Pressing on sleeve for 4th gear needle bearing



Pressing on sleeve for needle bearing/output shaft




Adjusting output shaft 4

(Determining thickness of output shaft shim)

Special tools and workshop equipment required


- Universal dial gauge bracket -VW 387-
- End measuring plate -VW 385/17-
- ♦ Thrust pad -VW 512-
- ♦ Straightening tool -3114/2-
- Press tool -VW 407-
- Torque wrench -V.A.G 1331-
- ◆ Dial gauge



Internal puller -1- Kukko 21/8-




Protected by copyright. Copying for private or commercial purposes, in part o permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG. with respect to the correctness of information in this document. Copyright



- ♦ Counter-support -4- Kukko 22/2-
- Puller -2- Kukko 18/0- (threaded spindle)

Adapter -VW 771/15-



Procedure

The output shaft must be re-adjusted when the following components are renewed:

- Output shaft
- Clutch housing

or

Tapered roller bearings

Table of adjustments ⇒ page 187

Requirement:

- Sealing surfaces of clutch and gearbox housings must be free of sealant.
- Press small tapered roller bearing outer race together with a 0.65 mm thick shim fully into clutch housing \Rightarrow page 157.
- Insert output shaft and tighten bearing mounting nuts to 25 Nm and then turn 90° further.

- Mount dial gauge (3 mm measuring range) and set to "0" with 1 mm preload.
- -A- = (threaded spindle) from puller --Kukko 18/0- .
- Move output shaft up and down; read off and note play indicated on dial gauge (in this example 0.30 mm).


Determining thickness of shim

The specified bearing preload is obtained by adding a constant preload figure (0.14 mm) to the measured value obtained (0.36 mm) and the thickness of the shim installed (0.65 mm).

Example:

Shim installed	0.65 mm
+ Measured value	0.36 mm
+ Preload (constant value)	0.14 mm
Thickness of shim	1.15 mm

Remove output shaft and pull out small tapered roller bearing outer race ⇒ page 157





Note

- Select correct shims from ⇒ Electronic parts catalogue .
- If the size of the shim required is larger than those listed in ⇒ Electronic parts catalogue install two shims amounting to the correct value.
- Tolerance variations make it possible to obtain the exact shim thickness required.
- Press in tapered roller bearing outer race together with the correct shim (in example 1.15 mm) ⇒ page 157 and install output shaft.
- Tighten bearing mounting nuts in clutch housing to 25 Nm and then turn 90° further.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

5 Exploded view - reverse shaft



After removal, always renew needle bearings in clutch housing and in reverse shaft support.

1 - Clutch housing

2 - Needle bearing

- □ Pulling out ⇒ page 170
- Pressing in ⇒ page 170

3 - Reverse gear wheel

4 - Circlip

- ☐ Always renew after removing
- ☐ Fit new circlip carefully
- Do not overstretch

5 - Reverse selector gear

- □ Remove circlip before renewing
- □ Shoulder faces towards reverse gear wheel

6 - Reverse shaft


□ Removing ⇒ page 104

7 - Needle bearing

- Pressing out
 - ⇒ page 170
- Pressing in ⇒ page 171

8 - Reverse shaft support


□ Removing and installing ⇒ page 104




5.1 Dismantling and assembling reverse shaft


Special tools and workshop equipment required


- ♦ Press tool -VW 454-
- Thrust plate -VW 447 H-
- Press tool -VW 411-
- ◆ Centring mandrel -12 551-
- Thrust plate -VW 401-
- Press tool -VW 408 A-





Internal puller -1-Kukko 21/2-





 Counter-support -4-Kukko 22/1-

Pulling needle bearing out of clutch housing

A - Counter-support, e.g. -Kukko 22/1-


B - Internal puller 14.5 ... 18.5 mm , e.g. -Kukko 21/2-



Note


The needle bearing is destroyed during removal and must be renewed.

Pressing needle bearing -A- into clutch housing



Pressing needle bearing out of reverse shaft support


Protected by copyright. Copying for private o permitted unless authorised by AUDI AG. Al with respect to the correctness of informa



Pressing needle bearing into reverse shaft support



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





Final drive - differential 39 –


Renewing flange shaft oil seals with gearbox installed

- ⇒ "1.1 Renewing flange shaft oil seal (left-side)", page 172
- ⇒ "1.2 Renewing flange shaft oil seal and sleeve (right-side; one-piece oil seal and sleeve)", page 175

1.1 Renewing flange shaft oil seal (left-side)

Special tools and workshop equipment required


- Multi-purpose tool -VW 771-
- Puller hook -VW 771/37-
- Thrust piece -T10160-
- Used oil collection and extraction unit -V.A.G 1782-
- Torque wrench -V.A.G 1331-
- Sealing grease -G 052 128 A1-



Removing


Gearbox in vehicle

- Remove noise insulation (centre) -1- ⇒ Rep. Gr. 66.
- Remove left wheel.




- Remove front left wheel.
- Remove left noise insulation -arrows-.
- Unbolt drive shaft from flange shaft ⇒ Rep. Gr. 40.
- Lift drive shaft clear and tie in place. Do not damage surface coating.
- Place container under the gearbox.









Pull out flange shaft oil seal using multi-purpose tool -VW 771and puller hook -VW 771/37-.









Installing

- Lightly oil outer circumference of new oil seal.
- Pack space between sealing lip and dust lip -arrow- half full with sealing grease -G 052 128 A1- .






- Drive in new seal onto stop (take care to keep seal straight) at or in w
- Install flange shaft: spect to the correctness of information in this document. Copyright by AU
- Press flange shaft in against spring on gearbox housing and secure with countersunk bolt. Tightening torque ⇒ Item 12 (page 180) .
- Bolt drive shaft to flange shaft ⇒ Rep. Gr. 40.
- Check oil level in gearbox and top up with gear oil if necessary <u>⇒ page 95</u> .



T10160

- Install wheel housing liner (front left) -arrows-.
- Install noise insulation (centre) ⇒ Rep. Gr. 66.
- Fit wheel.






1.2 Renewing flange shaft oil seal and sleeve (right-side; one-piece oil seal and sleeve)


Special tools and workshop equipment required

- ♦ Thrust piece -T10148-
- Spindle from assembly device -3066-
- Multi-purpose tool -VW 771-
- ◆ Puller hook -VW 771/37-
- ◆ Torque wrench -V.A.G 1331-




Special tools and workshop equipment required

♦ Lifting aid -2024 A/1-






Used oil collection and extraction unit -V.A.G 1782-




Removing

- Gearbox in vehicle
- Remove noise insulation (centre) -1- \Rightarrow Rep. Gr. 66.
- Remove right wheel.




- Unbolt heat shield for right-side drive shaft -arrows-.
- Turn steering to full right lock.





- Unbolt drive shaft -1- from flange shaft ⇒ Rep. Gr. 40.
- Lift drive shaft as far as possible and tie in place. Do not damage surface coating.






Note

Before removing the swivel joint, mark the installation position ⇒ Rep. Gr. 40; Removing and installing swivel joint.

Remove nuts -arrows- on swivel joint (right-side).




- Disengage wishbone (right-side) at swivel joint.
- Swivel suspension strut (right-side) outwards and support with Protected by co2024 Appling as shown in illustrations, in part or in whole, is not

permitte


with


ctness of information in this document. Copyright by AUDI AG WARNING

Secure locking pin and swivel joint with retaining clip -arrowand nut -1-.



- Remove flange shaft securing bolt -arrow-. To do so, screw two bolts into flange and counterhold flange shaft with suitable lever.
- Pull out flange shaft together with spring, thrust washer and tapered ring.






Pull out oil seal with sleeve.

A projection is located on inside diameter of sleeve.

- Position puller hook -VW 771/37- directly behind projection in
- During this operation, press puller hook -VW 771/37- firmly in against sleeve.




Installing

- Clean seat for oil seal in gearbox.
- Pull in oil seal together with sleeve.

A - Spindle from assembly device -3066- screwed into threaded piece in differential.

B - M12 nut


- Turn nut -B- and pull oil seal with sleeve in onto stop with thrust piece -T10148- .
- Pack space between sealing lip and dust lip half-full with sealing grease -G 052 128 A1- .



- Install flange shaft.
- Press flange shaft in against spring on gearbox housing and secure with countersunk bolt -arrow-. Tightening, torque. Copying for pr permitted unless authorised by AUDI ⇒ Item 12 (page 180) . with respect to the correctness of in
- Attach swivel joint to wishbone and secure ⇒ Rep. Gr. 40; Removing and installing swivel joint.
- Bolt drive shaft to flange shaft ⇒ Rep. Gr. 40.
- Install heat shield for right-side drive shaft.
- Check oil level in gearbox and top up with gear oil if necessary ⇒ page 95 .
- Install noise insulation (centre) ⇒ Rep. Gr. 66.



Component	Nm
Heat shield for drive shaft to cylinder block	25



N32-0001

2 **Exploded view - differential**



Note

- Heat tapered roller bearing inner race to 100° C before instal-
- Always renew both tapered roller bearings together.
- Adjust differential ⇒ page 188 if tapered roller bearings, differential cage, gearbox housing or clutch housing are being renewed.

1 - Gearbox housing

2 - Shim

- For differential
- Determining thickness ⇒ page 188

3 - Tapered roller bearing outer race

- □ Pulling out ⇒ page 183
- Pressing in ⇒ page 184

4 - Tapered roller bearing inner race

- □ Pulling off ⇒ page 183
- Pressing on ⇒ page 183

5 - Differential cage

- □ With final drive gear
- Differential cage is matched to one-piece thrust washer ⇒ page 185
- ☐ For correct version, refer to ⇒ Electronic parts catalogue

6 - Tapered roller bearing inner race

- □ Pulling off ⇒ page 183
- Pressing on ⇒ page 183

7 - Tapered roller bearing outer race

- Pressing out ⇒ page 182
- □ Pressing in ⇒ page 183


8 - Clutch housing

9 - Sleeve

- ☐ Cannot be renewed separately on this version
- One-piece oil seal and sleeve ⇒ Item 11 (page 180)

10 - Oil seal

☐ Cannot be renewed separately on this version




	One-piece oil seal and sleeve <u>⇒ Item 11 (page 180)</u>
11 - C	One-piece oil seal and sleeve
	If oil seal is damaged, renew sleeve and oil seal together ⇒ page 175
12 - C	Countersunk bolt
	25 Nm
	Screws into threaded piece ⇒ Item 20 (page 180)
	lange shaft
	Removing and installing ⇒ page 172
	Spring for flange shaft
	Installed behind flange shafts
	hrust washer
	Installation position ⇒ page 186
	apered ring
	With grooves to engage on thrust washer
	Installation position: Taper towards differential cage
17 - C	·
	Holds tapered ring, thrust washer and spring in position when flange shaft is removed
	One-piece thrust washer
	Lubricate with gear oil before installing
	One-piece thrust washer has a projection on some versions <u>⇒ page 185</u>
	Sun wheel
	Installing <u>⇒ page 185</u>
	Threaded piece
	Installing ⇒ page 185
_	Differential pinion pin
	Drive out with drift
	Installing ⇒ page 185
	Spring pin For securing differential pinion pin
	Spring pins of two different lengths are fitted
	Identification of different types of spring pin ⇒ page 184
	Short spring pin: removing and installing ⇒ page 184
	Long spring pin: is sheared off on removal <u>⇒ page 185</u>
	Long spring pin: installing <u>⇒ page 185</u>
23 - F	Planet pinion
	Installing ⇒ page 185
24 - S	Sun wheel
	Installing ⇒ page 185

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


Dismantling and assembling differential 2.1

Special tools and workshop equipment required


- ◆ Tapered roller bearing pull-er -V.A.G 1582-
- ♦ Adapter -V.A.G 1582/3-
- Press tool -VW 412-
- Thrust plate -VW 401-
- Thrust plate -VW 402-




- Press tool -VW 408 A-
- Press tool -VW 473-
- Thrust plate -30 205-
- Sleeve -3144-
- Press tool -2007-
- Torque wrench -V.A.G 1332-



Internal puller -1-Kukko 2[']1/7-





Counter-support -4-Kukko 22/2-

Pressing tapered roller bearing outer race out of clutch housing


First remove mounting sleeve for flange shaft oil seal.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Pressing tapered roller bearing outer race into clutch housing

No shim is installed on the clutch housing side.




Pulling off tapered roller bearing inner races

Before setting up the puller, place thrust plate -40 - 105- on differential cage.



Note

The procedure for pulling tapered roller bearing inner races off differential cage is the same for both bearings.




Pressing on tapered roller bearing inner races




Note

The same special tools are used for pressing on tapered roller bearing inner races for gearbox housing and clutch housing.



Pulling outer race for tapered roller bearing out of gearbox housing


- A Counter-support, e.g. -Kukko 22/2-
- B Internal puller 46 ... 58 mm, e.g. -Kukko 21/7-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


Pressing outer race for tapered roller bearing into gearbox housing

- Fit shim below outer race.
- Support gearbox housing with sleeve -3144- directly below bearing mounting.



Identification of different types of spring pin

Dimension "a" (mm)	Identification
28.5 (short spring pin), removing and installing ⇒ page 184	Annular groove -arrows-
36.0 (long spring pin), removing <u>⇒ page 185</u> , installing <u>⇒ page 185</u>	No annular groove




Allocation of differential cage

Check hole for spring pin in differential cage.

Hole in differential cage has been modified for longer spring pin.

Hole	Length of spring pin (mm)
-A-	28.5 (short spring pin)
-A- and -B-	36.0 (long spring pin)




Spring pin with annular groove (short spring pin): removing and installing

Removing

- Cover up tapered roller bearing inner race and speedometer drive gear to keep out metal particles and to prevent damage.
- Drive out spring pin with chisel, inserting chisel into annular groove.

Installing

Drive fully into differential cage.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Removing spring pin without annular groove (long spring pin): pressing out differential pinion pin.

The spring pin is sheared off when pressing out.


Drive the remaining part of the spring pin out of the differential cage.



Installing spring pin without annular groove (long spring pin)

- Align hole in differential pinion pin with hole in differential cage.
- Use a punch -1- to drive in new spring pin to dimension -a- = 3.0 mm.
- Spring pin must not come into contact with gearbox when differential cage is installed.


Protected by copyright. Copying for private or commercial purp permitted unless authorised by AUDI AG. AUDI AG does not go with respect to the correctness of information in this docume



On some versions the one-piece thrust washer has a projection next to the holes -A-.

In this case the differential cage has a corresponding circular slot

- Lubricate one-piece thrust washer with gear oil and install.
- Position one-piece thrust washer so that it engages in the slot -B- in the differential cage.




Installing differential bevel gears

- Lubricate one-piece thrust washer with gear oil and install.
- Install both sun wheels and secure (e.g. with flange shaft).
- Insert planet pinions (180° apart) and pivot into position.
- Push differential pinion pin -arrow A- in as far as first planet pinion.
- Fit threaded pieces -arrows B- in sun wheels.

Installation position: stepped shoulder towards sun wheel

Drive differential pinion pin into final position and secure with spring pin.




Audi TT 2007 ➤

Installation position of thrust washer for tapered ring -1-

Collar -arrow- faces spring -B-.

Some gearbox versions have projections -A-.

The projections -A- face towards tapered ring -1-.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Table of adjustments



Note


When performing repairs on the gearbox it is only necessary to re-adjust the input shaft, output shaft or differential if components have been renewed which have a direct effect on the adjustment Protecte of the gearbox. Refer to the following table to avoid unnecessary permitted justment work UDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

		Components requiring adjustment:		
		Input shaft ⇒ page 147	Output shaft ⇒ page 165	Differential ⇒ page 188
Components renewed:	Gearbox housing	х	One-piece oil seal and sleeve ⇒ Item 11 (page 180)	X
	Clutch housing	х	x	х
	Input shaft	Х		
	Output shaft (final drive set)		Х	
	Differential cage			x
	Tapered roller bearing for input shaft	х		
	Tapered roller bearing for output shaft		x	
	Tapered roller bearings for differential			х
	4th gear wheel	Х		

Adjusting differential 4

Special tools and workshop equipment required

- Universal dial gauge bracket -VW 387-
- End measuring plate -VW 385/17-
- Press tool -VW 407-
- Thrust plate -30 205-
- Torque wrench -V.A.G 1331-
- Internal puller -1 Kukko 21/7-
- Counter-support -4 Kukko 22/2-
- Dial gauge



Procedure

It is necessary to readjust the differential when the following components have been renewed:

- Gearbox housing
- Clutch housing
- Differential cage

or the

Differential tapered roller bearings

Table of adjustments ⇒ page 187

Press tapered roller bearing outer race without shim into gearbox housing using thrust plate -30 - 205- ⇒ page 183





Note

The tapered roller bearing inner and outer races are paired. Do not interchange.

- Press tapered roller bearing outer race into clutch housing using thrust plate -30 205- \Rightarrow page 184.
- Install differential in clutch housing.
- Place gearbox housing in position and tighten 5 bolts to 25



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- Attach dial gauge and set to "0" with a preload of 1 mm.
- Move differential up and down and read off and note play indicated on dial gauge. (0.70 mm in this example.)

Determining thickness of shim

The specified bearing preload is obtained by adding a constant figure (0.40 mm) to the reading indicated.

Example:

Measured value	0.70 mm
+ Preload (constant value)	0.40 mm
Thickness of shim =	1.10 mm

- Detach gearbox housing and pull tapered roller bearing outer race out of gearbox housing ⇒ page 183.
- Install shims of the calculated thickness, thickest shim first.

The following shims are available:



Note

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Select correct shims from ⇒ Electronic parts catalogue .

Bearing clearance	Shim
Measured value (mm)	Thickness (mm)
0.3030.449	0.650
0.450 0.499	0.700
0.500 0.549	0.750
0.550 0.599	0.800
0.600 0.649	0.850
0.650 0.699	0.900
0.700 0.749	0.950
0.750 0.799	1.000
0.800 0.849	1.050
0.850 0.899	1.100
0.900 0.949	1.150
0.950 0.999	1.200
1.000 1.049	1.250
1.050 1.099	1.300
1.100 1.149	1.350
1.150 1.199	1.400

If the size of the shim required is larger than those listed in the table, install two shims amounting to the correct value.

Tolerance variations make it possible to obtain the exact shim thickness required.

Press in outer race again and secure gearbox housing.

