

# Workshop Manual Audi TT 2007 ➤

6-speed manual gearbox 02Q, four-wheel drive

Edition 10.2009



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

# List of Workshop Manual Repair GroupsList of Workshop Manual Repair GroupsList of Workshop Manual Repair Groups

### Repair Group

00 - Technical data

30 - Clutch

34 - Controls, housing

35 - Gears, shafts

39 - Final drive - front differential



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Technical information should always be available to the foremen and mechanics, because their careful and constant adherence to the instructions is essential to ensure vehicle road-worthiness and safety. In addition, the normal basic safety precautions for working on motor vehicles must, as a matter of course, be observed.

All rights reserved.

No reproduction without prior agreement from publisher.

## Contents

υυ -	· rech	nical data	1
	1	Gearbox identification	1
	2	Code letters, allocation, transmission ratios, capacities	2
	3	Transmission layout	5
	3.1	Calculating ratio "i"	6
	4	General repair instructions	7
	4.1	Contact corrosion!	7
	4.2	Repair instructions	7
30 -	· Clutc	h	12
	1	Overview - clutch mechanism	12
	1.1	Notes on removing and installing clutch master cylinder and slave cylinder	12
	1.2	Function check for clutch master cylinder and slave cylinder	13
	2	Exploded view - pedal cluster, clutch master cylinder	15
	2.1	Removing and installing over-centre spring	16
	2.2	Removing and installing clutch pedal	18
	2.3	Removing and installing mounting bracket	21
	2.4	Removing and installing clutch position sender G476	23
	2.5	Removing and installing clutch master cylinder	24
	3	Exploded view - hydraulics (LHD)	27
	3.1	Removing and installing pipe/hose assembly or plastic pipe	29
	3.2	Bleeding clutch system	31
	4	Exploded view - hydraulics (RHD)	33
	5	Exploded view - clutch release mechanism, slave cylinder	35
	5.1	Removing and installing clutch slave cylinder together with release bearing	36
		e <b>Clutch:identification</b> .UDI AG. AUDI AG. does not guarantee or accent any liability.	37
	7	with respect to the correctness of information in this document. Copyright by AUDI AG.  Exploded view - Sachs version clutch	39
	7.1	Removing and installing clutch (Sachs version)	41
	8	Exploded view - LuK version clutch	45
	8.1	Removing and installing clutch (LuK version)	47
34 -	<ul><li>Contr</li></ul>	ols, housing	50
	1	Overview - selector mechanism	50
	2	Exploded view - gear knob and covers	52
	2.1	Removing and installing gear knob with gear lever boot	53
	3	Exploded view - gear lever and selector housing for vehicles with vehicle ID No. up to 8J-7-013000	55
	4	Exploded view - gear lever and selector housing for vehicles with vehicle ID No. from 8J-7-013001 onwards	58
	4.1	Dismantling and assembling selector mechanism	59
	5	Removing and installing selector mechanism	64
	6	Exploded view - gear selector cable and gate selector cable up to model year 2007	68
	6.1	Exploded view - gearbox selector lever and gate relay lever up to model year 2007	70
	6.2	Exploded view - gear selector cable and gate selector cable from model year 2008 onwards	72
	6.3	Removing and installing gear selector cable and gate selector cable	77
	7	Adjusting selector mechanism	79
	8	Removing and installing gearbox	82
	8.1	Removing gearbox - vehicles with 2.0 ltr. TFSI engine	82
	8.2	Removing gearbox - vehicles with 3.2 ltr. MPI engine	93

	8.3 8.4	Removing gearbox - vehicles with 2.0 ltr. TDI engine	
	9	Transporting gearbox	
	10	Securing gearbox to assembly stand	
	11	Exploded view - assembly mountings	
	11.1 11.2	Removing gearbox mounting - vehicles with 2.0 ltr. TFSI engine	
	11.3	Removing gearbox mounting - vehicles with 2.0 ltr. TDI engine	
	11.4	Installing gearbox mounting	
	11.5	Removing and installing pendulum support	
	12		138
	12.1	Checking oil level in manual gearbox	138
	13	Removing and installing bevel box	140
	13.1	Removing bevel box - vehicles with 2.0 ltr. TFSI engine	
	13.2	Removing bevel box - vehicles with 3.2 ltr. MPI engine	
	13.3	Removing bevel box - vehicles with 2.0 ltr. TDI engine	
	13.4	Installing bevel box	
	14	Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not Checking geas oil level bin bevel box AG does not guarantee or accept any liability.	150
	14.1	Checking geas oil nevel bin bevel box AG does not guarantee or accept any liability	150
	14.2	Topping up gleathoir in bevel box ation in this document. Copyright by AUDI AG.	
	15	Dismantling and assembling gearbox	
	15.1	General layout of gearbox	
	15.2	Exploded view	
	15.3 15.4	Exploded view - gearbox housing and selector mechanism Exploded view - input shaft, output shafts, differential, bevel box and selector rods	
	15.5	Dismantling and assembling gearbox (version without circlip A for input shaft sealing cap)	
	15.6	Dismantling and assembling gearbox (version with circlip A for input shaft sealing cap)	
	16	Exploded view - gearbox housing	185
	16.1	Servicing gearbox housing	
	17	Exploded view - clutch housing	195
	17.1	Servicing clutch housing	
	17.2	Renewing input shaft oil seal	198
	18	Exploded view - selector mechanism in gearbox	201
	18.1	Renewing oil seal for selector shaft	
	18.2	Removing and installing selector shaft	203
	19	Exploded view - selector forks	
	19.1	Dismantling and assembling selector forks	207
35 -	Gears	s, shafts	209
	1	Exploded view - input shaft	209
	1.1	Dismantling and assembling input shaft	
	1.2	Modifications in area of grooved ball bearing	215
	2	Exploded view - output shaft for 1st - 4th gear	217
	2.1	Dismantling and assembling output shaft for 1st - 4th gear	220
	2.2	Adjusting output shaft for 1st - 4th gear	230
	3	Exploded view - output shaft for 5th, 6th and reverse gear	235
	3.1	Dismantling and assembling output shaft for 5th, 6th and reverse gear	
	3.2	Adjusting output shaft for 5th, 6th and reverse gear	245
39 -	Final	drive - front differential	250
	1	Exploded view - flange shaft and oil seals on gearbox	250
	1.1	Removing and installing flange shaft (left-side)	
	1.2	Renewing oil seal for flange shaft (left-side)	251

1.3	Renewing oil seal for bevel box with gearbox installed	253
2	Exploded view - flange shaft and oil seals on bevel box	255
2.1	Removing and installing flange shaft (right-side)	256
2.2	Renewing flange shaft oil seal (right-side) at bevel box (outer seal)	258
2.3	Renewing needle bearings (polygon bearings) for flange shaft (right-side)	259
2.4	Renewing oil seal between gearbox and bevel box (on bevel box)	260
2.5	Renewing oil seal for output flange on bevel box	262
3	Exploded view - differential	267
3.1	Dismantling and assembling differential	269
3.2	Table of adjustments	274
3.3	Adjusting differential	274
4	Propshaft	279
5	Rear final drive	280



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


### Technical data 00 -

## Gearbox identification


The 6-speed manual gearbox 02Q, four-wheel drive is installed in the Audi TT 2007  $\cdot$ . Allocation  $\Rightarrow$  page 2.

### Location on gearbox

- ♦ Code letters and date of manufacture -arrow 1-
- Manual gearbox 02Q, four-wheel drive -arrow 2-



Manual gearbox 02Q, four-wheel drive -arrow-



### Code letters and date of manufacture of gearbox -arrow-


Example:	GUM	04	08	3
	I	I		I
	Code letters	Protected   peDayd	by copyright. Co u <b>Month</b> horis	opying for private or commer <b>LearAof manufac</b> a do
		with res	spect to the cor	rectn $ ilde{t}$ u ${f re}$ f ( $2003$ ) ${f n}$ in this

Additional data identify the factory where the unit was built.



### Note

The code letters for the gearbox are also given on the vehicle data stickers.



#### 2 Code letters, allocation, transmission ratios, capacities

	JLV	JYV	KDP
from	04.06	11.06	06.07
to	11.06	05.07	02.08
Model	Audi TT 2007 ►	Audi TT 2007 ▶	Audi TT 2007 ▶
Engine	3.2 ltr. MPI - 184 kW	3.2 ltr. MPI - 184 kW	3.2 ltr. MPI - 184 kW
Final drive I for 1st to 4th gear	72 : 17 = 4.235	72 : 17 = 4.235	72 : 17 = 4.235
Final drive II for 5th/6th gear and reverse gear	72 : 22 = 3.273	72 : 22 = 3.273	72 : 22 = 3.273
1st gear	47 : 14 = 3.357	47 : 14 = 3.357	47 : 14 = 3.357
2nd gear	48 : 23 = 2.087	48 : 23 = 2.087	48 : 23 = 2.087
3rd gear	47 : 32 = 1.469	47 : 32 = 1.469	47 : 32 = 1.469
4th gear	37 : 34 = 1.088	37 : 34 = 1.088	37 : 34 = 1.088
5th gear	41 : 37 = 1.108	41 : 37 = 1.108	41 : 37 = 1.108
6th gear	31 : 34 = 0.912	31 : 34 = 0.912	31 : 34 = 0.912
Reverse gear	34 : 23 x 14 : 14 = 3.990	34 : 23 x 14 : 14 = 3.990	34 : 23 x 14 : 14 = 3.990
top gear	2.985	2.985	2.985
gearbox	2.3 litres		
ox	0.9 litres		
		Hydraulic	
	to Model Engine Final drive I for 1st to 4th gear Final drive II for 5th/6th gear and reverse gear 1st gear 2nd gear 3rd gear 4th gear 5th gear 6th gear Reverse gear top gear	from to 11.06  Model Audi TT 2007 ► 3.2 ltr. MPI - 184 kW  Final drive I for 1st to 4th gear  Final drive II for 5th/6th gear and reverse gear  1st gear 47: 14 = 3.357  2nd gear 48: 23 = 2.087  3rd gear 47: 32 = 1.469  4th gear 37: 34 = 1.088  5th gear 41: 37 = 1.108  6th gear 31: 34 = 0.912  Reverse gear 2.985  gearbox	from to       04.06       11.06       05.07         Model Engine       Audi TT 2007 ►       Audi TT 2007 ►       3.2 ltr. MPI - 184 kW       3.2 ltr. MPI - 184 kW         Final drive I for 1st to 4th gear and reverse gear       72 : 17 = 4.235       72 : 17 = 4.235         Final drive II for 5th/6th gear and reverse gear       72 : 22 = 3.273       72 : 22 = 3.273         1st gear       47 : 14 = 3.357       47 : 14 = 3.357         2nd gear       48 : 23 = 2.087       48 : 23 = 2.087         3rd gear       47 : 32 = 1.469       47 : 32 = 1.469         4th gear       37 : 34 = 1.088       37 : 34 = 1.088         5th gear       41 : 37 = 1.108       41 : 37 = 1.108         6th gear       31 : 34 = 0.912       31 : 34 = 0.912         Reverse gear       34 : 23 x 14 : 14 = 3.990       34 : 23 x 14 : 14 = 3.990         top gear       2.985       2.985         gearbox       0.9 litres

The following data can be found in the ⇒ Electronic parts catalogue .

♦ Gear oil specification

- Bevel box gear oil specification
- Allocation of drive shaft flange type
- Allocation of clutch type
- Rear final drive identification

Manual gearbox		pying for private or commercial purp ed by AUDI AG. AUDI AG does not g		
Code letters	with respect to the corr	ectness of infor <b>knith</b> in this docume	int. Copyright KNZ I AG.	KNW
Manufactured	from	01.08	05.08	06.08
	to	12.09	06.09	06.09
Allocation	Model	Audi TT 2007 ►	Audi TT 2007 ►	Audi TT 2007 ►
	Engine	3.2 ltr. MPI - 184 kW	2.0 ltr. TFSI - 199 kW	2.0 ltr. TDI CR - 125 kW
Ratio	Final drive I for 1st to 4th gear	72 : 17 = 4.235	72 : 17 = 4.235	62 : 16 = 3.875
i = Z <sub>2</sub> : Z <sub>1</sub>	Final drive II for 5th/6th gear and reverse gear	72 : 22 = 3.273	72 : 22 = 3.273	62 : 20 = 3.100
	1st gear	47 : 14 = 3.357	47 : 14 = 3.357	49 : 13 = 3.769

Manual gearbox				
Code letters		KNT	KNZ	KNW
	2nd gear	48 : 23 = 2.087	48 : 23 = 2.087	48 : 23 = 2.087
	3rd gear	47 : 32 = 1.469	47 : 32 = 1.469	45 : 34 = 1.324
	4th gear	37 : 34 = 1.088	37 : 34 = 1.088	34 : 37 = 0.919
	5th gear	41 : 37 = 1.108	34 : 31 = 1.097	37 : 41 = 0.902
	6th gear	31 : 34 = 0.912	31 : 34 = 0.912	28 : 37 = 0.757
	Reverse gear	34 : 23 x 14 : 14 = 3.990	34 : 23 x 14 : 14 = 3.990	36 : 23 x 13 : 14 = 4.549
Overall ratio iov. in t	Overall ratio i <sub>ov.</sub> in top gear		2.985	2.826
Capacity of manual gearbox		2.3 litres		
Capacity of bevel box		0.9 litres		
Clutch actuation		Hydraulic		

- The following data can be found in the post lectronic parts catalogue.

  In the following data can be found in the post lectronic parts catalogue.

  In the following data can be found in the post lectronic parts catalogue.

  In the following data can be found in the care to accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

  Bevel box gear oil specification
- ◆ Allocation of drive shaft flange type
- ♦ Allocation of clutch type
- Rear final drive identification

Manual gearbox				
Code letters		KXY	KZN	KZV
Manufactured	from	06.09	12.09	06.09
	to			
Allocation	Model	Audi TT 2007 ►	Audi TT 2007 ►	Audi TT 2007 ►
	Engine	2.0 ltr. TDI CR - 125 kW	3.2 ltr. MPI - 184 kW	2.0 ltr. TFSI - 199 kW
Ratio	Final drive I for 1st to 4th gear	62 : 16 = 3.875	72 : 17 = 4.235	72 : 17 = 4.235
i = Z <sub>2</sub> : Z <sub>1</sub>	Final drive II for 5th/6th gear and reverse gear	62 : 20 = 3.100	72 : 22 = 3.273	72 : 22 = 3.273
	1st gear	49 : 13 = 3.769	47 : 14 = 3.357	47 : 14 = 3.357
	2nd gear	48 : 23 = 2.087	48 : 23 = 2.087	48 : 23 = 2.087
	3rd gear	45 : 34 = 1.324	47 : 32 = 1.469	47 : 32 = 1.469
	4th gear	34 : 37 = 0.919	37 : 34 = 1.088	37 : 34 = 1.088
	5th gear	37 : 41 = 0.902	41 : 37 = 1.108	34 : 31 = 1.097
	6th gear	28 : 37 = 0.757	31 : 34 = 0.912	31 : 34 = 0.912
	Reverse gear	36 : 23 x 13 : 14 = 4.549	34 : 23 x 14 : 14 = 3.990	34 : 23 x 14 : 14 = 3.990
Overall ratio i <sub>OV.</sub> in	top gear	2.826	2.985	2.985
Capacity of manual	l gearbox	2.3 litres		
Capacity of bevel b	ОХ	0.9 litres		
Clutch actuation		Hydraulic		



Manual gearbox			
Code letters	KXY	KZN	KZV

The following data can be found in the  $\Rightarrow$  Electronic parts catalogue.

- Gear oil specification
- Bevel box gear oil specification
- Allocation of drive shaft flange type
- Allocation of clutch type
- Rear final drive identification




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

### 3 Transmission layout

### Identification

Arrows point in direction of travel

- 1 Engine
- 2 Clutch
- 3 Manual gearbox
- 4 Input shaft
- 5 Output shaft II for 5th, 6th and reverse gear
- 6 Output shaft I for 1st 4th
- 7 Differential
- 8 Bevel box
- 9 Propshaft
- 10 Haldex coupling
- 11 Rear final drive
- 12 Differential




### Ratio

Arrows point in direction of travel

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- I 1st gear
- II 2nd gear
- III 3rd gear
- IV 4th gear
- V 5th gear
- VI 6th gear
- R Reverse gear
- A Final drive
- W1 Front bevel gears
- W2 Rear bevel gears



#### Calculating ratio "i" 3.1

### Example:

	6th gear	Final drive
Drive gear	ZG <sub>1</sub> = 34	ZA <sub>1</sub> = 22
Driven gear	ZG <sub>2</sub> = 31	ZA <sub>2</sub> = 72

 $i = ZG_2 : ZG_1^{1}$ 

 $i_G = gear \ ratio = ZG_2 : ZG_1 = 31 : 34 = 0.912$ 

 $i_A = axle ratio = ZA_2 : ZA_1 = 72 : 22 = 3.273$ 

 $i_{OV}$  = overall ratio =  $i_{G}$  x  $i_{A}$  = 0.912 x 3.273 = 2.985

1)  $Z_1$  = No. of teeth on drive gear,  $Z_2$  = No. of teeth on driven gear

tected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### 4 General repair instructions

Proper tools and the maximum possible care and cleanliness are essential for satisfactory gearbox repairs. The usual basic safety precautions also naturally apply when carrying out repair work.

A number of generally applicable instructions for the various repair procedures - which were previously repeated at numerous places in the Workshop Manual - are summarised here. They apply to the work described in this Manual.

#### 4.1 Contact corrosion!

Contact corrosion can occur if non-approved fasteners are used on the vehicle (bolts, nuts, washers etc.).

For this reason, only fasteners with a special surface coating are fitted.

Rubber or plastic parts and adhesives also consist of non-conductive materials.

If you are not sure whether used parts can be re-installed, always fit new parts ⇒ Electronic parts catalogue.

### Please note:

- The gearbox casing is made of a magnesium alloy.
- Use only genuine spare parts: these have been fully tested and are compatible with aluminium.
- We recommend the use of accessories approved by Audi.



Caution

Protected by copyright. Copying permitted unless authorised by A with respect to the correctness

Damage caused by contact corrosion is not covered under warranty.

private or commercial purposes, in part or in whole, is not JDI AG. AUDI AG does not guarantee or accept any liability of information in this document. Copyright by AUDI AG.

#### 4.2 Repair instructions

### Special tools

For a complete list of special tools used in this Workshop Manual ⇒ Workshop equipment and special tools.

### Gearbox

- Thoroughly clean all joints and connections and the surrounding areas before dismantling.
- When installing the gearbox, ensure that the dowel sleeves between the engine and the gearbox are correctly located.
- For allocation of bolts and other components, refer to ⇒ Electronic parts catalogue.
- Clean contact surfaces when assembling mounting brackets and waxed components. The contact surfaces must be free of wax and grease.
- After installing a replacement gearbox with bevel box, check oil level in gearbox ⇒ page 138 and bevel box ⇒ page 150.
- Capacities ⇒ page 2, specifications ⇒ Electronic parts catalogue .

### Oil seals, seals, O-rings and gaskets

- Always renew oil seals, O-rings and gaskets.
- After removing gaskets and seals, always inspect the contact surface on the housing or shaft for burrs resulting from removal or for other signs of damage.
- Before installing oil seals, lightly oil the outer circumference of the seal and fill the space between the sealing lips -arrowabout half full with grease -G 052 128 A1-.
- The open side of the oil seal should face the side containing the fluid.
- When installing a new oil seal, position the seal in the housing so that the sealing lip does not contact the shaft in the same place as the old seal (make use of installation depth tolerances).
- Protected by copyright. Copyring for private or commercial purposes, in part or in whole, is not 

  ◆erLightly-lubricate. Ø-rings: with oil before installation to prevent 


   whem being trapped during assembly ment. Copyright by AUDI AG.
- After installing new gaskets, O-rings and oil seals, check oil level in manual gearbox ⇒ page 138 and bevel box ⇒ page 150.




- Thoroughly clean joint surfaces on gearbox housing etc. before applying sealing paste.
- Apply sealing paste -AMV 188 200 03- evenly and not too thick.
- ♦ Breather holes must remain free of sealing paste.

### Locking elements

- ♦ Do not over-stretch circlips.
- Renew circlips which have been damaged or over-tensioned.
- Circlips must be properly seated in the base of the groove.
- Renew spring pins. Position: the slit -A- should be in line with the line of force -arrow-.





- Loosen the nuts and bolts in reverse sequence to the specified tightening sequence.
- Nuts and bolts which secure covers and housings should be loosened and tightened in diagonal sequence and in stages if no tightening sequence is specified.
- Renew self-locking nuts and bolts.
- The tightening torques stated apply to non-oiled nuts and bolts.
- Threaded holes which take self-locking bolts or bolts coated with locking fluid must be cleaned (using a tap or similar). Otherwise there is a danger of the bolts shearing off the next time they are removed.







- Install new tapered roller bearings as supplied; do not lubricate additionally with oil.
- Lubricate all bearings (except tapered roller bearings) with gear oil before installing in gearbox.
- Use inductive heater -VAS 6414- to heat inner races of tapered roller bearings to approx. 100°C before installing. Press home onto stop when installing so there is no axial clearance.
- Do not interchange inner or outer races of bearings of the same size.
- If required, renew the tapered roller bearings on one shaft together and use new bearings from a single manufacturer.
- Install needle bearings so the lettering (side with thicker metal) faces towards the installing tool.

### Shims

- Use a micrometer to measure the shims at several points. Tolerance variations make it possible to obtain the exact shim thickness required.
- Check for burrs and damage. Install only shims which are in perfect condition.
- Install only shims which are in perfect condition.





### Synchro-rings


- Do not interchange synchro-rings. When reusing always fit to the same selector gear.
- ♦ Check for wear; renew if necessary.
- Check the grooves -arrow 1- on synchro-ring -A- and on inner ring for wear (flattened sections in grooves).
- Make sure that the coating of coated synchro-rings is not damaged.
- If an intermediate ring -B- is fitted, check the outer contact surface -arrow 2- and inner contact surface -arrow 3- of the intermediate ring for "scoring", "visible traces of wear" and "blue discolouration (caused by overheating)".
- Check chamfer on selector gear for scoring and visible traces of wear.
- ◆ Lubricate with gear oil before installing.

### Gear wheels


- Clean before pressing on.
- Use inductive heater -VAS 6414- to heat to approx. 100°C before installing. Press home onto stop when installing so there is no axial clearance.

### Selector gears and locking collars


- After installing, check 1st to 6th speed selector gears for minimal axial play and freedom of movement.
- ♦ Abnormal wear on synchro-ring or selector gear:
- A Worn chamfer on dog teeth of synchro-ring or selector gear.




- ♦ In comparison: intact synchro-ring or selector gear:
- B Intact chamfer on dog teeth of synchro-ring or selector gear.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Abnormal wear on locking collar:
- C Worn chamfer on internal splines of locking collar.




- ♦ In comparison: intact locking collar:
- D Intact chamfer on internal splines of locking collar.

### Clutch actuation, clutch

- If the clutch pedal does not return to its initial position after releasing it (clutch pedal in rest position), you must bleed the clutch system (further measures ⇒ page 12).
- Ensure that the pressure plate is kept straight: loosen and tighten bolts consecutively in steps of 90°.
- If the clutch has burnt out, thoroughly clean the gearbox housing in area of clutch and parts of the engine facing the gearbox in order to prevent odours.



- ♦ Only blow out dual-mass flywheel with compressed all recorrectness of information in this document. Copyright by AUDI AG.
- Clutch pressure plates have an anti-corrosion coating and are greased. With the exception of the friction surface for the clutch plate, the pressure plate must not be cleaned. Otherwise the service life of the clutch will be considerably reduced.
- The friction surface of the pressure plate and the dual-mass flywheel must be cleaned (degreased) thoroughly.



## 30 – Clutch

### 1 Overview - clutch mechanism




Note

If you suspect a defective clutch master cylinder or clutch slave cylinder, pay attention to

⇒ "1.1 Notes on removing and installing clutch master cylinder and slave cylinder", page 12 and perform

⇒ "1.2 Function check for clutch master cylinder and slave cylinder", page 13 prior to renewing.

- ⇒ "2 Exploded view pedal cluster, clutch master cylinder", page 15
- ⇒ "2.1 Removing and installing over-centre-spring grapage 16 form
- ⇒ "2.2 Removing and installing clutch pedal", page 18
- ⇒ "2.3 Removing and installing mounting bracket", page 21
- ⇒ "2.4 Removing and installing clutch position sender G476", page 23
- ⇒ "2.5 Removing and installing clutch master cylinder", page 24
- II -
- ⇒ "3 Exploded view hydraulics (LHD)", page 27
- ⇒ "3.1 Removing and installing pipe/hose assembly or plastic pipe", page 29
- ⇒ "3.2 Bleeding clutch system", page 31
- III -
- ⇒ "4 Exploded view hydraulics (RHD)", page 33



# 1.1 Notes on removing and installing clutch master cylinder and slave cylinder

 Before renewing the clutch master cylinder or slave cylinder on the assumption that it is defective you must first carry out a function check

### ⇒ "1.2 Function check for clutch master cylinder and slave cylinder", page 13

- If slave cylinder is removed from gearbox with pipe/hose assembly still attached, make sure you do not press clutch pedal. Otherwise, the piston will be pressed out of the slave cylinder and be destroyed.
- After installing the slave cylinder, carefully press the clutch pedal. If you feel an unusually strong point of resistance when depressing the clutch pedal, you must not press it down further. The plunger of the slave cylinder is likely to have been guided past the clutch release lever. The slave cylinder would then be destroyed once pedal force exceeds approx. 300 N.

### 1.2 Function check for clutch master cylinder and slave cylinder

Before you renew the clutch master cylinder or slave cylinder you must - in the case of the following faults - first carry out the appropriate checks.

### Noises when operating the clutch:

- First check the over-centre spring / clutch pedal switch for noise.
- If you hear a noise, remove over-centre spring and repeat check.
- Renew relevant component.

### After releasing clutch pedal it still remains depressed / does not return to its initial position.

- Check whether the clutch pedal returns all the way to its initial position, thereby uncovering the vent opening in the master cylinder.
- The vent opening is integrated in the clutch master cylinder. It is not visible from the outside.
- The vent opening must be uncovered, otherwise the permanent self-bleeding function for the hydraulic clutch system will no longer be effective. te or commercial purposes, in part or in whole, is not
- ◆ Make the customer aware that the driver must NOT rest his/ her foot on the clutch pedal for long periods of time. This could impair the self-bleeding function of the clutch system as the vent opening in the master cylinder can no longer function.
- The self-bleeding function of the clutch system can be impaired if the footwell trim or floor mats get trapped, if the clutch pedal switch jams or if the driver rests his foot on the clutch pedal for long periods of time.

### Check the complete hydraulic system for leaks.

- Check brake fluid level in brake fluid reservoir.
- Check clutch master cylinder and slave cylinder as well as the pipe/hose assembly including connections for external leaks (visual inspection).
- If you identify any leaks you must renew the leaking compo-
- Bleed clutch system ⇒ page 12.

### Pedal forces:

approx. 140 N for complete service life of the clutch



### High pedal force:

Mechanical fault on pressure plate/clutch plate ⇒ page 39 or ⇒ page 45

### Clutch does not disengage or does not disengage fully:

- ◆ Air in hydraulic system: bleed clutch system ⇒ page 12 and check hydraulic system for external and internal leaks.
- Clutch plate does not move smoothly on input shaft splines (due to corrosion or dirt, etc.)
- Foreign body in clutch system
- Mechanical fault on pressure plate/clutch plate ⇒ page 39 or ⇒ page 45
- Wrong components used or components forgotten when carrying out repair work (e.g. intermediate plate or dowel

Sleeves).
Frotected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### 2 Exploded view - pedal cluster, clutch master cylinder



### Note

Lubricate all bearings and moving surfaces with grease -G 000 450 02-.

### 1 - Bulkhead

With mounting for mounting bracket

### 2 - Gasket

- ☐ Renew
- □ Between mounting bracket and bulkhead
- □ Self-adhesive
- Bond onto mounting bracket

### 3 - Mounting bracket

- For clutch pedal
- □ Removing and installing ⇒ page 21
- 4 Bolt

### 5 - Over-centre spring

- □ Removing and installing ⇒ page 16
- 6 Bearing bush


### 7 - Pivot pin

### 8 - Clutch pedal

- Removing and installing ⇒ page 18
- ☐ If fitting new pedal rubber, cut to required size as described ⇒ page 16

### 9 - Retaining clip

□ For operating rod on clutch master cylinder



### 10 - Seal

permitted unle s authorised by AUDI AG. AUDI AG does not guarantee or accept a with respect to the correctness of information in this document. Copyright by AUDI AG.

### □ Renew

Between master cylinder and mounting bracket

### 11 - Clutch master cylinder

□ Removing and installing ⇒ page 24

### 12 - Clutch position sender -G476-

- □ Removing and installing ⇒ page 23
- □ Checking in "Guided Fault Finding" ⇒ Vehicle diagnosis, testing and information system VAS 5051

### 13 - Retaining clip

☐ To remove and install pipe/hose assembly, pull out clip as far as it will go

### 14 - Supply hose

□ To brake fluid reservoir

- ☐ Made of rubber or plastic, depending on version
- ☐ Plastic supply hose with additional seals <u>⇒ page 28</u>

### 15 - Nut

- ☐ For securing mounting bracket to bulkhead
- □ 20 Nm
- □ 3x
- □ Self-locking
- ☐ Renew

### 16 - Nut


- □ 25 Nm
- □ Self-locking
- ☐ Renew

### 17 - Stop

□ For clutch pedal


### Crash bar - tightening torque

- Fit crash bar -2- and tighten 1 or 2 bolts (depending on version) -arrows B-.
- M6 10 Nm
- M8 20 Nm



### Renewing pedal rubber for clutch pedal


- Cut new clutch pedal rubber to size as illustrated.
- Dimension -x- = 20 mm



# 2.1 Removing and installing over-centre spring

Special tools and workshop equipment required


Assembly tool -T10178-



♦ Grease -G 000 450 02-

### Removing

- Clutch pedal mounting bracket fitted in vehicle
- Move driver's seat away from pedals.
- Remove storage compartment on driver's side = Representation Representation Remove storage compartment on driver's side = Representation Remove storage side = Remove side = Remove side = Remove storage side = Remove side
- Unscrew bolt -arrow A- and remove footwell air outlet (front left) -1-.
- Unclip wiring harness at rear of footwell air outlet -1- and move clear to one side.
- Unbolt crash bar -2- (secured by one or two bolts -arrows B-, depending on version).




Unbolt clutch pedal -1- from mounting bracket -3-. To do this, remove nut -2- and pull out bolt -5-.



### Note

The clutch pedal does not have to be detached from the operating rod on the clutch master cylinder.

Pivot clutch pedal down slightly and and take over-centre spring -4- out of mounting bracket.



### Installing


• Tightening torque <u>⇒ page 15</u>

Installation is carried out in reverse sequence; note the following:




### Note

- ♦ Renew self-locking nut.
- Lubricate all bearings and contact surfaces with grease -G 000 450 02-.
- Fit over-centre spring -2- into mounting bracket from above while holding end of spring in correct position with assembly tool -T10178-.




- Socket -arrow- of over-centre spring must/be in vertical posi-commettion.
   spring must/be in vertical posi-commettion must/be in vertical posi-commettion.
   with respect to the correctness of information in this
- Fit actuator on clutch pedal -A- into corresponding socket in over-centre spring -arrow-.
- Press clutch pedal slightly, push bolt through and tighten selflocking nut.
- Install crash bar ⇒ page 16.
- Install front footwell vent (left-side) ⇒ Rep. Gr. 80 .
- Install storage compartment on driver's side ⇒ Rep. Gr. 68.




## 2.2 Removing and installing clutch pedal

Special tools and workshop equipment required

♦ Pliers -T10005-




Assembly tool -T10178-




♦ Grease -G 000 450 02-

### Removing


- Clutch pedal mounting bracket fitted in vehicle
- Move driver's seat away from pedals.
- Remove storage compartment on driver's side  $\Rightarrow$  Rep. Gr.
- Unscrew bolt -arrow A- and remove footwell air outlet (front left) -1-.
- Unclip wiring harness at rear of footwell air outlet -1- and move clear to one side.
- Unbolt crash bar -2- (secured by one or two bolts -arrows B-, depending on version).



- Unbolt clutch pedal -1- from mounting bracket -3-. To do this, remove nut -2- and pull out bolt -5-.
- Pivot clutch pedal down slightly and and take over-centre spring -4- out of mounting bracket.



- Release retaining clip for operating rod on master cylinder using pliers -T10005- .
- Remove clutch pedal.



### Installing


Tightening torque ⇒ page 15

Installation is carried out in reverse sequence; note the following:




### Note

- ♦ Renew self-locking nut.
- ◆ Lubricate all bearings and contact surfaces with grease -G 000 450 02-.
- Install retaining clip -2- on operating rod -1- of master cylinder.
- Press retaining clip into mounting on clutch pedal so that it snaps into place.
- Fit over-centre spring -2- into mounting bracket from above while holding end of spring in correct position with assembly tool -T10178-.







Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

N30-0421

- Socket -arrow- of over-centre spring must be in vertical posi-
- Fit actuator on clutch pedal -A- into corresponding socket in over-centre spring -arrow-.
- Press top of clutch pedal forwards against spring pressure of over-centre spring, push through bolt and tighten self-locking nut.



### Note


It is easier to press the clutch pedal against the spring if you pull back the bottom of the pedal carefully as you bring the top of the pedal into installation position.

- Install crash bar ⇒ page 16.
- Install front footwell vent (left-side) ⇒ Rep. Gr. 80.
- Install storage compartment on driver's side ⇒ Rep. Gr. 68.


### 2.3 Removing and installing mounting bracket

### Special tools and workshop equipment required

♦ Hose clamp, up to Ø 25 mm -3094-



♦ Hose clip pliers -VAS 6340-



with respect to the correctness of information in this document. Copyright by AUDI AG


### Removing




### Note


In the following steps make sure that no brake fluid escapes onto the longitudinal member or onto the gearbox below. If this does happen, clean the affected area thoroughly.

- Use hose clamp -3094- to clamp off supply hose to clutch master cylinder.
- Disconnect supply hose at clutch master cylinder (if necessary, release spring-type clip -3- using hose clip pliers -VAS 6340-).
- Release retaining clip -2- with a screwdriver and disconnect pipe/hose assembly -1- or plastic pipe from clutch master cylinder.
- Unclip and detach clutch position sender -G476- from clutch master cylinder -arrow-. Electrical connector -4- can remain connected.





- Move driver's seat to rear as far as possible and move steering wheel into uppermost position.
- Remove storage compartment on driver's side ⇒ Rep. Gr.
- Unscrew bolt -arrow A- and remove footwell air outlet (front
- Unclip wiring harness at rear of footwell air outlet -1- and move clear to one side.
- Unbolt crash bar -2- (secured by one or two bolts -arrows B-, depending on version).





### Note

When working in the footwell, put cloths on the floor covering to protect it from possible brake fluid spills.

- Remove nuts -2-.
- Take out mounting bracket -1-.

### Installing

Tightening torque ⇒ page 15

Installation is carried out in reverse sequence; note the following:



### Note

- Renew self-locking nuts.
- Secure all hose connections with the correct hose clips (as original equipment); refer to ⇒ Electronic parts catalogue .
- Fit mounting bracket -1- and tighten nuts -2-.
- Install pipe/hose assembly or plastic pipe ⇒ page 29.
- Bleed clutch system ⇒ page 31.
- Install crash bar <del>⇒ page 16</del>.
- Install front footwell vent (left-side) ⇒ Rep. Gr. 80.
- Install storage compartment on driver's side ⇒ Rep. Gr. 68.

### Removing and installing clutch position 2.4 sender -G476-

### Removing

- Unplug electrical connector -4-.
- Unclip clutch position sender -G476- at clutch master cylinder in direction of -arrow- and remove.





### Note

-Items 1, 2 and 3- can be disregarded.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





### Installing


- Fit clutch position sender -G476- at clutch master cylinder and engage -arrow-.
- Attach electrical connector -4-.



### 2.5 Removing and installing clutch master cylinder

### Special tools and workshop equipment required

♦ Pliers -T10005-




### Removing




- If you suspect a defective clutch master cylinder, perform function test prior to renewing ⇒ "1.1 Notes on removing and installing clutch master cylinder and slave cylinder", page 12.
- When working in the footwell, put cloths on the floor covering to protect it from possible brake fluid spills.

- Remove mounting bracket ⇒ page 21.
- Release retaining clip for operating rod on clutch pedal using pliers -T10005- .




- Insert a spacer -A- between clutch pedal and stop, and press clutch pedal forward.
- Length of spacer = approx. 40 mm (e.g.  $^{1}/_{2}$ " socket)
- Release retainer clip -B- and pull master cylinder out of mounting bracket -arrow 1- and -arrow 2-.




with respect to the correctness of i

### Installing

- Move clutch pedal back as far as stop until it is in normal position.
- Install retaining clip -2- on operating rod -1- for clutch master cylinder.




- Insert a spacer -A- between clutch pedal and stop, and press clutch pedal forward.
- Length of spacer = approx. 40 mm (e.g.  $^{1}/_{2}$ " socket)
- Secure master cylinder on mounting bracket -arrow 1- and -arrow 2-.



- Press operating rod -1- for master cylinder in direction of -arrow- so that retaining clip -2- snaps into place in clutch ped-
- Install mounting bracket ⇒ page 21.







#### Exploded view - hydraulics (LHD) 3

### 1 - Brake fluid reservoir

### 2 - Hose clip (spring-type clip)

Not fitted in all vehicles

### 3 - Supply hose

- ☐ Made of rubber or plastic, depending on ver-
- Plastic supply hose with additional seals ⇒ page 28

### 4 - Clutch master cylinder

□ Removing and installing ⇒ page 24

### 5 - Clip

□ To remove and install pipe/hose assembly, pull out clip as far as it will go

### 6 - Seal or O-ring

- Renew damaged seals or O-rings
- Push onto pipe connec-
- Lubricate with brake fluid before installing
- ☐ Whether a seal or an Oring is used depends on the type of connection
- For correct version, refer to ⇒ Electronic parts catalogue

# 7 - Retaining clip

☐ To remove and install retaining clip first detach clutch master cylinder from clutch pedal ⇒ page 18

### 8 - Clutch pedal

□ Removing and installing ⇒ page 18

### 9 - Nut

- ☐ For securing mounting bracket to bulkhead
- ☐ Tightening torque ⇒ Item 15 (page 16)

### 10 - Pipe/hose assembly


- □ Removing and installing ⇒ page 29
- □ Different types depending on gearbox version
- ☐ For correct version, refer to ⇒ Electronic parts catalogue

### 11 - Bracket

- ☐ For pipe/hose assembly ⇒ Item 10 (page 27)
- Secured on body
- ☐ Identification of brackets ⇒ page 29

### 12 - Plastic pipe

□ Removing and installing ⇒ page 29



## 6-speed manual gearbox 02Q, four-wheel drive - Edition 10.2009

- ☐ Different types depending on gearbox version
- ☐ For correct version, refer to ⇒ Electronic parts catalogue

### 13 - Bracket

- ☐ For plastic pipe ⇒ Item 12 (page 27)
- Secured on body
- ☐ Identification of brackets <u>⇒ page 29</u>

### 14 - Seal or O-ring

- □ Renew damaged seals or O-rings
- Push onto pipe connection
- ☐ Lubricate with brake fluid before installing
- Whether a seal or an O-ring is used depends on the type of connection ⇒ page 28
- ☐ For correct version, refer to ⇒ Electronic parts catalogue

### 15 - Bleeder connection

### 16 - Clip

☐ To remove and install pipe/hose assembly or bleeder connection, pull out clip as far as it will go.

### 17 - Bleeder screw

- □ 4.5 Nm
- ☐ Bleeding clutch system ⇒ page 31

ring for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability 18 - Dust cap with respect to the correctness of information in this document. Copyright by AUDI AG.

### 19 - Clutch slave cylinder with release bearing

☐ Can only be renewed after removing gearbox


### 20 - Gearbox


### O-ring or seal for pipe/hose assembly or plastic pipe

- 1 O-ring
- ◆ Connection with annular groove -arrow 1-
- ♦ Check O-ring for damage and renew if necessary
- 2 Seal
- ♦ Connection with shoulder -arrow 2-
- Position seal -2- onto connection -arrow 2- before fitting

### Vehicles with plastic supply hose -1-


Seals -2- must be fitted in supply hose.





### Identification of brackets


Dimension "a" (mm)	Pipe version
8	Plastic pipe
6	Pipe/hose assembly



### Removing and installing pipe/hose as-3.1 sembly or plastic pipe


### Special tools and workshop equipment required

♦ Hose clamps, up to Ø 25 mm -3094-



### Removing

- Remove air cleaner housing completely Reports. 23, of Private or commercial purposes, in part or in whole, is not Rep. Gr. 24 permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.
- Use hose clamp -3094- to clamp off supply hose to clutch master cylinder.






### Note

- In the following steps make sure that no brake fluid escapes onto the longitudinal member or onto the gearbox below. If this does happen, clean the affected area thoroughly.
- Place a cloth underneath to catch escaping brake fluid.
- To detach at clutch master cylinder, release retaining clip -3with a screwdriver.
- Pull off pipe/hose assembly -1- or plastic pipe with Oping 2-pying for pand detach from bracket.



### Caution

Do not depress clutch pedal after removing pipe/hose assembly or plastic pipe.






### Note

Place a cloth underneath to catch escaping brake fluid.

 To detach at bleeder connection, release retaining clip -2- with a screwdriver and pull pipe/hose assembly -4- or plastic pipe with O-ring -3- off bleeder connection -1-.



### Installing


Installation is carried out in reverse sequence; note the following:



### Note


For distinction between O-rings -2- and seals, refer to ⇒ page 28

- Check O-ring -2- for damage and renew if necessary.
- Press pipe/hose assembly -1- or plastic pipe onto connection on clutch master cylinder -4- so that retaining clip -3- snaps into place.
- Pull on pipe to check it is secure.





- Check O-ring -3- for damage and renew if necessary.
- Press pipe/hose assembly -4- or plastic pipe onto bleeder connection so that retaining clip -2- snaps into place.
- Pull on pipe to check it is secure.
- Bleed clutch system ⇒ page 31.



#### 3.2 Bleeding clutch system




#### Note

- The clutch system must be bled after performing work on the hydraulic clutch mechanism.
- In the following steps make sure that no brake fluid escapes onto the longitudinal member or onto the gearbox below.
- Before bleeding clutch system, top up brake fluid reservoir for private or commercial purposes, in part or in whole, is not "max" marking with brake fluid permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability "max." marking with brake fluid. with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Special tools and workshop equipment required

Brake filling and bleeding equipment -VAS 5234-




♦ Brake fluid specification ⇒ Rep. Gr. 47.

#### **Procedure**

- Tightening torque ⇒ page 27
- Remove air cleaner housing completely ⇒ Rep. Gr. 23 or ⇒ Rep. Gr. 24.

- Pull clutch pedal back to its normal rest position.
- Connect brake filling and bleeding equipment -VAS 5234- to brake fluid reservoir.
- Remove protective cap from bleeder screw -arrow- and connect hose -A- from bleeder bottle to bleeder screw.
- Switch on bleeding equipment.
- · Operating pressure 2.0 bar
- Now open bleeder screw approx <sup>1</sup>/<sub>4</sub> turn and allow 100 cm<sup>3</sup> of brake fluid to run out.
- With bleeder screw open, pump clutch pedal rapidly all the way in and out by hand 15 to 20 times (approx. 2 times per second).
- Close bleeder screw.
- Switch off brake filling and bleeding equipment -VAS 5234and relieve pressure from bleeding equipment.
- Now press clutch pedal slowly all the way in and out 10 times.
- Check that clutch system is functioning properly.
- Disconnect bleeder hose and fit protective cap.
- Remove brake filling and bleeding equipment -VAS 5234from brake fluid reservoir.
- Install air cleaner housing ⇒ Rep. Gr. 23 or ⇒ Rep. Gr. 24.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Exploded view - hydraulics (RHD) 4

#### 1 - Brake fluid reservoir

#### 2 - Seal

- For plastic supply hose
- Seals must be fitted in supply hose.

#### 3 - Supply hose

- Made of rubber or plastic, depending on ver-
- Plastic supply hose with additional seals ⇒ Item 2 (page 33)

#### 4 - Clutch master cylinder

□ Removing and installing

Protected by copyright page 24r private or commerci norised by AUDI AG. AUDI AG doe with respective correctness of information in this d

> To remove and install pipe, pull out clip as far as it will go

#### 6 - Seal or O-ring

- Matched to type of connection ⇒ page 28
- For correct version, refer to ⇒ Electronic parts catalogue
- □ Renew damaged seals or O-rings
- ☐ Push onto pipe connec-
- ☐ Lubricate with brake fluid before installing

#### 7 - Retaining clip

☐ To remove and install retaining clip first detach master cylinder from clutch pedal <u>⇒ page 18</u>

#### 8 - Clutch pedal

#### 9 - Nut

- ☐ For securing mounting bracket to bulkhead
- □ 20 Nm

#### 10 - Bracket


Secured on body

#### 11 - Pipe

☐ For correct version, refer to ⇒ Electronic parts catalogue

#### 12 - Seal or O-ring

- Matched to type of connection ⇒ page 28
- ☐ For correct version, refer to ⇒ Electronic parts catalogue
- □ Renew damaged seals or O-rings
- Push onto pipe connection
- ☐ Lubricate with brake fluid before installing



#### 13 - Pipe/hose assembly

☐ For correct version, refer to ⇒ Electronic parts catalogue

#### 14 - Bracket

□ Secured to bracket for ABS/EDL

#### 15 - Seal or O-ring

- Matched to type of connection ⇒ page 28
- ☐ For correct version, refer to ⇒ Electronic parts catalogue
- □ Renew damaged seals or O-rings
- Push onto pipe connection
- ☐ Lubricate with brake fluid before installing

#### 16 - Clip

☐ To remove and install pipe/hose assembly or bleeder connection, pull out clip as far as it will go.

#### 17 - Bleeder screw

- ☐ Bleeding clutch system ⇒ page 31
- □ 4.5 Nm

#### 18 - Dust cap

#### 19 - Bleeder connection

#### 20 - Clutch slave cylinder with release bearing

- ☐ Can only be renewed after removing gearbox
- □ Removing and installing ⇒ page 36

#### 21 - Gearbox



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### 5 Exploded view - clutch release mechanism, slave cylinder

#### 1 - Bolt

- 12 Nm for metal clutch slave cylinder
- 15 Nm for plastic clutch slave cylinder
- □ 3x
- □ Renew
- ☐ Tighten bolts carefully in several small steps and in diagonal sequence; make sure that mounting lugs on slave cylinder do not break off

#### 2 - Clutch slave cylinder with release bearing

- Slave cylinder and release bearing are one unit and can only be renewed together
- Do not wash out bearing; wipe clean only
- ☐ If bearing is noisy, renew together with slave cylinder
- Removing and installing ⇒ page 36

#### 3 - O-ring

- □ Renew if damaged
- Push onto pipe connection
- Lubricate with brake fluid before installing

#### 4 - Retaining clip

#### 5 - Bleeder screw

- ☐ Tightening torque ⇒ Item 17 (page 28)
- 6 Protective cap

#### 7 - Retaining clip

#### 8 - Pipe/hose assembly or plastic pipe

- □ To clutch master cylinder
- □ Removing and installing ⇒ page 29

#### 9 - O-ring


- Renew if damaged Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not Push onto pipe connection d by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.
- ☐ Lubricate with brake fluid before installing

#### 10 - Bleeder connection

- Removing and installing
  - ⇒ "5.1 Removing and installing clutch slave cylinder together with release bearing", page 36

#### 11 - Oil seal

For input shaft



# 5.1 Removing and installing clutch slave cylinder together with release bearing




#### Note

Slave cylinder and release bearing are one unit and can only be renewed together.

#### Removing

- Gearbox removed ⇒ page 82
- Release retaining clip 22 with a screwdriver and pull bleederot permitted unless all norged in AUDI AS AUDI AG does not guarantee of accept any liability connection of a off-slave cylinder in Inis document. Copyright by AUDI AG.



- Remove bolts -arrows-.
- Take off slave cylinder together with release bearing -A-.

#### Installing


Tightening torque ⇒ page 35

Installation is carried out in reverse sequence; note the following:





#### Caution

Tighten securing bolts for slave cylinder in small steps. Otherwise mounting lugs -arrows- can be damaged.



- Check O-ring -3- for damage and renew if necessary.
- Press bleeder connection -4- onto connection on clutch slave cylinder -1- so that retaining clip -2- snaps into place.
- Pull on bleeder connection to check it is secure.
- Bleed clutch system ⇒ page 31.





#### Clutch identification 6




#### Note

The clutch fitted in the vehicle is supplied by either "Sachs" or


With gearbox installed, the clutch version fitted can be distinguished as follows:

- Release fasteners -1 ... 4- and remove centre noise insulation.



A number of recesses -arrows- are located in lower area of sump between engine -A- and gearbox -B-.

- Check the contour of the flywheel visible through the recesses.



A - round contour -arrows- = Sachs version clutch

Exploded view - Sachs version clutch ⇒ page 39

B - square contour -arrows 1- and annular groove -arrow 2- = LuK version clutch


Exploded view - LuK version clutch ⇒ page 45

N30-10069

Protected by copyright. Copying for private or commercial purposes, in permitted unless authorised by AUDI AG. AUDI AG does not guarantee with respect to the correctness of information in this document. Cop

# Round contour -arrows 1- and annular groove -arrow 2- = LuK version clutch

Exploded view - LuK version clutch ⇒ page 45



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Exploded view - Sachs version clutch 7



#### Note

The dual-mass flywheel, pressure plate and clutch plate are matched together; components from another manufacturer must not be installed on the same vehicle.

#### 1 - Dual-mass flywheel

- □ Removing and installing ⇒ Rep. Ğr. 13
- Ensure that dowel pins fit tightly
- □ Contact surface for clutch lining must be free of grooves, oil and grease
- Observe instructions for removal ⇒ page 41

#### 2 - Clutch plate


- □ Removing and installing
- □ Always renew pressure plate as well
- ☐ Installation position ⇒ page 44
- □ For diameter of clutch plate, refer to ⇒ Electronic parts catalogue

#### 3 - Pressure plate

- With adjustment mechanism
- Identification ⇒ page 40
- Removing and installing
- Checking ends of diaphragm spring ⇒ page 40
- ☐ Checking springs and riveting <u>⇒ page 40</u>
- Checking wire ring or sheet-metal ring ⇒ page 41
- □ Always renew clutch plate as well
- ☐ For correct version, refer to ⇒ Electronic parts catalogue
- ☐ Contact surface for clutch lining must be free of grooves, oil and grease


#### 4 - Bolt

- ☐ M6 13 Nm
- ☐ M7 20 Nm
- □ Loosen and tighten bolts consecutively in steps of 90°



#### Identification of self-adjusting Sachs version clutch

 Pressure plate with stop mechanism (position sensor) -arrow-.




#### Checking ends of diaphragm spring

 Wear up to half the thickness of the diaphragm spring -arrows- is permissible.


Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Checking springs and riveting

- I Springs OK
- Slight kinking on the outside -arrows A- is normal on production parts.
- II Springs damaged
- Renew pressure plate if springs are broken or badly bent -arrow B-.




- Check that rivets -arrows B- are secure at all springs -arrows A-.
- Renew pressure plate if rivets -arrows B- are loose.



#### Checking wire ring or sheet-metal ring

- Check wire ring or sheet-metal ring -arrow- in pressure plate for damage.
- Renew pressure plate if wire ring or sheet-metal ring is broken.



#### Instructions for removing dual-mass flywheel



#### Note

Do not use an impact wrench or pneumatic wrench to remove bolts -B-: this would severely damage the dual-mass flywheel. The bolts must always be removed by hand.

- Rotate dual-mass flywheel -A- so that the bolts are aligned centrally behind the holes -arrows-.
- When removing the bolts, make sure that none of the bolt heads contacts the dual-mass flywheel, as this would damage the flywheel when the bolts are unscrewed further.


# A30-0102

#### 7.1 Removing and installing clutch (Sachs version)


#### Special tools and workshop equipment required

♦ Counterhold tool -3067-

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Centring mandrel -T10097-



Grease for clutch plate splines -G 000 100-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Removing

Gearbox removed ⇒ page 82.

To prevent the pressure plate from becoming distorted during removal (causes clutch grab when driving off), always adhere to the following procedure when unbolting the pressure plate:

- Apply counter-hold tool -3067- in order to loosen bolts.
- Working clockwise, loosen all six bolts consecutively in steps of 90° (¹/4 turn) until the pressure plate is released.
- Stop -2- with pin -1- should come loose when the bolts are slackened.
- If the stop does not come loose, push the pin towards the dualmass flywheel.
- Take off pressure plate and clutch plate.

#### Installing

Tightening torque ⇒ page 39

Installation is carried out in reverse sequence; note the following:




#### Note

- The dual-mass flywheel, pressure plate and clutch plate are matched together; components from another manufacturer must not be installed on the same vehicle.
- ◆ Always renew clutch plate and pressure plate together and select the correct parts according to engine code ⇒ Electronic parts catalogue.
- If the clutch has burnt out, thoroughly clean the gearbox housing in area of clutch and parts of the engine facing the gearbox in order to prevent odours.
- ♦ Clean input shaft splines and (in the case of a used clutch plate) the hub splines. Remove corrosion and apply only a very thin coating of grease -G 000 100- to the splines. Then move clutch plate backwards and forwards on input shaft until hub moves freely on shaft. It is important to remove excess grease.
- Clutch pressure plates have an anti-corrosion coating and are greased. With the exception of the friction surface for the clutch plate, the pressure plate must not be cleaned. Otherwise the service life of the clutch will be considerably reduced.
- Pressure plate contact surface and clutch plate lining must make full contact with flywheel. Only then insert bolts.
- ♦ Only blow out dual-mass flywheel with compressed air.
- ♦ The friction surface of the pressure plate and the dual-mass flywheel must be cleaned (degreased) thoroughly.
- Check that dowel sleeves for centralising engine/gearbox are in the cylinder block; install if necessary.
- ♦ If the dowel sleeves are not fitted, this will lead to gear-change

  Protected | Problems | Clutch malfunction and in some cases | gearbox


  permitted | noise | (gears will make rattling noises) | tee or accept any liability

  with respect to the correctness of information in this document. Convirint by AUDI AG.




#### Installation position of clutch plate

 Marking "Getriebeseite" (gearbox side) and the protruding spring cage face towards gearbox.




- Use counter-hold tool -3067- .
- Fit pressure plate onto dowel pins.
- Use centring mandrel -T10097- to centralise clutch plate.



To prevent the pressure plate from becoming distorted during installation (causes clutch grab when driving off), always adhere to the following procedure when installing the pressure plate:

- Make sure that the stop pin (position sensor) -arrow- is free to move.
- Screw in all 6 bolts evenly by hand until bolt heads make contact with pressure plate.
- Working clockwise, tighten all six bolts consecutively in steps of 90° (<sup>1</sup>/<sub>4</sub> turn) until the housing makes contact with the flywheel.
- The stop pin -arrow- should then lift away from the pressure plate.
- Working clockwise, tighten all 6 bolts to final torque consecutively. Tightening torque ⇒ Iteme4e(pagey39) Copying for private or commercial

permitted unless authorised by AUDI AG. AUDI AG does with respect to the correctness of information in this do



#### Exploded view - LuK version clutch 8



#### Note

The dual-mass flywheel, pressure plate and clutch plate are matched together; components from another manufacturer must not be installed on the same vehicle.

#### 1 - Dual-mass flywheel

- □ Removing and installing ⇒ Rep. Ğr. 13
- Ensure that dowel pins fit tightly
- □ Contact surface for clutch lining must be free of grooves, oil and grease
- Observe instructions for removal ⇒ page 47

#### 2 - Clutch plate


- □ Removing and installing ⇒ page 47
- □ Always renew SAC pressure plate as well
- ☐ Installation position: marking "Getriebeseite" (gearbox side) faces towards gearbox
- ☐ For diameter of clutch plate, refer to ⇒ Electronic parts catalogue

#### 3 - SAC pressure plate

- ☐ "SAC" = self adjusting clutch
- □ Always renew clutch plate as well
- Removing and installing ⇒ page 47
- Checking position of adjuster ring on new SAC pressure plate ⇒ page 49
- ☐ Checking ends of diaphragm spring ⇒ page 40 ☐ Checking spring connection and rivets ⇒ page 46
- □ Checking metal ring ⇒ page 46
- ☐ Contact surface for clutch lining must be free of grooves, oil and grease


#### 4 - Bolt

- ☐ M6 13 Nm
- ☐ M7 20 Nm
- □ Loosen and tighten bolts consecutively in steps of 90°




#### Checking ends of diaphragm spring

 Wear up to half the thickness of the diaphragm spring -arrows- is permissible.




#### Checking springs and riveting

- I Springs OK
- Slight kinking on the outside -arrows A- is normal on production parts.
- II Springs damaged
- Renew pressure plate if springs are broken or badly bent -arrow B-.




- Check that rivets -arrows B- are secure at all springs -arrows A-.
- Renew pressure plate if rivets -arrows B- are loose.

permitted unless authorised by AUDI AG. AUDI AG does not with respect to the correctness of information in this docum



#### Checking metal ring

- Check metal ring -arrow- in pressure plate for damage.
- · Renew pressure plate if metal ring is broken.




#### Instructions for removing dual-mass flywheel



#### Note

Do not use an impact wrench or pneumatic wrench to remove bolts -B-: this would severely damage the dual-mass flywheel. The bolts must always be removed by hand.

- Rotate dual-mass flywheel -A- so that the bolts are aligned centrally behind the holes -arrows-.
- When removing the bolts, make sure that none of the bolt heads contacts the dual-mass flywheel, as this would damage the flywheel when the bolts are unscrewed further.



#### 8.1 Removing and installing clutch (LuK version)


#### Special tools and workshop equipment required


Counterhold tool -3067-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Centring mandrel -T10097-





♦ Grease for clutch plate splines -G 000 100-

#### Removing

- Gearbox removed ⇒ page 82.
- Apply counter-hold tool -3067- in order to loosen bolts.

To prevent the pressure plate from becoming distorted during removal (causes clutch grab when driving off), always adhere to the following procedure when unbolting the pressure plate:

- Working clockwise, loosen all six bolts consecutively in steps of 90° (¹/4 turn) until the pressure plate is released.
- Take off pressure plate and clutch plate.

#### Installing

Tightening torque ⇒ page 45

Installation is carried out in reverse sequence; note the following:



#### Note


- The dual-mass flywheel, pressure plate and clutch plate are matched together; components from another manufacturer must not be installed on the same vehicle.
- ♦ Always renew clutch plate and pressure plate together and select the correct parts according to engine code ⇒ Electronic parts catalogue.
- ♦ Checking position of adjuster ring on new pressure plate ⇒ page 49
- ♦ If the clutch has burnt out, thoroughly clean the gearbox housing in area of clutch and parts of the engine facing the gearbox in order to prevent odours.
- ◆ Clean input shaft splines and (in the case of a used clutch plate) the hub splines. Remove corrosion and apply only a very thin coating of grease -G 000 100- to the splines. Then move clutch plate backwards and forwards on input shaft until hub moves freely on shaft. It is important to remove excess grease.
- ◆ Clutch pressure plates have an anti-corrosion coating and are greased. With the exception of the friction surface for the clutch plate, the pressure plate must not be cleaned. Otherwise the service life of the clutch will be considerably reduced to Copying for private or commercial purposes, in part or in whole, is not
- permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

  Pressure plate contact surface and clutch plate lining must the correctness of information in this document. Copyright by AUDI AG.
- make full contact with flywheel. Only then insert bolts.
   Only blow out dual-mass flywheel with compressed air.

in the cylinder block; install if necessary.


- ♦ The friction surface of the pressure plate and the dual-mass
- flywheel must be cleaned (degreased) thoroughly.

   Check that dowel sleeves for centralising engine/gearbox are
- If the dowel sleeves are not fitted, this will lead to gear-change problems, clutch malfunction and in some cases gearbox noise (gears will make rattling noises).




#### Checking position of adjustment mechanism (new SAC pressure plates only)

- The two edges -A- of the adjuster ring should be located between the two notches -arrows B-.
- If the adjuster ring is in a different position on a new pressure plate, the pressure plate and clutch plate must not be installed.
- The position of the adjuster ring can be outside the notches on used clutches.



#### Installation position of clutch plate:

The marking "Getriebeseite" (gearbox side) faces towards the gearbox




- Use counter-hold tool -3067-.
- Fit pressure plate onto dowel pins.
- Use centring mandrel -T10097- to centralise clutch plate.

To prevent the pressure plate from becoming distorted during installation (causes clutch grab when driving off), always adhere to the following procedure when installing the pressure plate:

- Screw in all 6 bolts evenly by hand until bolt heads make contact with pressure plate.
- Working clockwise, tighten all six bolts consecutively in steps of 90° (1/4 turn) until the housing makes contact with the flywheel.







### Controls, housing


#### Overview - selector mechanism

- ⇒ "2 Exploded view gear knob and covers", page 52
- ⇒ "2.1 Removing and installing gear knob with gear lever boot <u>', page 53</u>
- ⇒ "3 Exploded view gear lever and selector housing for vehicles with vehicle ID No. up to 8J-7-013000", page 55
- ⇒ "4 Exploded view gear lever and selector housing for vehicles with vehicle ID No. from 8J-7-013001 onwards",
- ⇒ "4.1 Dismantling and assembling selector mechanism", page 59
- ⇒ "5 Removing and installing selector mechanism", page 64
- ⇒ "6 Exploded view gear selector cable and gate selector cable up to model year 2007", page 68
- ⇒ "6.1 Exploded view gearbox selector lever and gate relay lever up to model year 2007", page 70
- ⇒ "6.2 Exploded view gear selector cable and gate selector cable from model year 2008 onwards", page 72
- ⇒ "6.3 Removing and installing gear selector cable and gate selector cable", page 77
- ♦ ⇒ "7 Adjusting selector mechanism", page 79
- -Arrow A- gear selection movement
- -Arrow B- gate selection movement



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- 1 Gear selector cable
- 2 Gate selector cable
- 3 Heat shield
  - Detach before removing selector mechanism
- 4 Gate relay lever
- 5 Gearbox selector lever





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### 2 Exploded view - gear knob and covers

## 1 - Gear knob with gear lever boot

- Cannot be separated from each other
- □ Renew together
- □ Removing and installing⇒ page 53
- □ Detaching from trim panel for centre console⇒ page 53
- Disconnecting from securing frame⇒ page 53

#### 2 - Clip

- Secures gear knob to gear lever
- Secure with hose clip pliers -V.A.G 1275-

# 3 - Trim panel for centre console

- Remove and install together with gear knob⇒ page 53
- Detaching from gear lever boot ⇒ page 53

#### 4 - Securing frame

- □ Detaching from trim panel for centre console ⇒ page 53
- Detaching from gear lever boot ⇒ page 53

#### 5 - Washer

□ 4x

#### 6 - Bolt


- □ 1.5 Nm
- □ 4x

#### 7 - Noise insulation plate

#### 8 - Noise insulation


#### 9 - Gear lever

□ Adjusting selector mechanism ⇒ page 79




#### Detaching trim panel for centre console and securing frame for gear lever boot

- Remove bolts -arrows-.
- Detach trim panel from securing frame



#### Detaching securing frame and gear lever boot

Carefully release tabs -arrows- and lift off securing frame -1from gear lever boot -2-.



#### Removing and installing gear knob with 2.1 gear lever boot



Note


The gear knob is removed together with the gear lever boot and the trim panel for the centre console.

#### Special tools and workshop equipment required

♦ Removal wedge -3409-



♦ Hose clip pliers -V.A.G 1275-



#### Removing

- Open ashtray.
- Carefully lever off trim panel from centre console -arrows-.



e, is not y liability AG.


Protected by copyright. C permitted unless authori with respect to the co

- Unplug electrical connector on trim panel.
- Pull trim panel -3- up and over gear knob.
- Open clip -1- and pull off gear knob -2- together with gear lever boot and trim panel -3-.
- Detach gear lever boot and trim panel for centre console -3-⇒ page 53 .

#### Installing

Installation is carried out in reverse sequence; note the following:

- Push gear knob onto gear lever until it contacts stop.
- Secure gear knob to gear lever with a new clip -1-, using hose clip pliers -V.A.G 1275- .




#### 3 Exploded view - gear lever and selector housing for vehicles with vehicle ID No. up to 8J-7-013000



#### Note

Lubricate all bearings and moving surfaces with grease -G 000 450 02-.



- 18 Spring
  - ☐ Installing ⇒ page 57
- 19 Gate selector lever
- 20 Bolt
  - □ 5 Nm
- 21 Gasket
  - □ Renew
- 22 Floor plate
  - Bend tabs open to remove
  - □ Renew

#### 23 - Gate selector cable

- □ Removing and installing ⇒ page 77
- Adjusting ⇒ page 79

#### 24 - Gear selector cable

- □ Removing and installing ⇒ page 77
- Adjusting ⇒ page 79

#### 25 - Securing clip

- ☐ Renew
- □ Removing ⇒ page 56

#### 26 - Nut

- □ 8 Nm
- □ 4x

#### 27 - Bearing bush


Only fits in one position

#### 28 - Securing clip

☐ Renew

#### Detaching securing clip for gear selector cable -A- and gate selector cable -B-


- Use screwdriver to lift tab -arrow 1- and lever off securing clip -arrow 2-.



Protected by copyright. Copying for private permitted unless authorised by AUDI AG. A with respect to the correctness of information

#### Removing and installing securing clip

- Hold gear lever -2- in position.
- Press spacer bush -3- in direction indicated -arrow-.
- Take off securing clip -1-.




#### Installing spring

- Insert arm -A- of spring in guide -1- from above.
- Pull down arm -B- of spring and insert it in the guide from be-



#### Note

The gate selector lever is removed to give a better illustration.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### 4 Exploded view - gear lever and selector housing for vehicles with vehicle ID No. from 8J-7-013001 onwards

#### Note

- Lubricate bearings and moving surfaces with grease -G 000 450 02-.
- Dismantling and assembling selector mechanism <del>→ page 59</del>

#### 1 - Floor plate

- ☐ Bend tabs open to remove
- Always renew

#### 2 - Gasket

□ Renew

#### 3 - Gear lever

☐ Can be removed and installed without removing gear lever guide ⇒ Item 15 (page 59)

#### 4 - Damping washer

□ Push onto gear lever as far as stop -arrow-

#### 5 - Retaining clip

- □ Take care not to damage selector cables when removing.
- □ Renew

#### 6 - Gate selector cable

- □ Lever off gate selector lever
- Press onto gate selector lever inside selector mechanism
- Installation position ⇒ page 50

#### 7 - Bush

#### 8 - Gear selector cable

- □ Lever off gear lever guide
- Press onto gear lever guide inside selector mechanism
- ☐ Installation position ⇒ page 50

#### 9 - Damper


#### 10 - Ball socket

- Will be damaged during removal
- □ Renew

#### 11 - Bush

#### 12 - Securing clip

□ Removing and installing ⇒ page 57





- 13 Spring
- 14 Bush
- 15 Gear lever guide
- 16 Nut
  - □ 4x
- M6 8 Nm
- M8 25 Nm

#### 17 - Gasket

- □ Between selector housing and floor
- □ Self-adhesive
- Self-adhesive
  Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not
  Glue onto selector housing mitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


#### 18 - Selector housing

- With spring and gate selector lever
- ☐ Spring and gate selector lever cannot be removed

#### 4.1 Dismantling and assembling selector mechanism


Special tools and workshop equipment required

♦ Thrust block -T10083-



#### Dismantling

- Remove selector mechanism ⇒ page 64
- Using a screwdriver, bend open tabs -arrows- on all sides of floor plate and remove floor plate.
- Remove gasket from selector housing.
- Remove gear selector cable and gate selector cable from selector housing <u>⇒ page 58</u>.





- Lift top spring arm -A- over tab on gate selector lever.
- Using a screwdriver, press lugs -arrows- on ball socket towards ball on gear lever guide; if necessary, break off lugs.



Protected by copyright. Copying for private or commercial purposes, in part or in whe permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept a

- Prise ball socket -A-out of selector housing together with gear lever guide and gear lever -B-.
- Then press ball socket off ball on gear lever guide and remove.







#### Note

- Note guides -A- when performing the following steps.
- They must not be allowed to break off.
- Swivel bottom spring arm -arrow 1- onto stop on shoulder of gate selector lever.




#### Caution


During the following steps, the bottom spring arm (-arrow 1-) can become dislodged and snap downwards off the shoulder of the gate selector lever.

- Pull gear lever guide upwards as far as stop and at the same time pull ball-head pin -arrow 2- out of gate selector lever.
- Press spring -arrow 1- carefully off the shoulder of the gate selector lever.

The spring arms will then compress "diagonally".




- Then turn gear lever guide in direction of -arrow 1-.
- The pin -arrow 2- should be positioned in the recess on the selector housing.
- Next, swivel gear lever guide out in direction of -arrow 3- together with gear lever.




#### Assembling selector mechanism


- Release spring arms -A- and -B-.
- Spring arms -A- and -B- must point in opposite directions. (Shown here with gear lever guide installed.)



- Insert gear lever guide into selector housing together with gear lever.
- Pin -arrow 1- should be positioned just inside recess on selector housing.
- Turn gear lever guide in direction of -arrow 2- until ball-head pin -A- is above recess on selector housing.



- Protected by copyright, Copying for private
- Position selector housing with gear leveriguide onto thrust AUDI AG. AU block -T10083- .
- The gear lever guide rests in the larger recess -arrow- in the thrust block -T10083-.
- The gear lever guide should protrude out of the selector housing as far as the stop.




- Insert arm -A- of spring in guide from above.
- Pull arm -B- of spring downwards and insert it next to the guide (towards ball head).




#### Note


For illustration purposes, only part of the gate selector lever is shown.

- Carefully take selector housing off thrust block -T10083- together with gear lever guide.
- Move gate selector lever rearwards as far as stop in direction of -arrow 1-.
- Grease ball-head pin.
- Press ball-head pin into gate selector lever -arrow 2-.
- Guides -A- and tabs -B- must not be damaged.







- Now insert gear lever guide (which is now fitted in selectorying for pri housing) into larger recess -arrow- in thrust plock in 19083 to AUDI A again.
- The gear lever guide should protrude out of the selector housing as far as the stop.



- Lift top spring arm -A- over pin on gate selector lever.
- Use a new ball socket -B-.
- Grease ball socket and ball of gear lever guide.
- Press ball socket onto ball of gear lever guide as far as stop.
- Remove selector housing from thrust block -T10083-.
- Press ball socket into selector housing in direction of -arrows-.



- All four lugs -arrows- must engage.
- Lift top spring arm -A- over pin on gate selector lever into guide.
- Insert bottom spring arm into guide.
- Fit gear lever, gear selector cable, gate selector cable and floor plate  $\Rightarrow$  page 58.
- Install selector mechanism ⇒ page 64.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

# 5 Removing and installing selector mechanism

#### Removing

- Remove gear knob together with trim panel for centre console
   ⇒ page 53.
- Remove centre console ⇒ Rep. Gr. 68.
- Remove noise insulation panels above selector mechanism.
- Remove nuts -arrows-.



- Remove air cleaner housing completely ⇒ Rep. Gr. 23 or ⇒ Rep. Gr. 24.
- Detach securing clip -1- for gear selector cable and pull cable off pin.


#### Metal gate relay lever:

 Detach securing clip -2- for gate selector cable from gate relay lever and pull cable off pin.

# 2 1 A34-0620

#### Plastic gate relay lever:

- To prevent damage to gate selector cable, cable end-piece must be detached from gate selector cable before removing relay lever.
- Pull locking mechanism forwards in direction of -arrow 1- onto stop and then turn to left in direction of -arrow 2- to lock.
- Then press gate relay lever forwards (in direction of -arrow 3-).
- Detach cable end-piece only when gate relay lever is removed ⇒ page 76.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Vehicles with 4-cylinder engine:

Remove two bolts and one flange nut -arrows- and detach cable support bracket from gearbox.




Protected by copyright. Copying for private or commercial purposes, in part or in permitted unless authorised by AUDI AG. AUDI AG does not guarantee or acce


Vehicles with V6 engine act to the correctness of information in this document. Copyright by


Remove three bolts -arrows- and detach cable support bracket from gearbox.

#### Continued for all vehicles:

- Remove propshaft ⇒ Rear final drive 02D, 0AV, 0BR and 0BY; Rep. Gr. 39 .
- Loosen fasteners -arrows- and detach heat shield towards rear of vehicle.
- Swing selector housing down and remove with selector cables.








#### Installing

Installation is carried out in reverse sequence; note the following:

 Install selector mechanism and tighten nuts -arrows-. Tightening torque <u>⇒ Item 16 (page 59)</u>




- Route cables -1- from selector mechanism -2- to gearbox as follows:
- The cables must run parallel and must not be crossed.
- The cables must be routed in the slot provided in heat shield -3-.



#### Note


The enlargement shows the heat shield from above.




The cables and heat shield are held in the correct positions by clip -A-.



Protected by copyright. Copying for private or commercial purposes, in part or permitted unless authorised by AUDI AG. AUDI AG does not guarantee or ac with respect to the correctness of information in this document. Copyright by



Attach cable support bracket to gearbox -arrows-. Tightening torque ⇒ page 68



- Spread a small amount of grease -G 000 450 02- onto pins -arrows- of gearbox selector lever -1- and, if necessary, gate relay lever -2-.
- If they are removed, always renew securing clip -3- and, on vehicles with metal gate relay lever, securing clip -4-.
- Fit gear selector cable and secure with securing clip -3-.

# Metal gate relay lever:

- Fit gate selector cable and secure with securing clip -4-.

# Plastic gate relay lever


Insert gate selector cable in cable end-piece.

# Continued for all vehicles:

- Adjust selector mechanism ⇒ page 79.
- Install propshaft ⇒ Rear final drive 02D, 0AV, 0BR and 0BY; Rep. Gr. 39.
- Fit noise insulation above selector mechanism and install centre console ⇒ Rep. Gr. 68.
- Install gear knob together with boot <u>⇒ page 53</u>.
- Install air cleaner housing ⇒ Rep. Gr. 23 or ⇒ Rep. Gr. 24.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



# Exploded view - gear selector cable and gate selector cable up to 6 model year 2007



# Note

Lubricate all bearings and moving surfaces with grease -G 000 450 02-

# 1 - Securing clip

# 2 - Cable end-piece

- Secures gate selector cable to gate relay lever
- □ Allocation ⇒ page 69
- Release to adjust selector mechanism ⇒ page 80

# 3 - Securing clip

# 4 - Cable end-piece

- Secures gear selector cable to gearbox selector lever
- □ Allocation ⇒ page 69
- □ Release to adjust selector mechanism ⇒ page 80

# 5 - Bush

# 6 - Grommet

# 7 - Gear selector cable

- Removing and installing <u>⇒ page 77</u>
- ☐ From vehicle ID No. 8J-7-013001 onwards: modified attachment on gear lever inside selector mechanism ⇒ Item 8 (page 58)
- Adjusting ⇒ page 79

# 8 - Securing clips

□ Discontinued for vehicle ID No. 8J-7-013001 onwards <u>⇒ page 58</u>


# 9 - Retaining clips

# 10 - Gate selector cable

- □ Removing and installing ⇒ page 77
- ☐ From vehicle ID No. 8J-7-013001 onwards: modified attachment on gate selector lever inside selector mechanism ⇒ Item 6 (page 58)
- Adjusting ⇒ page 79

# 11 - Bolt

- □ 20 Nm
- ☐ 2x on vehicles with 4-cylinder engine
- ☐ 3x on vehicles with 6-cylinder engine



# 12 - Cable support bracket


# 13 - Nut

- □ 20 Nm
- ☐ Only on vehicles with 4-cylinder engine

# Identification of cable end-pieces

The holes in the cable end-pieces have different diameters.


Cable end-piece for:	Dimension "a"
1 Gear selector cable to gearbox selector lever from 06.06 onwards	8.5 mm
2 Gear selector cable to gearbox selector lever up to 05.06	10 mm
2 Gate selector cable to metal gate relay lever	8 mm



# From 06.06 onwards: smaller diameter of mounting pin for cable end-piece (on gear selector cable)

Mounting pin for cable end-piece (on gear selector cable)	Dimension "a"
Up to 05.06	10 mm
From 06.06 onwards	8.5 mm

Protected by copyright. Copying for private or commerce permitted unless authorised by AUDI AG. AUDI AG doe with respect to the correctness of information in this



# 6.1 Exploded view - gearbox selector lever and gate relay lever up to model vear 2007



# Note

Lubricate all bearings and moving surfaces with grease -G 000 450 02- .

# 1 - Selector mechanism cover

Removing and installing (with gearbox installed) ⇒ page 203

# 2 - Selector shaft

- □ Removing and installing (with gearbox installed)
- 3 Bush

# 4 - Securing clip

□ Removing ⇒ page 71

# 5 - Oil seal

□ Renewing ⇒ page 201

# 6 - Securing clip

# 7 - Cable end-piece

- Secures gear selector cable to gearbox selector lever
  - ⇒ Item 4 (page 68)
- □ Allocation ⇒ page 69

# 8 - Nut

- □ 23 Nm
- Self-locking
- □ Renew

# 9 - Gearbox selector lever

- With damper weight
- ☐ Install so that gap in splines aligns with selector shaft ⇒ page 71
- Installation position ⇒ page 71
- ☐ Different diameters of mounting pin for cable end-piece ⇒ page 69


# 10 - Securing clip

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not 11 - Cable end-piece permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

- Secures gate selector cable to gate relay lever ⇒ Item 2 (page 68)
- □ Allocation ⇒ page 69
- ☐ Release to adjust selector mechanism ⇒ page 80

# 12 - Gate relay lever

□ Installation position ⇒ page 71




14 - Bush

15 - Angled rod

☐ For adjusting selector mechanism ⇒ page 79

# Removing securing clip for gate relay lever

Lift clip -arrow-.




# Installing gearbox selector lever

When installing gearbox selector lever, make sure that the gap in the splines -arrow A- aligns with the wider spline -arrow Bon the selector shaft.




Protected by copyright. Copying for private or commercial purposes, in part of permitted unless authorised by AUDI AG. AUDI AG does not guarantee or a with respect to the correctness of information in this document. Copyright



# Installation position: gearbox selector lever/gate relay lever

- 1 Gearbox selector lever with damper weight
- 2 Gate relay lever locates in guide rail of gearbox selector lever via slide block -arrow-.
- Coat guide rail and slide block -arrow- with grease -G 000 450 02- .



# 6.2 Exploded view - gear selector cable and gate selector cable from model year 2008 onwards



# Note

Lubricate all bearings and moving surfaces with grease -G 000 450 02-.

# 1 - Gearbox

# 2 - Clip

- Not fitted on all versions
- ☐ For gate relay lever from 08.2008 onwards
- Detaching and fitting⇒ page 76

# 3 - Gearbox selector lever

- ☐ Fitting ⇒ page 74
- ☐ Installation position ⇒ page 74
- After installing, adjust selector mechanism⇒ page 79

# 4 - Cable end-piece

- Secures gear selector cable to gearbox selector lever
- Allocation ⇒ page 73
- Detaching from gear selector cable⇒ page 74

# 5 - Securing clip

- □ Removing ⇒ page 75
- Renew

# 6 - Nut

- □ Self-locking
- ☐ Renew
- □ 23 Nm

# 7 - Retaining clip

☐ Renew

# 8 - Gear selector cable

- □ Detaching and securing at gearbox selector lever ⇒ page 75
- ☐ Removing and installing ⇒ page 77
- Adjusting ⇒ page 79


# 9 - Gate selector cable

- □ Removing and installing ⇒ page 77
- Adjusting ⇒ page 79

# 10 - Selector housing

# 11 - Retaining clips

☐ Renew



# 12 - Retaining clip

□ Renew

# 13 - Cable support bracket

# 14 - Bolt

- □ 20 Nm
- ☐ 2x on vehicles with 4-cylinder engine
- ☐ 3x on vehicles with 6-cylinder engine

# 15 - Grommet

# 16 - Bush

# 17 - Nut

- □ 20 Nm
- ☐ Only on vehicles with 4-cylinder engine

# 18 - Gate relay lever

- Made of plastic
- ☐ Different versions available; for correct version refer to ⇒ Electronic parts catalogue
- □ Installation position ⇒ page 74
- ☐ Detaching and securing gate relay lever (with detent catch) at gearbox selector lever ⇒ page 75
- □ Detaching and securing gate relay lever (with clip) at gearbox selector lever ⇒ page 76

# 19 - Slide block

permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

☐ Installation position ⇒ page 74

# 20 - Cable end-piece

- Secures gate selector cable to gate relay lever
- □ Allocation ⇒ page 69
- □ Detaching from gate selector cable ⇒ page 74


# 21 - Angled rod

☐ For adjusting selector mechanism ⇒ page 79

# Identification of cable end-pieces


The holes in the cable end-pieces have different diameters.

Cable end-piece for:	Dimension "a"
-1- Gear selector cable to gearbox selector lever	8.5 mm
-2- Gate selector cable to gate relay lever	10 mm




# Installing gearbox selector lever

 When installing gearbox selector lever, make sure that the gap in the splines -arrow A- aligns with the wider spline -arrow Bon the selector shaft.




# Installation position: gearbox selector lever/gate relay lever

- 1 Gearbox selector lever
- 2 Clip or detent catch (depending on version)
- 3 Gate relay lever locates in guide rail of gearbox selector lever via slide block -arrow B-.
- Coat guide rail and slide block -arrow- with grease G 000 450 Copyir 02-.
   with respect to the corrector



# Detaching cable end-pieces from gear selector cable and gate selector cable

- Pull locking mechanism forwards -arrow 1- onto stop and then turn to left -arrow 2- to lock.
- Take cable -B- out of cable end-piece -A-.



# Detaching and securing gear selector cable at gearbox selector lever

# Detaching

- Lift up tab and detach securing clip -3- for gear selector cable from gearbox selector lever -1-.
- Pull gear selector cable -2- off pin -arrow-.

# Securing



Note

Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AG doe with respect to the correctness of information in this

- Renew securing clip for gear selector cable.
- Apply a small quantity of grease -G 000 450 02- to the pin -arrow-.
- Push gear selector cable -2- onto gearbox selector lever -1and secure with securing clip -3-.

# Detaching and securing gate relay lever (with detent catch) at gearbox selector lever -arrow 1-

# Detaching

Press in detent -arrow 1- as far as stop and remove gate relay lever together with cable end-piece (move relay lever in normal direction of operation).



Note


-Arrow 2- can be disregarded.


# Securing



To install, lubricate bearings and moving surfaces with grease -G 000 450 02-.

- Press cable end-piece onto gate relay lever ⇒ page 76.
- Insert gate relay lever with cable end-piece as far as stop.
- Gate relay lever is secured by detent -arrow 1-.
- Cable end-piece is secured by detent -arrow 2-.
- Ensure that components engage securely.





# Detaching and securing gate relay lever (with clip) at gearbox selector lever -arrow 1-

# Detaching

Remove clip -arrow 1- and take off gate relay lever together with cable end-piece.

# Securing



# Note

Lubricate all bearings and moving surfaces with grease -G 000 450 02-.

- Insert gate relay lever with cable end-piece as far as stop.
- Press on clip -arrow 1-, making sure it engages securely.





# Note

-Arrow 2- can be disregarded.

# Levering cable end-piece for gate selector cable off gate relay


- Gate relay lever removed
- Apply plain slot screwdriver -A- between bush -B- and gate relay lever.





# Pressing cable end-piece for gate selector cable onto gate relay lever

- Gate relay lever removed
- Press on cable end-piece only at bush -arrow-.
- Cable end-piece must move freely on gate relay lever.
- Cable end-piece must be behind detent.
- Ensure that components engage securely.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

# 6.3 Removing and installing gear selector cable and gate selector cable

# Removing

- Remove selector mechanism ⇒ page 64.
- Using a screwdriver, bend open tabs -arrows- for selector mechanism on floor plate and remove floor plate.
- Remove gasket.



# Vehicles with vehicle ID No. up to 8J-7-013000:

- Detach securing clips -1- and -4- and pull both cables off pins.


# Vehicles with vehicle ID No. from 8J-7-013001 onwards:

- Prise gear selector cable and gate selector cable off pins.

# Continued for all vehicles:


Take off securing clips -2 ... 3- and detach gear selector cable and gate selector cable from selector housing. Copying for private or commo rised by AUDI AG. AUDI AG


with respect to the correctness of information in th



Release cable end-pieces -A- for gate selector cable and gear selector cable -B- as follows:

- Push sleeve forwards onto stop -arrow 1-.
- Turn sleeve clockwise onto stop -arrow 2- so that it engages.
- Detach cable end-pieces from cables.
- Pull off securing clips -1- and -2-.
- Detach cable support bracket from cables.





# Installing

Installation is carried out in reverse sequence; note the following:

 Secure gear selector cable and gate selector cable to selector housing with securing clips -1 ... 4-.


# Vehicles with vehicle ID No. from 8J-7-013001 onwards:

Press gear selector cable and gate selector cable onto pins.

# 3 1 A34-0586

# Continued for all vehicles:


- Fit new gasket and secure new floor plate to selector mechanism by bending over tabs -arrows-.
- Install selector mechanism ⇒ page 64.
- Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not pAdjustrselectorsmechanism. Phage 19 guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



## 7 Adjusting selector mechanism

# Special tools and workshop equipment required

♦ Locking pin -T10027 A-



# Requirements for adjustment

- Gear selector linkage must be in proper condition and undamaged.
- Selector mechanism must move freely.
- Gearbox, clutch and clutch mechanism must be in proper condition.
- Gearbox in neutral.

# Adjusting

- Open ashtray.
- Carefully lever off trim panel from centre console -arrows-.
- Pull trim panel up and over gear knob.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any lia with respect to the correctness of information in this document. Copyright by AUDI AG

- With gearbox in neutral, guide gear lever to the left into 1st/ 2nd gear gate.
- Lift noise insulation plate.
- Then guide locking pin -T10027A- through hole -A- and into hole -B-.



# Note

The noise insulation panels are removed to give a better illustration.

Remove air cleaner housing completely ⇒ Rep. Gr. 23 or ⇒ Rep. Gr. 24.

Release cable end-pieces -A- for gate selector cable and gear selector cable -B- as follows:

- Push sleeve forwards onto stop -arrow 1-.
- Turn sleeve clockwise onto stop -arrow 2- so that it engages.



# Note

It should be possible to move selector cable -B- in the cable endpiece.

Gearbox in neutral.


Lock the selector shaft as follows:


- Press down gearbox selector lever -1- in direction of arrow
- At the same time press and turn angled rod -2- in direction of arrow -B- and -C- until it engages.


The selector shaft is then locked and can no longer be moved.


- Check that gate selector cable and gear selector cable -B- are located in cable end-pieces -A- without tension.
- Release locking sleeve -arrow 1-.
- Allow locking sleeve to slide onto stop -arrow 2-.

Cable adjustment is now complete.










- Turn angled rod -A- back to initial position in direction of -arrow 2- and pull out of gearbox in direction of -arrow 1-.
- Pull locking pin -T10027 A- out of selector mechanism.

# Checking gear lever setting

- With the gearbox in neutral, the gear lever should rest in the 3rd/4th gear gate.
- Depress clutch.
- Select all gears several times. Pay particular attention to the operation of the reverse gear locking mechanism.
- The gear lever should return by itself from the reverse gear gate to the 3rd/4th gear gate.

If the gear lever sticks or baulks repeatedly when engaging a gear, perform the adjustment procedure again.

- Fit cover and trim panel for centre console.
- Install air cleaner housing ⇒ Rep. Gr. 23 or ⇒ Rep. Gr. 24.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

# 8 Removing and installing gearbox


# General view

- ♦ <u>\*\*8.1 Removing gearbox vehicles with 2.0 ltr. TFSI engine", page 82</u>
- ♦ \*\*8.2 Removing gearbox vehicles with 3.2 ltr. MPI engine"
  page 93.
- \* "8.3 Removing gearbox vehicles with 2.0 ltr. TDI engine", page 106
  Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability


# 8.1 Removing gearbox - vehicles with 2.0 ltr. TFSI engine

# Special tools and workshop equipment required


- Support bracket -10 222
   A-
- ◆ Hose clamps, up to Ø 25 mm -3094-
- ♦ Gearbox support -3282-
- ♦ Adapter -VW 771/40-
- Engine and gearbox jack -V.A.G 1383 A-



♦ Pin -3282/29-



◆ Adjustment plate -3282/33-



- ♦ Bolt M10x20
- Grease -G 000 450 02-
- ◆ Grease for clutch plate splines -G 000 100-

# **Procedure**



# Caution


-arrow- ⇒ Rep. Gr. 27.


When disconnecting the battery there is a risk of serious damage to electronic components:

Observe the correct procedure for disconnecting the bat-


Protected by copyright. Copying for private or With ignition switched off, disconnect battery learth cable, AUDI AG. AU

Remove engine cover panel -arrows-.






- Remove air cleaner housing completely ⇒ Rep. Gr. 24.
- Remove bolts -arrows- and detach bracket for air cleaner housing.



Detach securing clip -1- and pull cable end-piece off pin.

# Metal gate relay lever:

Detach securing clip -2- and pull cable end-piece off gate relay



Protected by copyri


any liability


# Plastic gate relay lever:

- To prevent damage to gate selector cable, cable end-piece must be detached from gate selector cable before removing relay lever.
- Pull locking mechanism forwards in direction of -arrow 1- onto stop and then turn to left in direction of -arrow 2- to lock.
- Then press gate relay lever forwards (in direction of -arrow 3-).
- Detach cable end-piece only when gate relay lever is removed ⇒ page 76 .


# Continued for all vehicles:

Detach cable support bracket from gearbox -arrows-; then move to one side and tie up together with selector cables.






Unscrew top engine/gearbox securing bolts -arrows-.




- Remove the two top bolts on radiator cowl -top arrows-.




- Set up support bracket -10 222 A- together with racks -10 -222 A /1- on wing mounting flanges.
- Engage hook of spindle -10 222 A /11- in engine lifting eye (left-side).
- Partly take up weight of engine with spindle, but do not lift.


Protected by copyright. Copying for private or commercial purpose permitted unless authorised by AUDI AG. AUDI AG does not gua with respect to the correctness of information in this document




- With vehicle still standing on its wheels, slacken off front left flange bolt -2- 90° (maximum). Do not slacken further, as this would damage the wheel bearing.
- Remove both front wheels.




Remove noise insulation panels -1- and -2-  $\Rightarrow$  Rep. Gr. 66.




Remove noise insulation (left and right) -arrows-.



Unscrew bolt -2- and disconnect air duct for gearbox cooling -1- (-arrow-).



Protected by copyright. Copying for private Remove noise insulation frame -arrow=septiteReps Graths50 d by AUDI AG. A with respect to the correctness of information of the correctness of the correctness




- Release retainers -arrows A- using a screwdriver.
- Detach air intake grille -1- (left-side) from bumper cover in direction of -arrow B-.




- Open flap -2- -arrow- and remove bolt -1-.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





- Remove nut -1- and detach bracket from stud together with electrical wiring.
- Move bracket and wiring clear to the side.
- Remove bottom bolt securing starter -1-.














- 2 1 A21-10061
- Detachellectrical connector provide or commercial purposes, in part or in whole, is not
  permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability
- Remove remaining bolts bottom arrows and take out radiator account from below.




- Remove nuts -arrows-.
- Detach catalytic converter from turbocharger and secure catalytic converter to prevent it from falling.




# Note


-Item 1- and -item 2- can be disregarded.




- Unbolt heat shield for drive shaft (right-side) from bevel box -arrows-.
- Unbolt drive shaft (left-side) from flange shaft on gearbox.
- Unbolt drive shaft (right-side) from flange shaft on bevel box.



Slacken bolts -1- and remove bolts -2-.



- Mark position of flexible coupling and bevel box flange in relation to one another.
- Unbolt propshaft with flexible coupling from bevel box -arrows- (counterhold triangular flange with suitable lever).




Push engine/gearbox assembly forward slightly (towards front end) and then pull propshaft off bevel box.



# Caution

The seal -arrow- in the propshaft flange can be damaged.

 Push propshaft towards the rear and to the right as far as possible.





# Note

If seal is damaged propshaft must be renewed.


If a plastic pipe is installed between clutch master cylinder and slave cylinder, clamp off supply hose to clutch master cylinder using hose clamp up to 25 mm -3094- .



# Note

Protected by copyright. Copying for private or comme permitted unless authorised by AUDI AG. AUDI AG de with respect to the correctness of information in the

- In the following steps make sure that no brake fluid escapes onto the starter or onto the gearbox below. If this does happen, clean the affected area thoroughly.
- Seal off open lines and connections with clean plugs or sealing caps to prevent dirt from entering.




If a pipe/hose assembly is installed between clutch master cylinder and slave cylinder, clamp off hose -A- using hose clamp up to 25 mm -3094- .



# Note

-Arrow- can be disregarded.




- Pull clip -arrow- out as far as stop.
- Pull plastic pipe or pipe/hose assembly -A- out of bleeder connection for clutch slave cylinder and seal end of pipe.



# Caution


Do not operate clutch pedal after disconnecting pipe/hose assembly.


- Remove nut -B-.
- Detach earth cable and remove top securing bolt for starter.
- Place starter to side onto longitudinal member.
- Remove bolts on gearbox mounting -arrows-.




Protected by copyright. Copying for private or commercial purposes, in part permitted unless authorised by AUDI AG. AUDI AG does not guarantee or with respect to the correctness of information in this document. Copyrigh

- By adjusting spindles on support bracket -10 222 A-, lower gearbox by distance -a-.
- Dimension -a- = 60 mm.







Unbolt gearbox bracket from gearbox -arrows-.



# N34-10012





# Metal gate relay lever -1-:

- Pull off securing clip -arrow- and remove gate relay lever -1-. Plastic gate relay lever -1-:
- Removing gate relay lever (with detent catch) ⇒ page 75
- Removing gate relay lever (with clip) ⇒ page 75

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

# Continued for all vehicles:

Remove flange bolt -2- and detach drive shaft (left-side) -1-.



# Note


The wheel bearing must not be subjected to load after the bolt -2- securing the drive shaft has been slackened.

- Remove engine/gearbox connecting bolts (bottom) -4- and -5-.
- Leave connecting bolt -3- screwed in.


To remove gearbox "02Q" set up gearbox support -3282- with adjustment plate -3282/33-.

- Insert gearbox support -3282- in engine and gearbox jack -V.A.G 1383 A- .
- Align arms of gearbox support according to holes in adjustment plate.

- Bolt on support elements -A-, as illustrated on adjustment plate.
- Screw in pin -3282/29- instead of support element -C-.
- Place engine and gearbox jack -V.A.G 1383 A- under vehicle; arrow symbol -B- on adjustment plate points to front of vehicle.
- Align adjustment plate and gearbox parallel to one another.





- Secure adapter -VW 771/40- in tapped hole of gearbox housing, as shown in illustration.
- Screw pin -3282/29- into hole for bolt securing pendulum support to gearbox.
- Secure gearbox to gearbox support -3282- with bolt M10x20 -item A-.
- Make sure pin -B- is flush at bottom with guide of gearbox support -3282- -arrow-.
- Unscrew last engine/gearbox securing bolt -C-.



Now remove bracket -A- for bevel box.
Protected by copyright. Copying for private of the copyright copyright.

permitted unless authorised by AUDI AG. AL with respect to the correctness of inform






Turn gearbox upwards at differential end. Guide output flange -C- on gearbox past propshaft -A- and front exhaust pipe -B-. Rotate output flange if necessary.



# Note


Also pay attention to area between bevel box and intermediate plate on engine.

- Then tilt gearbox to the left by turning spindles of gearbox support -3282- .
- Guide gearbox past suspension bracket for wishbone, then push gearbox forwards slightly and lower out carefully.




# Special tools and workshop equipment required

- ♦ Support bracket -10 222
- Hooks -10 222 A /10-
- Hose clamps, up to Ø 25 mm -3094-
- ♦ Gearbox support -3282-
- Pin -3282/29-
- Adjustment plate -3282/33-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- Engine and gearbox jack V.A.G 1383 A-
- Engine support bracket, basic set -T40091-
- Engine support bracket, supplementary set -T40093-




permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Adapter -VW 771/40-



Bracket -T10338-



- ♦ Bolt M10x20
- ♦ Grease -G 000 450 02-
- ♦ Grease for clutch plate splines -G 000 100-
- ♦ Universal grease -G 052 735-

# **Procedure**



# Note


- ♦ Observe general repair instructions ⇒ page 7.
- All cable ties which are released or cut projected by copyright. Copyring for private or commercial purposes, in part or in whole, is not must be fitted in the same position when installing the correctness of information in this document. Copyright by AUDI AG.




# Caution

When disconnecting the battery there is a risk of serious damage to electronic components:

- Observe the correct procedure for disconnecting the bat-
- With ignition switched off, disconnect battery earth cable -arrow- ⇒ Rep. Gr. 27.
- Remove air cleaner housing completely ⇒ Rep. Gr. 24.




- Detach line -1- from air cleaner bracket -2-.
- Remove bolts -arrows- and remove air cleaner bracket.
- Detach securing clip -3- for gear selector cable from gearbox selector lever -1- and pull cable off pin -arrow-.



- Detach securing clip -arrow 1- and pull cable end-piece off pin.


# Metal gate relay lever:

Detach securing clip -2- and pull cable end-piece off pin gate relay lever.




# Plastic gate relay lever:

- To prevent damage to gate selector cable, cable end-piece must be detached from gate selector cable before removing relay lever.
- Pull locking mechanism forwards in direction of -arrow 1- onto stop and then turn to left in direction of -arrow 2- to lock.
- Then press gate relay lever forwards (in direction of -arrow 3-).
- Detach cable end-piece only when gate relay lever is removed ⇒ page 776 and y copyrights copyring to private or some page 776 and permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liab with respect to the correctness of information in this document. Copyright by AUDI AG.



# Continued for all vehicles:

Detach cable support bracket from gearbox -arrows-; then move to one side and tie up together with selector cables.



If a plastic pipe is installed between clutch master cylinder and slave cylinder, clamp off supply hose to clutch master cylinder using hose clamp -3094- .



# Note

- In the following steps make sure that no brake fluid escapes onto the starter or onto the gearbox below. If this does happen, clean the affected area thoroughly.
- Seal off open lines and connections with clean plugs or sealing caps to prevent dirt from entering.
- If a pipe/hose assembly is installed between clutch master cylinder and slave cylinder, clamp off hose -A- using hose clamp -3094- .



# Note

-Arrow- can be disregarded.

Protected by copyright. Copying for private or commercial purposes, in pa permitted unless authorised by AUDI AG. AUDI AG does not guarantee of with respect to the correctness of information in this document. Copyr

- Pull clip -arrow- out as far as stop.
- Pull plastic pipe or pipe/hose assembly -A- out of bleeder connection for clutch slave cylinder and seal end of pipe.



# Note


-Item B- can be disregarded.





# Caution


Do not operate clutch pedal after disconnecting pipe/hose assembly.


- Unplug electrical connector -1- for reversing light switch -F4-.
- Unscrew earth wire -2-.
- Then remove upper securing bolt from starter located below earth wire -2-.
- Unplug electrical connector -3-.
- Push cover -4- to rear.













- Unscrew top engine/gearbox securing bolts -arrows-.



 Secure bracket -T10338- to vacant tapped hole at rear left of engine.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


- Set up support bracket -10 222 A- on wing mounting flanges using the following equipment:
- ♦ Rack -10 222 A /1- (2x)
- Hook -10 222 A /10- (spindle faces towards rear)
- Spindle -10 222 A /11- (spindle faces towards front)
- Shackle -10 222 A /12-
- Connecting piece -T40091/3- (2x)
- Hook spindle -10 222 A /11- with shackle -10 222 A /12onto engine lifting eye (right-side).
- Attach hook -10 222 A /10- to bracket -T10338- .
- Partly take up weight of engine/gearbox assembly via the spindles.
- ProtectAls emble supports 1740093/3-(2x) with ladapters ole, is not with T40093/3-2- for left side and -T40093/3-3- for right side.
- Disconnect earth wire from longitudinal member (left-side).
- Remove securing bolt for front section of longitudinal member on left and right.
- Bolt adapter -T40093/3-2- (left-side) and -T40093/3-3- (rightside) to longitudinal members -arrow-, using the bolts removed previously.





# Note

Illustration shows left side of vehicle.

Insert square bars -T40091/1- into connecting pieces -T40091/3- and supports -T40093/3- as illustrated.







- Fit connecting pieces -T40093/4- onto square bars.
- Insert support -T40091/2- with slide -T40093/5- into the two connecting pieces -T40093/4-.



# WARNING

Accidents can be caused if parts of the support bracket are not correctly secured.


- Secure support -T40091/2- using retaining pins and split pins of the connecting pieces -T40093/4- .
- Secure connecting pieces and supports using clamping bolts.
- Attach spindle -10 222 A /11- to slide and engine lifting eye.
- Take up weight of engine/gearbox assembly by tightening the 3 spindles evenly.
- Remove both front wheels.
- Release fasteners -1 ... 4- and remove centre noise insulation.




A10-10600


Protected by copyright. Copying for private or commercial purposes, in part of permitted unless authorised by AUDI AG. AUDI AG does not guarantee or a

Remove noise insulation (left and right) -arrows-.




Remove noise insulation frame -arrow- ⇒ Rep. Gr. 50.






- Remove nut -3- and detach bracket -2- for wiring harness.
- Remove starter securing bolt -1- and detach starter.




- Unplug electrical connector -1- at oil level and oil temperature sender -G266- .
- Unclip bracket -2- for electrical wiring leading to oil level and oil temperature sender -G266- at subframe.






- Remove bolts -arrows- for exhaust pipe bracket.



- Remove bolts -2- and -3-.
- Fix position of subframe to avoid unnecessary wheel alignment ⇒ Rep. Gr. 40.
- Remove subframe  $\Rightarrow$  Rep. Gr. 40.




- Unbolt heat shield for drive shaft (right-side) from bevel box -arrows-.
- Unbolt drive shaft (left-side) from flange shaft on gearbox.
- Unbolt drive shaft (right-side) from flange shaft on bevel box.
- Tie up drive shafts with cable ties.




# Note


Make sure you do not damage surface coating on drive shafts.

Remove bolts -arrows- and detach bracket for bevel box.





- Mark position of flexible coupling and bevel box flange in relation to one another.
- Unbolt propshaft with flexible coupling from bevel box -arrows- (counterhold triangular flange with suitable lever).



Protected by copyright. Copying for private or commercial purpos


Push engine/gearbox assembly forward slightly (towards front guar end) and then pull propshaft off bevel box.



# Caution

The seal -arrow- in the propshaft flange can be damaged.

Push propshaft towards the rear and to the right as far as possible.






# Note


If seal is damaged propshaft must be renewed.

Tie up propshaft.


Remove bolt -arrow- from above bevel box.




- Remove bolts -arrows- on gearbox mounting.




with respect to the correctn By adjusting spindles on support bracket -10 - 222 A- , lower gearbox by distance -a-.





- Unbolt gearbox bracket from gearbox -arrows-.




#### Metal gate relay lever -1-:

- Pull off securing clip -arrow- and remove gate relay lever -1-.


#### Plastic gate relay lever -1-:

- Removing gate relay lever (with detent catch) ⇒ page 75
- Removing gate relay lever (with clip) <u>⇒ page 75</u>




#### Continued for all vehicles:

 Remove engine/gearbox connecting bolt -arrow- (on engine side).




 Unscrew engine/gearbox securing bolt -arrow- located next to bevel box -C-.

Note: retaining clip -A- securing bolt -arrow- is fitted in sump -B-.




To remove gearbox "02Q" set up gearbox support -3282- with adjustment plate -3282/33- .


- Insert gearbox support -3282- in engine and gearbox jack -V.A.G 1383 A- .
- Align arms of gearbox support according to holes in adjustment plate.
- Bolt on support elements -A-, as illustrated on adjustment plate .
- Screw in pin -3282/29gdinstead of support element of tal purposes, in part
   permitted unless authorised by AUDI AG does not guarantee or
- Place engine and gearbox: jack-t/r.A.G.1383r.A.: under vehicle; copyright arrow symbol -B- on adjustment plate points to front of vehicle.
- Align adjustment plate and gearbox parallel to one another.
- Screw pin -3282/29- into hole for bolt securing pendulum support to gearbox.



- Secure adapter -VW 771/40- in tapped hole of gearbox housing, as shown in illustration.
- Secure gearbox to gearbox support -3282- with bolt M10x20 -item A-.



Unscrew last engine/gearbox securing bolts at bottom -1 ... 3-.



Separate gearbox from engine and pivot upwards at differential end. Guide output flange -C- on gearbox past propshaft -A- and front exhaust pipe -B-. Rotate output flange if neces-



#### Note

Also pay attention to area between bevel box and intermediate plate on engine.

- Press gearbox off dowel sleeves.
- Carefully lower gearbox.



#### Note

When lowering gearbox make sure the electromechanical power steering is not damaged.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

E N34-10706


#### 8.3 Removing gearbox - vehicles with 2.0 ltr. TDI engine

#### Special tools and workshop equipment required


- Support bracket -10 222
- Hose clamps, up to Ø 25 mm -3094-
- Gearbox support -3282-
- Adapter -VW 771/40-
- Engine and gearbox jack V.A.G 1383 A-



Pin -3282/29-



◆ Adjustment plate -3282/33-



- ♦ Bolt M10x20
- ♦ Grease -G 000 450 02-
- ♦ Grease for clutch plate splines -G 000 100-
- ♦ Universal grease -G 052 735-

#### **Procedure**




#### Caution


When disconnecting the battery there is a risk of serious damage to electronic components:


- Observe the correct procedure for disconnecting the bat-
- With ignition switched off, disconnect battery earth cable -arrow- ⇒ Rep. Gr. 27 .
- Remove engine cover panel -arrows-.
- Remove air cleaner housing ⇒ Rep. Gr. 23.
- Drain coolant ⇒ Rep. Gr. 19.
- Remove starter  $\Rightarrow$  Rep. Gr. 27.
- Remove radiator cowl ⇒ Rep. Gr. 19.

Protected by copyright. Copying for private or cor permitted unless authorised by AUDI AG. AUDI A with respect to the correctness of information


Remove bolts -arrows- and detach bracket for air cleaner housing.







- Press release tabs and disconnect crankcase breather hose -1- from cylinder head cover.
- Move clear vacuum hoses -arrows- at air pipe.
- Release hose clip -2- and detach air pipe.




Lift retaining clips -arrows- and disconnect coolant hoses from heat exchanger.



#### Note

Place a cloth underneath heat exchanger to catch escaping cool at any permitted unless authorised by AUDI AG. AUD ant. with respect to the correctness of information




Remove bolts -arrows- at air pipe.



# Note


-Items 1 ... 5- can be disregarded.



Detach securing clip -arrow 1- and pull cable end-piece off pin.

#### Metal gate relay lever:

Detach securing clip -2- and pull cable end-piece off pin gate relay lever.





#### Plastic gate relay lever:

- To prevent damage to gate selector cable, cable end-piece must be detached from gate selector cable before removing relay lever.
- Pull locking mechanism forwards in direction of -arrow 1- onto stop and then turn to left in direction of -arrow 2- to lock.
- Then press gate relay lever forwards (in direction of -arrow 3-).
- Detach cable end-piece only when gate relay lever is removed ⇒ page 76 .


#### Continued for all vehicles:

Detach cable support bracket from gearbox -arrows-; then move to one side and tie up together with selector cables.





Remove top engine/gearbox securing bolts -1-.




If a plastic pipe is installed between clutch master cylinder and slave cylinder, clamp off supply hose to clutch master cylinder using hose clamp -3094- .



#### Note

- In the following steps make sure that no brake fluid escapes onto the starter or onto the gearbox below. If this does happen, Protectean the affected area thoroughly! purposes, in part or in whole, is not not guarantee or accept any liability
- "Seal off open lines and connections with clean plugs or sealing caps to prevent dirt from entering.




If a pipe/hose assembly is installed between clutch master cylinder and slave cylinder, clamp off hose -A- using hose clamp -3094- .



#### Note

-Arrow- can be disregarded.



- Pull clip -arrow- out as far as stop.
- Pull plastic pipe or pipe/hose assembly -A- out of bleeder connection for clutch slave cylinder and seal end of pipe. ight. Copying for p

permitted unless authorised by AUDI with respect to the correctness of



#### Note

-Item B- can be disregarded.



#### Caution


Do not operate clutch pedal after disconnecting pipe/hose assembly.

Unplug electrical connector -2- for reversing light switch -F4-.





#### Note

-Item 1- can be disregarded.




- Set up support bracket -10 222 A- on wing mounting flanges.
- Attach hooks of spindles -10 222 A /11- to engine lifting eyes.
- Take up weight of engine evenly with spindles; do not lift.
- Remove both front wheels.







Remove noise insulation (left and right) -arrows-.




- Remove noise insulation frame -arrow- ⇒ Rep. Gr. 50.



Release hose clip -2- and lift retaining clip -1- to remove air hose.



- Unbolt heat shield for drive shaft (right-side) from bevel box -arrows-.
- Unbolt drive shaft (left-side) from flange on gearbox and tie up.
- Unbolt drive shaft (right-side) from bevel box flange.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI  ${\sf AG}$ .

Remove bolts -arrows 2, 3- from bracket for bevel box.




#### Note


-Arrows 1- can be disregarded.



- Unplug electrical connector -1- at oil level and oil temperature sender -G266- .
- Unclip bracket -2- for electrical wiring leading to oil level and oil temperature sender -G266- at subframe.



Unbolt bracket for exhaust system -arrows- and pull bracket rised by






#### Caution


off retaining pins.

The flexible joints in the exhaust system can be damaged.


- The flexible joints in the front exhaust pipe must not be bent further than 10°.
- Remove nuts -arrows- for exhaust pipe clamp.



Unscrew bolts -1 ... 3- and remove pendulum support.



- Mark position of flexible coupling and bevel box flange in relation to one another.
- Unbolt propshaft with flexible coupling from bevel box -arrows- (counterhold triangular flange with suitable lever).




Push engine/gearbox assembly forward slightly (towards front end) and then pull propshaft off bevel box.



# Caution

The seal -arrow- in the propshaft flange can be damaged.


♦ Push propshaft towards the rear and to the right as far as possible.



### Note


If seal is damaged propshaft must be renewed.

Remove bolts on gearbox mounting -arrows-.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- By adjusting spindles on support bracket -10 222 A-, lower gearbox by distance -a-.
- Dimension -a- = 70 mm.



Unbolt gearbox bracket from gearbox -arrows-.




# Metal gate relay lever -1-:

Pull off securing clip -arrow- and remove gate relay lever -1-.


#### Plastic gate relay lever -1-:

- Removing gate relay lever (with detent catch) ⇒ page 75
- Removing gate relay lever (with clip) ⇒ page 75



#### Continued for all vehicles:


- Lower rear of engine by dimension -a- using spindle -10 222 A /11- .
- Dimension -a- = 30 mm.




Protected by copyright. Copying for private or commercial purposes, permitted unless authorised by AUDI AG. AUDI AG does not guaranteed unless authorised by AUDI AG. with respect to the correctness of information in this document. C


To remove gearbox "02Q" set up gearbox support -3282- with adjustment plate -3282/33-.

- Insert gearbox support -3282- in engine and gearbox jack -V.A.G 1383 A- .
- Align arms of gearbox support according to holes in adjustment plate .
- Bolt on support elements -A-, as illustrated on adjustment plate.
- Screw in pin -3282/29- instead of support element -C-.
- Place engine and gearbox jack -V.A.G 1383 A- under vehicle; arrow symbol -B- on adjustment plate points to front of vehicle.
- Align adjustment plate and gearbox parallel to one another.
- Screw pin -3282/29- into hole for bolt securing pendulum support to gearbox.
- Secure adapter -VW 771/40- in tapped hole of gearbox housing, as shown in illustration.
- Secure gearbox to gearbox support -3282- with bolt M10x20 -item A-.





- Remove engine/gearbox connecting bolts (bottom) -3, 4, 5-.
- Press gearbox off dowel sleeves.
- Carefully lower gearbox using engine and gearbox jack -V.A.G 1383 A- (press engine slightly forwards when doing so).
- Take care not to trap any wires.
- While lowering gearbox, change position of gearbox using spindles on gearbox support -3282- .



#### 8.4 Installing gearbox

Installation is carried out in reverse sequence; note the following:

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



#### Note

- Renew self-locking nuts and bolts when performing assembly work.
- Renew oil seals, gaskets, O-rings and bolts which are tightened by turning through a specified angle.
- All cable ties which are released or cut open during removal must be fitted in the same position when installing.
- Clean input shaft splines and (in the case of a used clutch plate) the hub splines. Remove corrosion and apply only a very thin coating of grease for clutch plate splines -G 000 100- to the splines. Then move clutch plate backwards and forwards on input shaft until hub moves freely on shaft. It is important to remove excess grease.
- When installing a new gearbox, the gear selector lever and gate relay lever must be transferred to the new unit.
- Use thread tap to remove any remaining locking fluid from all threaded holes which will accommodate self-locking bolts.
- If no dowel sleeves for centralising engine/gearbox are in the cylinder block, install dowel sleeves.
- Make sure that the intermediate plate is engaged on the sealing flange and fitted on the dowel sleeves -arrows-.
- Check that clutch plate is centralised ⇒ page 47.
- Check release bearing for wear. Renew clutch slave cylinder with release bearing if necessary ⇒ page 35.
- Raise gearbox carefully using gearbox support -3282-.
- Align gearbox with engine and install.




Guide output flange -C- on gearbox past propshaft -A- and front exhaust pipe -B-. Rotate output flange if necessary.


#### Continued for all vehicles:




### Note

- When installing gearbox make sure the electromechanical power steering is not damaged.
- Pay attention to all pipes/hoses/wiring when installing the gearbox.






If necessary, install bracket for bevel box -A-.



Screw in and tighten bottom engine/gearbox securing bolts -1 ... 3- first, then remaining securing bolts ⇒ page 120 .



Lubricate bearings and moving surfaces of gate relay lever -1- with grease -G 000 450 02- .

#### Metal gate relay lever:

Insert gate relay lever -1- and secure with securing clip -arrow-.

#### Plastic gate relay lever -1-:


- Fit gate relay lever (with detent catch) ⇒ page 75.
- Fit gate relay lever (with clip) ⇒ page 75.

# N34-10012

#### Continued for all vehicles:

Install gearbox bracket ⇒ page 1






- Align engine/gearbox in installation position. To do so, tighten spindles of support bracket -10 - 222 A- until gearbox bracket -1- makes contact with gearbox mounting -2-.
- Additionally, place engine and gearbox jack -V.A.G 1383 Abelow gearbox (near differential) and lift until gearbox bracket is parallel with gearbox mounting.



#### Note

Gearbox mounting and gearbox bracket must be parallel to avoid causing damage to thread of gearbox bracket.

Install gearbox mounting ⇒ page 126.





#### Note

When installing gearbox ensure engine/gearbox mountings are installed stress-free ⇒ Rep. Gr. 10.




#### Caution

Do not remove support bracket -10 - 222 A- until all bolts securing the left-hand engine/gearbox mounting have been tight-ened to the specified torque.

Install bracket for bevel box ⇒ page 121, ⇒ page 122,
 ⇒ page 122.
 Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

 If fitted, install small cover plate -A- at rear of bevel box -arrow- ⇒ page 121.

- Install drive shafts (left and right) ⇒ Rep. Gr. 40.
- Install heat shield for drive shaft (right-side) ⇒ page 122 ,
   ⇒ page 122 ,
   ⇒ page 123 .





 Press engine/gearbox assembly towards bulkhead, taking care to guide pin on bevel box into propshaft flange.



#### Note

- ♦ When removing and installing the gearbox do not damage the seal in the propshaft flange. Renew propshaft if damaged.
- Ensure propshaft is horizontal when pushing it onto centring pin.
- Bolt flexible coupling on propshaft onto bevel box flange -arrows- ⇒ Rear final drive 02D, 0AV, 0BR and 0BY; Rep. Gr. 39.







Install pendulum support ⇒ page 126.



#### Note

- Gearboxes manufactured from 28 05 7 onwards have thread inserts (e.g. "HeliCoil") in the bolt holes for the pendulum support.
- These can be recognised by the shoulder on the first thread turn -arrow-.
- Please use the correct securing bolts and observe the specified tightening torques ⇒ Item 2 (page 126).
- Vehicles with 6-cyl. engine: attach steering box to subframe ⇒ Rep. Gr. 48.
- Install exhaust system and cross piece ⇒ Rep. Gr. 26.
- Install radiator cowl ⇒ Rep. Gr. 19.
- Install starter ⇒ Rep. Gr. 27.
- Install pipe/hose assembly or plastic pipe ⇒ page 29.
- Bleed clutch system ⇒ page 31.
- Install cable support bracket on gearbox ⇒ page 68.
- Apply a small quantity of grease -G 000 450 02- to pin -arrow- of gearbox selector lever -1-.
- Push gear selector cable onto pin -arrow- and secure with securing clip -3-.

#### Metal gate relay lever -2-

- Apply a small quantity of grease -G 000 450 02- to pin -arrow- of gate relay lever -2-.
- Push gate selector cable onto pin -arrow- and secure with securing clip -4-.


#### Plastic gate relay lever -2-


Insert gate selector cable in cable end-piece.

#### Continued for all vehicles

- Adjust selector mechanism ⇒ page 79.
- Install air cleaner housing ⇒ Rep. Gr. 23 or ⇒ Rep. Gr. 24.
- Connect battery. Follow the steps required after connecting the battery ⇒ Řep. Gr. 27.
- Check oil level in gearbox ⇒ page 138.
- Check gear oil level in bevel box ⇒ page 150.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.







- Install left and right noise insulation -arrows-.
- Install noise insulation frame ⇒ Rep. Gr. 50.
- Vehicles with TDI engine: fill up with coolant ⇒ Rep. Gr. 19.
- Install noise insulation ⇒ Rep. Gr. 66.
- Fit wheels  $\Rightarrow$  Rep. Gr. 44.

#### Tightening torques (installing gearbox)




#### Note


- Tightening torques apply only to lightly greased, oiled, phosphated or black-finished nuts and bolts.
- Additional lubricant such as engine or gear oil may be used, but do not use graphite lubricant.
- Do not use parts which have been degreased.
- Tolerance for tightening torques ±15%.

#### Securing manual gearbox to 2.0 ltr. TFSI engine

Item	Bolt	Nm
1 1) 2)	M12x55	80
2 <sup>2)</sup>	M12x165	80
3 1)	M10x105	40
4 1)	M10x50	40
5 3)	M12x65	80
Α	Dowel sleeves for centralising	

- 1) Renew bolts.
- 2) Bolt with stud M8.
- 3) Screwed into gearbox from engine side.







Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Securing manual gearbox to 3.2 ltr. MPI engine

Item	Bolt <sup>1</sup>	Nm
1 <sup>2)</sup> , 3 <sup>3)</sup>	M12x55	80
2 <sup>4)</sup>	M12x65	80
	M12x55	80
4 <sup>4)</sup> , 5 <sup>4)5)</sup>	M10x50	40
6 <sup>3)</sup>	M12x80	80
Α	Dowel sleeves for centralising	

A34-10035

- 1) Renew bolts.
- 2) Bolt with stud M8.
- 3) With captive washer.
- <sup>4)</sup> Screwed into gearbox from engine side.
- <sup>5)</sup> Retaining clip must be fitted in engine sump.

#### Securing manual gearbox to 2.0 ltr. TDI engine

Item	Bolt	Nm
1 1) 2)	M12x55	80
2 <sup>2)</sup>	M12x165	80
3 1)	M10x105	40
4 <sup>1)</sup>	Prote(Md 0x50 right. Cop	ying for private <b>40</b> commercial pu
5 <sup>3)</sup>	wit <b>M42x65</b> the correc	tness of inform <b>80</b> on in this docum
A	Dowel sleeves	for centralising




- <sup>2)</sup> Bolt with stud M8.
- 3) Screwed into gearbox from engine side.


#### Further tightening torques

Component	Nm
Small cover plate for flywheel	10

#### Bracket for bevel box for vehicles with 2.0 ltr. TFSI engine: tightening torque and sequence

- Tighten bolts in 3 stages as follows:
- 1. Screw in bolts -1- (hand-tight).
- 2. Tighten bolts -2- to 40 Nm.
- 3. Tighten bolts -1- to 40 Nm.





#### Bracket -A- for bevel box for vehicles with 3.2 ltr. MPI engine: tightening torque and sequence


- Tighten bolts in 4 stages as follows:
- 1. Screw in bolts -1- and -2- hand-tight.
- 2. Pre-tighten bolts -1- to 3 Nm.
- 3. Tighten bolts -2- to 35 Nm.
- 4. Tighten bolts -1- to 45 Nm.


#### Bracket for bevel box for vehicles with 2.0 ltr. TDI engine: tightening torque and sequence


- Tighten bolts in 5 stages as follows:
- 1. Screw in bolts -1- and -2- hand-tight.
- 2. Pre-tighten bolts -1- to 8 Nm.
- 3. Tighten bolts -2- to 8 Nm.
- 4. Tighten bolts -1- to 40 Nm.
- 5. Tighten bolts -2- to 40 Nm.

#### Heat shield for drive shaft (right-side) for vehicles with 2.0 ltr. TFSI engine: tightening torque

Tighten bolts -arrows- to 25 Nm.








#### Heat shield for drive shaft (right-side) for vehicles with 3.2 ltr. MPI engine: tightening torque


Tighten bolts -arrows- to 25 Nm.


Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AG does with respect to the correctness of information in this doc



Heat shield for drive shaft (right-side) for vehicles with 2.0 ltr. TDI engine: tightening torque  $\,$ 

- Tighten bolts -arrows- to 25 Nm.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


#### 9 Transporting gearbox

# Special tools and workshop equipment required

♦ Gearbox lifting tackle -3336-




Workshop hoist -VAS 6100-



#### **Procedure**


- Bolt gearbox lifting tackle -3336- to clutch housing.
- Set support arm on sliding bracket by means of locking pin -arrow-.
- Number of holes visible = 9
- Lift gearbox with workshop hoist -VAS 6100- and gearbox lifting tackle -3336-.
- Set down gearbox as required (for example in transport container).



#### Securing gearbox to assembly stand 10


# Special tools and workshop equipment required

- ◆ Support plate -VW 309-
- Support clamp -VW 313-
- ♦ Gearbox support -VW 353-



- Secure gearbox to assembly stand with bolts -arrows-.

Protected by copyright. Copying for private or permitted unless authorised by AUDI AG. AUI with respect to the correctness of information



#### 11 Exploded view - assembly mountings

#### 1 - Bolt

- Gearbox bracket to gearbox
- □ 60 Nm + 90°
- □ Renew

#### 2 - Bolts

Pendulum support to gearbox



#### Caution

On 02Q manual gearboxes, HeliCoil inserts may be fitted in the bolt connections for the pendulum support. These thread inserts are standard on gearboxes manufactured from 28 05 7 onwards.

#### **Mentification** *⇒ page 128*


Bolts of property class 10.9 must be used on all gearboxes with HeliCoil thread inserts.

**B**olts of property class 8.8 are specified for gearboxes without thread inserts.

**B**olts of property class 8.8 are listed in the ⇒ Parts catalogue up to ID No. 8J-7-050 000.

**B**olts of property class 10.9 are listed in the ⇒ Parts catalogue from ID No. 8J-8-000 001 onwards.

The specified tightening torque for the bolts depends on the property class.



- Gearbox with thread inserts in conjunction with bolts of property class 10.9:
  - □ 50 Nm + 90°
- Gearbox without thread inserts with bolts of property class 8.8:
  - □ 40 Nm + 90°
  - Always renew

#### 3 - Engine support

#### 4 - Bolt

- ☐ Engine support to engine
- ☐ Tightening torque ⇒ Rep. Gr. 10

5 - Engine mounting
6 - Bolt
☐ Engine mounting to body
☐ Tightening torque ⇒ Rep. Gr. 10
7 - Connecting bracket
8 - Bolt
<ul> <li>Connecting bracket to engine mounting</li> </ul>
☐ Tightening torque ⇒ Rep. Gr. 10
9 - Bolt
□ Connecting bracket to body
☐ Tightening torque ⇒ Rep. Gr. 10
10 - Bolt
<ul><li>□ Engine mounting to body</li><li>□ Tightening torque ⇒ Rep. Gr. 10</li></ul>
11 - Bolts
☐ Engine mounting to engine support
☐ Tightening to engine support
12 - Pendulum support
☐ Removing and installing <u>⇒ page 136</u>
13 - Bolt
☐ Pendulum support to subframe
□ 100 Nm + 90°
☐ Renew
14 - Bolt
☐ Gearbox mounting to gearbox bracket
□ 60 Nm + 90°
☐ Renew
15 - Bolt
<ul><li>☐ Gearbox mounting to body</li><li>☐ 40 Nm + 90°</li></ul>
□ Renew
16 - Gearbox mounting
□ Removing:
◆ Vehicles with 2.0 ltr. TFSI engine ⇒ page 128
♦ Vehicles with 3.2 ltr. MPI engine ⇒ page 130
◆ Vehicles with 2.0 ltr. TDI engine ⇒ page 133
☐ Installing ⇒ page 136

17 - Bolt

☐ Gearbox bracket to gearbox

□ 60 Nm + 90°

□ Renew

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


18 - Gearbox bracket

#### Gearbox with thread inserts (e.g. "HeliCoil") for securing pendulum support



#### Note


- Gearboxes manufactured from 28 05 7 onwards always have thread inserts (e.g. "HeliCoil") in the bolt holes for the pendulum support.
- These can be recognised by the shoulder on the first thread turn -arrow-.
- Different securing bolts and tightening torques *⇒ Item 2 (page 126)*



#### Removing gearbox mounting tred venicles day AUDI AG. AUDI AG does not guarantee or accept any liability with 2.0 ltr. TESI engine with respect to the correctness of information in this document. Copyright by AUDI AG. 11.1 with 2.0 ltr. TFSI engine


## Special tools and workshop equipment required

♦ Support bracket -10 - 222 A-




#### Removing


- Remove engine cover panel -arrows-.
- Remove air cleaner housing completely ⇒ Rep. Gr. 23.



Remove bolts -arrows- and detach bracket for air cleaner housing.




- Set up support bracket -10 222 A- on wing mounting flanges.
- Engage hook of spindle -10 222 A /11- in engine lifting eye (left-side).
- Take up weight of engine evenly with spindles; do not lift.




Remove bolts -arrows-.






- Open retainers for wiring duct -arrows-.
- Cut open cable tie -1- and push electrical wiring to one side.
- Unclip wiring duct.




- Remove bolts -1- and detach gearbox mounting -A-. Install gearbox mounting ⇒ page 136.




# 11.2 Removing gearbox mounting - vehicles with 3.2 ltr. MPI engine

# Special tools and workshop equipment required


♦ Support bracket -10 - 222 A-




♦ Bracket -T10338-



♦ Engine support bracket, basic set -T40091-




◆ Engine support bracket, supplementary set -T40093-




#### Removing


- Remove air cleaner housing completely ⇒ Rep. Gr. 24.
- Unbolt bracket for air cleaner housing -arrows-.



Secure bracket -T10338- to vacant tapped hole at rear left of engine.



- Set up support bracket -10 222 A- on body flanges using the following equipment:
- ♦ Rack -10 222 A /1- (2x)
- ♦ Hook -10 222 A /10- (spindle faces towards rear)
- ◆ Spindle -10 222 A /11- (spindle faces towards front)
- ♦ Shackle -10 222 A /12-
- Connecting piece -T40091/3- (2x)
- Hook spindle 100 222 Ay 19 with shackle 10 0 222 A 11 in whole, is onto engine includes authorised by AUDI AG. AUDI AG does not guarantee or accept any ila onto engine include a company and a com
- Attach hook -10 222 A /10- to bracket -T10338- .
- Partly take up weight of engine/gearbox assembly via the spindles.




- Attach adapters -T40093/3-2- (left-side) and -T40093/3-3-(right-side) to supports -T40093/3-.
- Disconnect earth wire from longitudinal member (left-side).
- Remove securing bolt for front section of longitudinal member (both sides).
- Bolt adapters -arrow- to longitudinal members, using bolts removed previously.




#### Note

Illustration shows left side of vehicle.

Insert square bars -T40091/1- into connecting pieces -T40091/3- and supports -T40093/3- as illustrated.





Protected by copyright. Copying for private or commercial purposes, in part permitted unless authorised by AUDI AG. AUDI AG does not guarantee or with respect to the correctness of information in this document. Copyrigh


- Fit connecting pieces -T40093/4- onto square bars.
- Insert support -T40091/2- with slide -T40093/5- into the two connecting pieces -T40093/4-.




#### **WARNING**

Accidents can be caused if parts of the support bracket are not correctly secured.


- Secure support -T40091/2- using retaining pins and split pins of the connecting pieces -T40093/4-
- Secure connecting pieces and supports using clamping bolts.
- Attach spindle -10 222 A /11- to slide and engine lifting eye.
- Take up weight of engine/gearbox assembly by tightening the 3 spindles evenly.




Remove bolts -arrows-.



- Open retainers for wiring duct -arrows-.
- Protected by copyright. Copying permitted unless authorised by
- Cut open cable tie -1- and push electrical wiring to one side.
- Unclip wiring duct.




- Remove bolts -1- and detach gearbox mounting -A-.
- Detach support bracket -10 222 A- from engine. Install gearbox mounting <u>⇒ page 136</u>.




#### 11.3 Removing gearbox mounting - vehicles with 2.0 ltr. TDI engine

Special tools and workshop equipment required

Support bracket -10 - 222 A-




Removal lever -80 - 200-




#### Removing

- Remove air cleaner housing ⇒ Rep. Gr. 23.
- Remove bolts -arrows- and detach bracket for air cleaner housing.




- Press release tabs and disconnect crankcase breather hose -1- from cylinder head cover.
- Move clear vacuum hoses -arrows- at air pipe.
- Release hose clip -2- and detach air pipe.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- Set up support bracket -10 222 A- on wing mounting flanges.
- Attach hooks of spindles -10 222 A /11- to engine lifting eyes.
- Take up weight of engine evenly with spindles; do not lift.




- Remove bolts -arrows-.




Protected by copyright. Copying permitted unless authorised by with respect to the correctne

- Take electrical connector -1- out of bracket.
- Open retainers for wiring duct -arrows-, unclip electrical wiring using removal lever -80 200- and press electrical wiring to the side.
- Unclip wiring duct.



- Remove bolts -1- and detach gearbox mounting -A-. Install gearbox mounting ⇒ page 136.




#### 11.4 Installing gearbox mounting

#### Installing

Tightening torques ⇒ page 126

Installation is carried out in reverse sequence; note the following:

- First secure gearbox bracket to gearbox -arrows-.



- Pull gearbox up with spindle on support bracket -10 222 Auntil gearbox bracket -1- contacts support arm of gearbox mounting -2-. permitted unless authorised by AUDI AG. AUDI A
- Hand-tighten bolts -arrows- initially.



#### Caution


Screw in bolts straight when fitting as otherwise the threads in the support arm of the gearbox mounting will be damaged.


- Gearbox bracket -1- and support arm of gearbox mounting -2- must be aligned in absolutely parallel position before fitting bolts -arrows-. If necessary, push the gearbox up at the rear with a trolley jack.
- Only tighten bolts after subframe has been installed ⇒ Rep. Gr. 40 and assembly mountings aligned ⇒ Rep. Gr. 10.
- Detach support bracket -10 222 A- from engine.
- Install air cleaner housing ⇒ Rep. Gr. 23 or ⇒ Rep. Gr. 24.

#### 11.5 Removing and installing pendulum support

#### Removing

- Release fasteners -1 ... 4- and remove centre noise insulation.






- Unscrew bolts -1 ... 3- and remove pendulum support.

#### Installing


Installation is carried out in reverse sequence; note the following:

Tightening torques ⇒ "11 Exploded view - assembly mountings", page 126




#### Note

- Gearboxes manufactured from 28 05 7 onwards have thread inserts (e.g. "HeliCoil") in the bolt holes for the pendulum support.
- These can be recognised by the shoulder on the first thread turn -arrow-.
- Please use the correct securing bolts and observe the specified tightening torques ⇒ Item 2 (page 126).



Protected by copyright. Cor permitted unless authoris iability


First secure pendulum support to gearbox -arrow Buttandect to the corre -arrow C-, then on subframe -arrow A-.



#### 12 Overview - oil level in manual gearbox

# Oil filler plug/drain plug - tightening torques

- I Oil filler plug/drain plug with multi-point socket
- ♦ 45 Nm
- II Oil filler plug/drain plug with hexagon socket
- 30 Nm



#### 12.1 Checking oil level in manual gearbox




#### Note


- The manual gearbox and bevel box have separate oil fillings.
- Checking gear oil level in bevel box <del>⇒ page 150</del>
- For gear oil specification, refer to ⇒ Electronic parts cata-

# Special tools and workshop equipment required

♦ Multi-point bit -3357-





Used oil collection and extraction unit -V.A.G 1782-



#### **Procedure**

- Tightening torque <u>⇒ page 138</u>
- Drive vehicle onto a four-column lifting platform or over an inspection pit (vehicle must be horizontal).
- Release fasteners -1 ... 4- and remove centre noise insulation.
- Place used oil collection and extraction unit -V.A.G 1782- below gearbox.
- Remove oil filler plug -arrow- in manual gearbox.
- Specification: oil level up to bottom lip of filler hole
- Top up gear oil if necessary.
- Fit oil filler plug with new seal and tighten.
- Install noise insulation ⇒ Rep. Gr. 66.







Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


#### 13 Removing and installing bevel box

#### General view


- $\Rightarrow$  "13.1 Removing bevel box vehicles with 2.0 ltr. TFSI engine", page 141
- ⇒ "13.2 Removing bevel box vehicles with 3.2 ltr. MPI engine", page 143
- ⇒ "13.3 Removing bevel box vehicles with 2.0 ltr. TDI engine", page 146
- ⇒ "13.4 Installing bevel box", page 147

# Special tools and workshop equipment required

♦ Socket and extended bit -T10107 A-, 6 mm




Hexagon key extension, 8 mm -3247-



Extension -2024 A /1-







Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### 13.1 Removing bevel box - vehicles with 2.0 Itr. TFSI engine

#### Removing

- Remove front exhaust pipe with catalytic converters and front silencer ⇒ Rep. Gr. 26.
- Drain off engine oil ⇒ Maintenance; Booklet 810.
- Remove front right wheel.
- Unbolt heat shield for drive shaft (right-side) from bevel box -arrows-.
- Unbolt drive shaft (right-side) from flange shaft on bevel box.
- Unplug electrical connector -1- at oil level and oil temperature sender -G266- .
- Unclip bracket -2- for electrical wiring leading to oil level and oil temperature sender -G266- at subframe.






- Remove nuts -arrows- securing swivel joint (right-side).
- Disengage swivel joint from wishbone.



# Note

Illustration shows installation position at front suspension (leftside).



Swivel suspension strut (right-side) outwards and support with extension -2024 A /1-, as shown in illustration.



#### WARNING

Protected by copyright. Copying for private or co permitted unless authorised by AUDI AG. AUDI


Risk of accident if parts of support are not properly secured.

Secure locking pin and wishbone with retaining clip -arrow- and nut -1-.




# Note

Illustration shows installation position at front suspension (leftside).



Slacken bolts -1- and remove bolts -2-.




Unscrew bolts -arrow-, detach oil return line from turbocharger and press to right side by copyright. Copying for private or commercial purposes, in part permitted unless authorised by AUDI AG. AUDI AG does not guarantee or with respect to the correctness of information in this document. Copyright



# Note

-Item 1- can be disregarded.




Using socket and extended bit -T10107 A- , remove bolt -arrow 1- securing flange shaft (right-side). To do so, screw two bolts into flange and counterhold flange shaft with suitable lever.




#### Note

Items -A and B- can be disregarded.



- Unscrew bolts (4 in total) securing bevel box to manual gearbox -arrows-.
- Pull bevel box together with flange shaft (right-side) off gearbox and take out bevel box.


Install bevel box ⇒ page 147.



#### 13.2 Removing bevel box - vehicles with 3.2 Itr. MPI engine


## Removing

- Remove front wheels.
- Release fasteners -1 ... 4- and remove centre noise insulation.




- Remove right noise insulation -arrows-.


Protected by copyright. Copying for private permitted unless authorised by AUDI AG. with respect to the correctness of inform




- Remove noise insulation frame -arrow- ⇒ Rep. Gr. 50.



- Unplug electrical connector -1- at oil level and oil temperature sender -G266- .
- Unclip bracket -2- for electrical wiring leading to oil level and oil temperature sender -G266- at subframe.






Remove bolts -2- and -3-.



# Note

Bolt -1- can be disregarded.

- Locate subframe in position to avoid unnecessary wheel alignment ⇒ Rep. Gr. 40.
- Remove subframe ⇒ Rep. Gr. 40 .




- Unbolt drive shaft (right-side) from flange shaft on bevel box.
- Lift drive shaft up as far as possible and secure with cable tie.




# Note


Make sure you do not damage surface coating on drive shaft.

Remove bolts -arrows- and detach bracket for bevel box.










- Mark position of flexible coupling and bevel box flange in relation to one another.
- Unbolt propshaft with flexible coupling from bevel box -arrows- (counterhold triangular flange with suitable lever).



Protected by copyright. Copying for private or commercial purposes


Push engine/gearbox assembly forward slightly (towards front guarant push engine guarant p end) and then pull propshaft off bevel box.



#### Caution

The seal -arrow- in the propshaft flange can be damaged.

Push propshaft towards the rear and to the right as far as possible.





#### Note

If seal is damaged propshaft must be renewed.


- Tie up propshaft.
- Using socket and extended bit -T10107 A- , remove bolt -arrow 1- securing flange shaft (right-side). To do so, screw two bolts into flange and counterhold flange shaft with suitable lever.




# Note

- The flange shaft (right-side) remains in the bevel box.
- Items -A and B- can be disregarded.
- Unscrew bolts (4 in total) securing bevel box to manual gearbox -arrows-.
- Pull bevel box together with flange shaft (right-side) off gearbox and take out bevel box.

Install bevel box <del>⇒ page 147</del>.






#### 13.3 Removing bevel box - vehicles with 2.0 Itr. TDI engine

## Removing

- Remove flange shaft (right-side) ⇒ page 256.
- Unplug electrical connector -1- at oil level and oil temperature sender -G266- .
- Unclip bracket -2- for electrical wiring leading to oil level and oil temperature sender -G266- at subframe.






# Note

Place a cloth below the engine to catch escaping engine oil.


- Remove bolt -2- and banjo bolt -3-.
- Detach bracket for turbocharger from oil return pipe.




Remove bolts -arrows 1, 2, 3- and detach bracket for bevel box.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Mark position of flexible coupling and bevel box flange in relation to one another.
- Unbolt propshaft with flexible coupling from bevel box -arrows- (counterhold triangular flange with suitable lever).




Push engine/gearbox assembly forward slightly (towards front end) and then pull propshaft off bevel box.



#### Caution

The seal -arrow- in the propshaft flange can be damaged.

Push propshaft towards the rear and to the right as far as possible.






# Note

If seal is damaged propshaft must be renewed.


Unscrew bolts -1 ... 3- and remove pendulum support.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Unscrew bolts (4 in total) securing bevel box to manual gearbox -arrows-.
- Detach bevel box from gearbox and remove.

Install bevel box ⇒ page 147.



#### 13.4 Installing bevel box

Tightening torques ⇒ page 255

Installation is carried out in reverse sequence; note the following:



Note

Renew O-rings

#### Vehicles with petrol engine:



#### Caution

The oil seal between the bevel box and the gearbox can be damaged.

- Turn flange shaft while fitting bevel box with flange shaft (right-side) onto gearbox.
- Push bevel box fully onto gearbox, ensuring that splines of bevel box input shaft and differential are centred when brought together.
- If the teeth are correctly positioned and the components are located centrally, the bevel box will slide against the gearbox onto the stop.
- Bolt bevel box to gearbox.



#### Note

Do not use the securing bolts to pull the bevel box onto the gearbox. This could cause the bevel box to tilt and the securing eyes may break off.

- Install bracket for bevel box ⇒ page 121, ⇒ page 122
- Install heat shield for drive shaft (right-side) ⇒ page 122 ,
   ⇒ page 122 .
- Install oil return line for turbocharger ⇒ Rep. Gr. 21.
- Install exhaust system and cross piece ⇒ Rep. Gr. 26.

# Vehicles with 3.2 ltr. MPI engine:

- Install subframe ⇒ Rep. Gr. 40.
- Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.
- Attach steering box to subframe ⇒ Rep. Gr. 48.

#### Vehicles with TDI engine:

- Install bracket for bevel box ⇒ page 122.
- Install bracket for turbocharger ⇒ Rep. Gr. 21.
- Install flange shaft (right-side) ⇒ page 256.
- Install heat shield for drive shaft (right-side) ⇒ page 123.

# Continued for all vehicles:

Install drive shaft (right-side) ⇒ Rep. Gr. 40.



Press engine/gearbox assembly towards bulkhead, taking care to guide pin on bevel box into propshaft flange.



#### Note

- When removing and installing the gearbox do not damage the seal in the propshaft flange. Renew propshaft if damaged.
- Ensure propshaft is horizontal when pushing it onto centring pin.
- Bolt flexible coupling on propshaft onto bevel box flange -arrows- ⇒ Rear final drive 02D, 0AV, 0BR and 0BY; Rep. Gr. 39.
- Install pendulum support ⇒ page 136.





# Note

- Gearboxes manufactured from 28 05 7 onwards have thread inserts (e.g. "HeliCoil") in the bolt holes for the pendulum sup-
- These can be recognised by the shoulder on the first thread turn -arrow-.
- Please use the correct securing bolts and observe the specified tightening torques ⇒ Item 2 (page 126).
- Check gear oil level in bevel box ⇒ page 150.
- Check gear oil level in gearbox ⇒ page 138.
- Install noise insulation frame ⇒ Rep. Gr. 50.
- Install noise insulation ⇒ Rep. Gr. 66.
- Top up engine oil ⇒ Maintenance ; Booklet 810

Fit wheels ⇒ Rep. Gr. 44 .

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





#### 14 Overview - gear oil in bevel box


Oil filler plug - tightening torque



# Note

Renew oil filler plug -arrow-.

Tighten oil filler plug to 15 Nm.



#### 14.1 Checking gear oil level in bevel box




#### Note

- The bevel box is secured to the side of the gearbox and has a separate oil filling.
- For gear oil specifications, refer to ⇒ Electronic parts catalogue .


# Special tools and workshop equipment required

Used oil collection and extraction unit -V.A.G 1782-



#### **Procedure**

- Vehicle must be standing on level surface.
- Bevel box must be in installation position.
- Tightening torque ⇒ page 150
- Release fasteners -1 ... 4- and remove centre noise insulation.
- Place used oil collection and extraction unit -V.A.G 1782- below bevel box.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- Remove oil filler plug -arrow- in bevel box.
- Specification: oil level up to bottom lip of filler hole
- Top up gear oil if necessary ⇒ "14.2 Topping up gear oil in bevel box", page 151



## Note


Carefully remove any traces of escaped oil on bevel box.


- Tighten new oil filler plug. Tightening torque ⇒ page 150
- Install noise insulation ⇒ Rep. Gr. 66.

#### 14.2 Topping up gear oil in bevel box

# Special tools and workshop equipment required

♦ Used oil collection and extraction unit -V.A.G 1782-






♦ Charging device for Haldex coupling 2 -VAS 6291-




Protected by copyright. Copying for private or commercial purposes, in part or in permitted unless authorised by AUDI AG. AUDI AG does not guarantee or acce with respect to the correctness of information in this document. Copyright by



#### **Procedure**

- Vehicle must be standing on level surface.
- Bevel box must be in installation position.
- Tightening torque <u>⇒ page 150</u>

Route hose of charging device for Haldex coupling 2 -VAS 6291- through engine compartment.




Unbolt heat shield for drive shaft (right-side) from bevel box -arrows-.



# Note

Illustration shows 3.2 ltr. MPI engine.







# Note

Cover area beneath oil filler plug -arrow- with a cloth.

- Place used oil collection and extraction unit -V.A.G 1782- below bevel box.
- Remove oil filler plug -arrow- in bevel box.



- Disconnect adapter -A- and elbow joints Bopying for private or commercial permitted unless authorised by AUDI AG. AUDI AG does not screw adapter -A- in onto stop, respect to the correctness of information in this doc
- Connect elbow joint -B- and adapter -A-, making sure they engage.
- The hose must not hang down.




- Please make sure that valve -arrow- is closed.
- Screw oil reservoir -A- onto charging device for Haldex coupling 2 -VAS 6291- .
- Now open valve -arrow- and hold oil reservoir as shown in illustration.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any lial The bevel box will now be filled.

- When bevel box is filled correctly oil will emerge at adapter
- After oil has escaped from adapter -A-, place the reservoir at a lower position to enable part of the excess oil to drain back from the hose into the reservoir.




- Please note that some oil will remain in the hose of the charging device.
- Unscrew adapter -VAS 6291/2-.
- Fit new oil filler plug and tighten. Tightening torque ⇒ page 150





# Note

Carefully remove any traces of escaped oil on bevel box.

- Install heat shield for drive shaft (right-side) ⇒ page 122, <u>⇒ page 122</u> , <u>⇒ page 123</u> .
- Install noise insulation ⇒ Rep. Gr. 66.








#### 15 Dismantling and assembling gearbox

- ⇒ "15.1 General layout of gearbox", page 154
- ⇒ "15.2 Exploded view", page 155
- ⇒ "15.3 Exploded view gearbox housing and selector mechanism", page 156
- ⇒ "15.4 Exploded view input shaft, output shafts, differential, bevel box and selector rods", page 158
- ⇒ "15.5 Dismantling and assembling gearbox (version without circlip A for input shaft sealing cap)", page 159
- ⇒ "15.6 Dismantling and assembling gearbox (version with circlip A for input shaft sealing cap)", page 172


#### 15.1 General layout of gearbox

- 1 Clutch housing
- 2 Reverse shaft
- 3 Output shaft for 5th, 6th and reverse gear
- 4 Clutch slave cylinder with release bearing
- 5 Input shaft
- 6 Output shaft for 1st 4th gear
- 7 Differential
- 8 Bevel box
- Protected by copy
- 9 Flange shaft (right-side)
- 10 Bevel gear with input shaft
- 11 Shaft bevel gear
- 12 Output flange
- 13 Flange shaft (left-side)
- 14 2nd speed selector gear
- 15 1st speed selector gear
- 16 4th speed selector gear
- 17 3rd speed selector gear
- 18 5th speed selector gear
- 19 6th speed selector gear
- 20 Reverse selector gear
- 21 Gearbox housing



#### 15.2 **Exploded view**


- I Exploded view gearbox housing and selector mechanism <u>⇒ page 156</u>
- II Exploded view input shaft, output shafts, differential, bevel box and selector rods ⇒ page 158



# Sealing cap for input shaft with circlip -A-

On gearboxes manufactured from 21 01 8 onwards, the sealing cap for the input shaft is secured by a circlip -A-.

- ⇒ "15.5 Dismantling and assembling gearbox (version without circlip A for input shaft sealing cap)", page 159
- ⇒ "15.6 Dismantling and assembling gearbox (version with circlip A for input shaft sealing cap)", page 172



# 15.3 Exploded view - gearbox housing and selector mechanism

# 1 - Bolt

☐ Tightening torque

⇒ Item 7 (page 250)

## 2 - Flange shaft with spring

- □ Removing and installing⇒ page 159
- □ Assembling⇒ page 267

## 3 - Circlip

- ☐ For sealing cap

  ⇒ Item 4 (page 156)
- ☐ Fitted in gearboxes manufactured from 21 01 8 onwards

## 4 - Sealing cap

- Secured by circlip in gearboxes manufactured from 21 01 8 onwards
- Removing and installing (without circlip)
  - ⇒ page 159
- Removing and installing (with circlip)
  - ⇒ page 159
- Select correct components from ⇒ Electronic parts catalogue .

# 5 - Circlip

□ For grooved ball bearing on input shaft
 ⇒ Item 1 (page 209)

# 6 - Reversing light switch -F4-

- → 20 Nm
- Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not 
  7 Seapermitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.
  - □ Renew

#### 8 - Oil drain plug

☐ Tightening torque <u>⇒ page 138</u>

#### 9 - Seal

☐ Renew

# 10 - Locking bolt


- For selector shaft
- □ 45 Nm

#### 11 - Bolt

- With captive washer
- ☐ 15 Nm + 90°
- ☐ Renew
- ☐ Correct allocation of replacement bolts ⇒ page 157

#### 12 - Bolt

Without washer



- ☐ 15 Nm + 90°
- ☐ Renew
- ☐ Correct allocation of replacement bolts ⇒ page 157

# 13 - Selector mechanism

- ☐ Dismantling and assembling ⇒ page 201
- ☐ Removing with gearbox in vehicle ⇒ page 203

#### 14 - Bolt

- □ 20 Nm
- ☐ Renew

# 15 - O-ring

Protected by  $\square$ pyr $\square$ ene $\square$ ying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with release Clutch nousing formation in this document. Copyright by AUDI AG.


☐ Servicing <u>⇒ page 195</u>

# 17 - Gearbox housing

□ Servicing ⇒ page 185

# Correct allocation of replacement bolts

- A Bolt with captive washer
- B Bolt without washer
- C Bolt with captive washer



#### 15.4 Exploded view - input shaft, output shafts, differential, bevel box and selector rods

#### 1 - Output shaft for 1st - 4th gear

- □ Dismantling and assembling ⇒ page 220
- Installation position ⇒ page 159

# 2 - Selector rod with selector fork for 1st and 2nd gear

- Installation position ⇒ page 159
- 3 Selector rod with selector fork for 3rd and 4th gear
  - Installation position ⇒ page 159

#### 4 - Output shaft for 5th, 6th and reverse gear

- Dismantling and assembling <del>⇒ page 237</del>
- Installation position ⇒ page 159

## 5 - Selector rod with selector fork for 5th and 6th gear

Installation position ⇒ page 159


# 6 - Reverse gear selector fork

☐ Installation position ⇒ page 159

#### 7 - Input shaft

- Dismantling and assembling ⇒ page 211
- Always renew grooved ball bearing on input shaft

⇒ Item 6 (page 210)



#### 8 - Reverse shaft

for private or commercial purposes, in part or in whole, is not panitt With thrust washer AG. AUDI AG does not guarantee or accept any liability of information in this document. Copyright by AUDI AG.

# 9 - Thrust washer

#### 10 - Bleeder connection

□ Connect to clutch slave cylinder ⇒ Item 14 (page 158)

#### 11 - Clutch housing

#### 12 - Input shaft oil seal

☐ Renewing ⇒ page 198

# 13 - O-ring

- Always renew
- Push onto pipe connection
- Lubricate with brake fluid before installing

# 14 - Clutch slave cylinder with release bearing

#### 15 - Bolt

☐ Tightening torque ⇒ Item 1 (page 35)

#### 16 - Bolt

☐ Tightening torque <u>⇒ Item 13 (page 255)</u>

#### 17 - Bolt

- □ 40 Nm
- □ 4x
- □ Renew

#### 18 - Bevel box

- ☐ Removing and installing (with gearbox installed) ⇒ page 140
- □ Removing and installing (with gearbox removed) ⇒ page 159


#### 19 - Differential

☐ Dismantling and assembling ⇒ page 269


#### Installation position of shafts and selector rods in gearbox


- 1 Input shaft
- 2 Output shaft for 1st 4th gear
- 3 Output shaft for 5th/6th and reverse gear
- 4 Reverse shaft
- A Selector rod for 3rd and 4th gear
- B Selector rod for 1st and 2nd gear
- C Selector rod for 5th and 6th gear
- D Reverse gear selector fork 1)

<sup>1)</sup> In gearboxes manufactured from 25 05 9 onwards: mounted on selector rod for 5th/6th gear selector fork -item C-. Identification of different types of reverse gear selector forks ⇒ page 207




Removing and installing gearbox housing, selector mechanism, input shaft, output shafts, differential, bevel box and selector rods






# Special tools and workshop equipment required

- Support plate -VW 309-
- Support clamp -VW 313-
- Gearbox support -VW 353-
- Installing sleeve -VW 455-
- Multi-purpose tool -VW
- -1- Kukko internal puller 21/1
- -3- Kukko 17/0 splitter
- -4- Kukko 22/1 countersupport




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


- ♦ Support bridge -30 211 A-
- Thrust piece -T10042-
- Drift -T10169-
- Thrust piece -T40008-
- Torque wrench -V.A.G 1331-
- ♦ Hot air blower -V.A.G 1416-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability


◆ Used oil collection and extraction unit -V.A.G 1782-





Socket and extended bit -T10107 A-







Protected by copyright. Copying for private or commercial purposes, in part or in whole, permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

## Dismantling

- Gearbox removed ⇒ page 82 and mounted on assembly stand ⇒ page 125 .
- Turn gearbox on assembly stand so that oil drain plug faces downwards.
- Place used oil collection and extraction unit -V.A.G 1782- below gearbox.
- Drain gear oil out of gearbox.
- Unscrew bolt for flange shaft (right-side) using socket and extended bit -T10107 A-.
- Remove all 4 bolts -arrows- securing bevel box to gearbox (illustration only shows 3 bolts).
- Carefully push bevel box away from gearbox, making sure it does not fall down.




- Remove bolts -arrows-.
- Take off slave cylinder together with release bearing -A-.




- Make sure that the selector shaft is not locked in position by the angled rod -arrow- when carrying out the following steps.
- Put selector shaft in neutral position.
- Remove locking bolt -2-.
- Remove bolts -3-.

lever.

- Remove reversing light switch -F4- -1-.
- Pull selector shaft -4- out of gearbox housing.



Remove bolt securing flange shaft (left-side). To do so, screw two bolts into flange and counterhold flange shaft with suitable



Remove bolts -B- securing gearbox housing from inside clutch housing.



# Note

One of the bolts -arrow- is outside the joint flange.


Protected by copyright. Co permitted unless authoris ability with respect to the corr


N34-0997

- Lock input shaft by fitting installing sleeve -VW 455- over input shaft and against clutch housing.
- Tighten splitter -A-, e.g. -Kukko 17/0- behind splines on input shaft.
- The rear side of the splitter must be in contact with installing sleeve (zero play).




- Pierce rubber in centre of sealing cap of with a screwdriver.
- Pull sealing cap out of gearbox housing.
- A Counter-support, e.g. -Kukko 22/1-
- B Internal puller 8 ... 12 mm, e.g. -Kukko 21/01-






Detach circlip -C- from input shaft grooved ball bearing as follows:


- Hold one end of circlip with screwdriver -A-.
- Lever other end of circlip out of slot in ball bearing -arrow- with 2nd screwdriver -B-.
- Lever out circlip further by re-applying screwdriver -B-.



- Where fitted, detach spacer -1- from gearbox housing -2-.
- When renewing the gearbox housing, check whether the spacer has to be re-installed ⇒ page 167.



Remove bolts -A-.



V.A.G 1416 VW 771/1

/W 771/40


VW 309


- Screw adapter VW 771/40 into threaded hole in gearbox hous-
- Using hot air blower -V.A.G 1416-, heat area around seat of input shaft ball bearing in gearbox housing for approx. 10 minutes to approx. 100°C.
- Using multi-purpose tool VW 771/1, pull gearbox housing off clutch housing -arrow-.




# Note

If necessary, carefully apply a lever to the protruding flanges on alternate sides of the gearbox housing, taking care not to damage the sealing surfaces.






Protected by copyright. Copying for private permitted unless authorised by AUDI AG. with respect to the correctness of inform



Remove splitter -A- and installing sleeve VW 455 from input

A second mechanic is required for removing the shafts from the clutch housing.



- Lift up differential -1- with your left hand.
- With your right hand, lift 1st 4th gear output shaft together with selector rods -2- -arrow A-.
- At the same time, the second mechanic must lift the input shaft, reverse shaft and 5th/6th gear output shaft -3- out of the clutch housing together with the selector rods -arrow B-.



#### Note

If required, the differential can be put back in the clutch housing after lifting the shafts.

Drive out input shaft oil seal with sleeve -30-21-.




#### Note

Always renew grooved ball bearing on input shaft *⇒ Item 6 (page 210)* .

## **Assembling**

- A new grooved ball bearing has been pressed onto the input shaft ⇒ Item 6 (page 210)
- Tightening torques ⇒ page 156
- Insert input shaft -1-, output shaft for 5th and 6th gear -2- together with selector rod -3-, selector fork -4- and reverse shaft -5-.



3

N34-10029

Install differential -1-.


Protected by copyright. Copying for private or commercial pupermitted unless authorised by AUDI AG. AUDI AG does no with respect to the correctness of information in this docu



#### Note

A second mechanic is required for installing the shafts in the clutch housing.

- Take 1st 4th gear output shaft -3- with selector rods -4- in your right hand as illustrated.
- Lift up differential slightly with your left hand.
- At the same time the second mechanic must lift the input shaft and output shaft for 5th, 6th and reverse gear -2- slightly, together with the reverse shaft.
- Now insert 1st 4th gear output shaft in direction of -arrow-.
- The teeth of the input shaft, output shafts and final drive gear/ differential must mesh.
- Now, together with second mechanic, locate shafts and differential in their bearing seats.




Secure support bridge -30 - 211 A- for input shaft to clutch housing.



# Note

Illustration shows clutch housing turned through 180° for clarity.

Screw in bolt -A- until input shaft lifts slightly.





# Note

- On some gearboxes, grooved ball bearing for input shaft -A-and bearing mounting -B- are flattened on one side.
- Check grooved ball bearing for input shaft and gearbox hous-

Grooved ball bearing for input shaft and gearbox housing
Without flattened sides on grooved ball bearing -A- and bearing

mounting -B- ⇒ page With flattened sides on grooved ball bearing A-rand bearing mounting -B- ⇒ page 168


From gearbox manufacturing date 10 04 6 to approx. 20 01 8:


A spacer is fitted on either side of grooved ball bearing for input shaft ⇒ Item 6 (page 210) .

Top spacer	Outside diameter	78.6 mm
Bottom spacer	Outside diameter	85 mm




Area above grooved ball bearing	Dimension "a"	Top spacer
Up to gearbox man- ufacturing date 09 04 6	10 mm	No
From gearbox man- ufacturing date 10 04 6 onwards	10.7 mm	Yes







#### In the gearbox housing, the area below the seat for the grooved ball bearing has also been modified -arrow-.

Area below bearing seat		Bottom spacer
Up to gearbox man- ufacturing date 09 04 6	Not modified	No
From gearbox man- ufacturing date 10 04 6 onwards	Slightly deeper	Yes







# Gearboxes with flattened sides on grooved ball bearing for input shaft -A- and bearing mounting -B-:


- A spacer must not be fitted above or below the grooved ball bearing.
- Flattened sides -A- on grooved ball bearing and bearing mounting -B- in gearbox housing must be aligned.
- Mark flattened sides with paint.
- Copy markings onto top area of grooved ball bearing and top area of bearing mounting on gearbox housing (⇒ next illustra-
- Using hot air blower -V.A.G 1416- , heat area around seat of vate or input shaft ball bearing in gearbox housing for approx 10 mi-G. ALD nutes to approx. 100°C.




# Note

Heating is necessary to ensure that grooved ball bearing is not damaged when installing gearbox housing.

Align marking -A- on grooved ball bearing with marking -B- on gearbox housing and fit gearbox housing.





# Continued for all gearboxes:

Using hot air blower -V.A.G 1416-, heat area around seat of input shaft ball bearing in gearbox housing for approx. 10 minutes to approx. 100°C.



# Note

Heating is necessary to ensure that grooved ball bearing is not damaged when installing gearbox housing.

- Apply sealing paste -AMV 188 200 03- evenly to sealing surface of clutch housing.
- Fit gearbox housing and tighten new bolts -A-, -B- and -C- to specified torque.


#### Allocation of bolts:


Protected by copyright. Copying for private or commercial purp A - Bolt with captive washer permitted unless authorised by AUDI AG. AUDI AG does not guith respect to the correspond of information purposes.

- B Bolt without washer
- C Bolt with captive washer
- If a spacer was fitted on the grooved ball bearing before installing the gearbox housing, a spacer -1- (outer diameter = 78.6 mm) must also be fitted after installing the gearbox housing -2- <u>⇒ page 167</u>.
- Install circlip -1- for input shaft grooved ball bearing.
- Remove support bridge -30 211 A- for input shaft.



- If stop sleeve for selector shaft has been removed, drive it in now using drift -T10169- (drive in until drift contacts stop).
- Turn gearbox on assembly stand so that opening for selector shaft faces up.






Insert selector shaft -1- into bottom mounting -2- and into selector forks -3-.



#### Note

The sealing cap is removed to give a better illustration.




- Now push selector shaft -1- against stop sleeve -2- in direction of -arrow- and run selector finger -3- down through selector forks and onto stop.
- Selector mechanism cover -4- should be parallel to joint surface on gearbox housing.
- Selector shaft should move up and down easily (gate selector movement).




#### Note


If the selector mechanism cover is not parallel with the joint surface, the selector shaft is not seated in its bottom mounting.



- Tighten bolts -3- for selector mechanism cover -4-.
- Screw in locking bolt -2-; angled rod -arrow- must be released.
- Install reversing light switch -F4- -1-.
- Install flange shaft (left-side) ⇒ page 250 .



- Drive in input shaft oil seal.
- Install clutch slave cylinder with release bearing ⇒ page 36.
- Select all gears.



Drive sealing cap into gearbox housing onto stop using thrust piece -T10042- .

# Attach bevel box to gearbox as follows:



#### Caution

The oil seal between the bevel box and the gearbox can be damaged.


- Turn flange shaft while fitting bevel box with flange shaft (right-side) onto gearbox.
- On manual gearbox, grease splines on differential with grease for clutch plate splines -G 000 100- .
- Push bevel box fully onto gearbox, ensuring that splines of bevel box input shaft and differential are centred when brought together.
- If the teeth are correctly positioned and the components are located centrally, the bevel box will slide against the gearbox ivate or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability onto the stop. with respect to the correctness of information in this document. Copyright by AUDI AG.




#### Note

Do not use the securing bolts to pull the bevel box onto the gearbox. This could cause the bevel box to tilt and the securing eyes may break off.


- Tighten all 4 bolts -arrows- securing bevel box to gearbox (illustration only shows 3 bolts). Tightening torques ⇒ Item 10 (page 255)
- Install flange shaft (right-side) ⇒ page 255.






# Dismantling and assembling gearbox 15.6 (version with circlip -A- for input shaft sealing cap)

Removing and installing gearbox housing, selector mechanism, input shaft, output shafts, differential, bevel box and selector rods




#### Special tools and workshop equipment required


- Support plate WW 309s of inf
- Support clamp -VW 313-
- Gearbox support -VW 353-
- Installing sleeve -VW 455-
- Multi-purpose tool -VW 771-
- -1- Kukko internal puller
- -3- Kukko 17/0 splitter
- -4- Kukko 22/1 countersupport




- ♦ Support bridge -30-211A-
- Thrust piece -T10042-
- Thrust piece -T10143-
- Thrust piece -T40008-
- Torque wrench -V.A.G 1331-
- ♦ Hot air blower -V.A.G 1416-
- Drift -T10169-
- Or drift -T10362-⇒ page 192




♦ Oil seal extractor lever -VW 681-



♦ Used oil collection and extraction unit -V.A.G 1782-




Socket and extended bit -T10107 A-




# Removing

- Gearbox removed ⇒ page 82 and mounted on assembly stand
   ⇒ page 125.
- Turn gearbox on assembly stand so that oil drain plug faces downwards.
- Place drip tray underneath.
- Drain gear oil out of gearbox.


- Remove bolt for flange shaft (right-side) using socket and extended bit -T10107 A-.
- Remove all 4 bolts -arrows- securing bevel box to gearbox (illustration only shows 3 bolts).
- Carefully push bevel box away from gearbox, making sure it does not fall down.



- Remove clutch slave cylinder with release bearing -arrows-.




- Make sure that the selector shaft is not locked in position by the angled rod -arrow- when carrying out the following steps.
- Put selector shaft in neutral position.
- Remove locking bolt -2-.
- Remove bolts -3-.
- Remove reversing light switch -F4- -1-.
- Pull selector shaft -4- out of gearbox housing.



Remove bolt securing flange shaft (left-side). To do so, screw two bolts into flange and counterhold flange shaft with suitable lever.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



Remove bolts -B- securing gearbox housing from inside clutch housing.





#### Note

One of the bolts -arrow- is outside the joint flange.


Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability


- Lock input shaft by fitting installing sleeve -VW 455- over input shaft and against clutch housing.
- Tighten splitter -A-, e.g. -Kukko 17/0- behind splines on input shaft.
- The rear side of the splitter must be in contact with installing sleeve (zero play).







- Pull sealing cap out of gearbox housing.
- A Counter-support, e.g. -Kukko 22/1-
- B Internal puller 8 ... 12 mm, e.g. -Kukko 21/01-











Detach circlip -C- from input shaft grooved ball bearing as follows:

- Hold one end of circlip with screwdriver -A-.
- Lever other end of circlip out of slot in ball bearing -arrow- with 2nd screwdriver -B-.
- Lever circlip out further by repositioning screwdriver -B-.



Protected Remove gearbox housing/clutch housing securing bolts -A-. with respect to the correctness of information in this document. Copyright by AUDI AG.






- Screw adapter VW 771/40 into threaded hole in gearbox housing.
- Using hot air blower -V.A.G 1416-, heat area around seat of input shaft ball bearing in gearbox housing for approx. 10 minutes to approx. 100°C.
- Using multi-purpose tool VW 771/1, pull gearbox housing off clutch housing -arrow-.




## Note

If necessary, carefully apply a lever to the protruding flanges on alternate sides of the gearbox housing, taking care not to damage the sealing surfaces.

Remove splitter -A- and installing sleeve VW 455 from input shaft.








#### Note

A second mechanic is required for removing the shafts from the clutch housing.

- Lift up differential -1- with your left hand.
- With your right hand, lift 1st 4th gear output shaft together with selector rods -2- -arrow A-.
- At the same time, the second mechanic must lift the input shaft, reverse shaft and 5th/6th gear output shaft -3- out of the clutch housing together with the selector rods -arrow B-.





#### Note

If required, the differential can be put back in the clutch housing after lifting the shafts.

 Remove oil seal for input shaft using oil seal extractor lever -VW 681-.




#### Note

Always renew grooved ball bearing on input shaft ⇒ Item 6 (page 210) .

#### Assembling gearbox

- A new grooved ball bearing has been pressed onto the input shaft ⇒ Item 6 (page 210).
- Insert input shaft -1-, output shaft for 5th and 6th gear -2- together with selector rod -3-, selector fork -4- and reverse shaft -5-.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Up to gearbox manufacturing date 24 05 9:


- Bearing for reverse gear selector fork:
- Fit reverse gear selector fork -1- on shaft -2- behind selector rod for 5th/6th gear -3-.



### From gearbox manufacturing date 25 05 9 onwards

- Bearing for reverse gear selector fork:
- Fit reverse gear selector fork -1- on selector rod with selector fork for 5th/6th gear -2-.





#### Continued for all gearboxes:

Install differential -1-.



#### Note

A second mechanic is required for installing the shafts in the clutch housing.

- Take 1st 4th gear output shaft -3- with selector rods -4- in your right hand as illustrated.
- Lift differential slightly with your left hand.
- At the same time, have the second mechanic lift the input shaft and output shaft for 5th, 6th and reverse gear -2- slightly, together with the reverse shaft.

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not

- Now insert 1st 4th gear output shalftdim an authorse dry AUDIAG. AUDI AG does not guarantee or accept any liability with respect to the correctness of mormation in this document. Copyright by AUDI AG.
- The teeth of the input shaft, output shafts and final drive gear/ differential must mesh.
- Now, together with second mechanic, locate shafts and differential in their bearing seats.
- Secure support bridge -30-211A- for input shaft to clutch housing.




#### Note


Illustration shows clutch housing turned through 180° for clarity.


- Screw in bolt -A- until input shaft lifts slightly.
- Grooved ball bearing for input shaft will fit into gearbox housing in one position only.

The grooved ball bearing and the bearing mounting are flattened on one side.

- If the sides are flattened -A- and -B-, a spacer must not be fitted above or below the grooved ball bearing  $\Rightarrow$  page 215.
- Flattened sides -A- on grooved ball bearing and bearing mounting -B- in gearbox housing must be aligned.
- Mark flattened sides with paint.
- Copy markings onto top area of grooved ball bearing and top area of bearing mounting on gearbox housing (⇒ next illustration).
- Using hot air blower -V.A.G 1416-, heat area around seat of input shaft ball bearing in gearbox housing for approx. 10 minutes to approx. 100°C.










#### Note


- Heating is necessary to ensure that grooved ball bearing is not damaged when installing gearbox housing.
- ♦ Align marking -A- on grooved ball bearing with marking -B- on gearbox housing and fit gearbox housing.
- Apply sealing paste -AMV 188 200 03- evenly to sealing surface of clutch housing.





#### Allocation of bolts:

- A Bolt with captive washer
- B Bolt without washer
- C Bolt with captive washer


Protected by copyright. Copying for private or cor permitted unless authorised by AUDI AG. AUDI with respect to the correctness of information







- Remove support bridge -30-211A- for input shaft.
- If stop sleeve for selector shaft has been removed, drive it in now ⇒ page 192 (drive in until tool reaches stop).




- Turn gearbox on assembly stand so that opening for selector shaft faces up.
- Insert selector shaft -1- into bottom mounting -2- and into selector forks -3-.



#### Note

The sealing cap is removed to give a better illustration.




- Now push selector shaft -1- against stop sleeve -2- in direction of -arrow- and run selector finger -3- down through selector forks and onto stop.
- Selector mechanism cover -4- should be parallel to joint surface on gearbox housing.
- Selector shaft should move up and down easily (gate selector movement).




#### Note


If the selector mechanism cover is not parallel with the joint surface, the selector shaft is not seated in its bottom mounting.

- Tighten bolts -3- for selector mechanism cover -4-.
- Screw in locking bolt -2-; angled rod -arrow- must be released.
- Install reversing light switch -F4- -1-.






Install flange shaft together with spring, thrust washer and tapered ring.




- Drive in input shaft oil seal so it is flush.
- Install clutch slave cylinder with release bearing ⇒ page 36
- Select all gears.



permitted unless authorised by AUDI AG. AUDI AG does



Drive sealing cap into gearbox housing onto stop.



Secure sealing cap with circlip -A-.

Attach bevel box to gearbox as follows:



#### Caution


The oil seal between the bevel box and the gearbox can be damaged.

- ◆ Turn flange shaft while fitting bevel box with flange shaft (right-side) onto gearbox.
- On manual gearbox, grease splines on differential with grease for clutch plate splines -G 000 100- .
- Push bevel box fully onto gearbox, ensuring that splines of bevel box input shaft and differential are centred when brought together. d by copyright. Copying for private or commercial purposes, in part or in whole, is not
- Also align the teeth of the flange shaft (right-side) and the dif-y liability ferential pinion; if necessary turn the flange shaft.
- If the teeth are correctly positioned and the components are located centrally, the bevel box will slide against the gearbox onto the stop.




#### Note

Do not use the securing bolts to pull the bevel box onto the gearbox. This could cause the bevel box to tilt and the securing eyes may break off.



- Tighten all 4 bolts -arrows- securing bevel box to gearbox (illustration only shows 3 bolts). Tightening torques ⇒ Item 10 (page 255)
- Install flange shaft (right-side) ⇒ page 255.





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### 16 Exploded view - gearbox housing



#### Note

Securing gearbox to assembly stand ⇒ page 125

#### 1 - Gearbox housing

- ☐ If renewed: Adjust output shafts and differential <u>⇒ page 274</u>
- Modifications in area of mounting for grooved ball bearing on input shaft
  - ⇒ Item 3 (page 209)
- □ Select correct components from ⇒ Electronic parts catalogue

#### 2 - Sealing cap

- □ Removing ⇒ page 189
- ☐ Driving in <u>⇒ipage 190 e c</u>

#### 3 - Plug

- ☐ For oil drain hole
- ☐ Tightening torque ⇒ page 138

#### 4 - Seal

□ Renew

#### 5 - Plug

- □ For oil filler hole
- ☐ Tightening torque ⇒ page 138

#### 6 - Angled rod


- ☐ For adjusting selector mechanism ⇒ page 79
- ☐ Can be renewed without dismantling gearbox
- □ Removing ⇒ page 190
- Installation position <u>⇒ page 190</u>
- ☐ Driving in ⇒ page 190

#### 7 - Bearing bush for selector rods

- □ Pulling out ⇒ page 191
- □ Driving in ⇒ page 191

#### 8 - Stop sleeve

- ☐ Pressing out (gearbox dismantled) ⇒ page 191
- ☐ Driving out (gearbox not dismantled) ⇒ page 191
- ☐ Identification of different types of stop sleeve <u>⇒ page 192</u>
- ☐ Driving in stop sleeve with shoulder <u>⇒ page 192</u>
- ☐ Driving in stop sleeve without shoulder ⇒ page 192



<u> </u>	everse shaft needle bearing  Always renew after removing  Pulling out ⇒ page 192  Pressing in ⇒ page 193
10 - <sup>-</sup> _ _	Tapered roller bearing outer race  For 5th/6th and reverse gear output shaft  Removing and installing ⇒ page 237
	Shim  For 5th/6th and reverse gear output shaft  Table of adjustments ⇒ page 274
<u> </u>	Tapered roller bearing outer race  For 1st - 4th gear output shaft  Removing and installing ⇒ page 220  If renewed: Adjust 1st - 4th gear output shaft ⇒ page 230
	Shim  For 1st - 4th gear output shaft  Table of adjustments ⇒ page 274
	Tapered roller bearing outer race  For differential  Removing and installing ⇒ page 267  If renewed: adjust differential ⇒ page 274
	Shim  For differential  Table of adjustments ⇒ page 274
	Bearing bush for selector shaft  Pulling out ⇒ page 193  Driving in ⇒ page 193
	Sealing plug  Driving out ⇒ page 193  Driving in ⇒ page 194
	Oil seal for flange shaft (left-side) Renewing <u>⇒ page 251</u>


Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### 16.1 Servicing gearbox housing

#### Special tools and workshop equipment required

- ♦ Guide pin -VW 436 A-
- Guide pin -VW 439-
- Multi-purpose tool -VW
- ♦ Support plate -VW 801-
- Guide pin -10 15-
- Thrust piece -3124-


Protected by copyright. Copying for private or commer permitted unless authorised by AUDI AG. AUDI AG do with respect to the correctness of information in this




Drift sleeve -VW 244 B-Thrust plate -VW 401-VW 244 b VW 401 Thrust plate -VW 402-Press tool -VW 407-Tube -VW 416 B-Punch -3264-VW 402 VW 407 Protected by copyright. Copying for prival permitted unless authorised by AUDI AG with respect to the correctness of information of the correctness of information of the correctness of or commercial purposes, in part or in whole, is not mation in this document. Copyright by AUDI AG. VW 416 B 3264


G34-0036

- ♦ Assembly tool -3290-
- Drift -T10168-
- Drift -T10169-
- Thrust piece -T10203-
- -1- Kukko internal puller 21/2 and 21/4
- -4- Kukko 22/2 countersupport










## Removing sealing cap

Protecte Pierce rubber in cenate or commercial purposes, in part or in whole, is not permitte tre of sealing cap with. AUDI AG does not guarantee or accept any liability with raiscrewarteer-B-and pry off sealing cap

-in direction of arrow-


#### Driving in sealing cap

- Drive in sealing cap as far as stop.



#### Removing angled rod for selector shaft


- Shear off pin in released position.
- Insert screwdriver -A- in bore for angled rod -B-.
- Pry out angled rod -arrow-.



#### Installation position of angled rod


- Marking on angled rod -arrow- must face towards connection on clutch slave cylinder -1-.
- Angle -a- must be approx. 45°.






#### Driving in angled rod for selector shaft

- The angled rod -arrow- must be in the released position when driving in.
- Drive in angled rod until tool contacts stop.




#### Pulling out bearing bush for selector rod

- A Internal puller 14.5 ... 18.5 mm, e.g. -Kukko 21/2-
- B Counter-support , e.g. -Kukko 22/2-




#### Driving in selector rod bush

- Drive in selector rod bush until tool contacts stop.



#### Pressing out stop sleeve (gearbox dismantled)

- Place gearbox housing on thrust plates -VW 401- and -VW 402- so that the dowel sleeves in the gearbox housing do not become damaged.
- Press out stop sleeve -A-.



#### Driving out stop sleeve (gearbox not dismantled)


- Locking bolt and selector shaft removed
- Turn gearbox so that stop sleeve does not drop into gearbox.
- Drive out stop sleeve using guide pin -10 15-.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is no permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liabilit with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Identification of different types of stop sleeve


- A stop sleeve with shoulder -arrow 1- <u>⇒ page 192</u> or without shoulder -arrow 2- ⇒ page 192 may be fitted.
- Select correct components from ⇒ Electronic parts catalogue.



#### Driving in stop sleeve with shoulder as far as tool stop


Gearbox housing bolted to clutch housing

Protected by copyright. Copying for private or commercial purporpermitted unless authorised by AUDI AG. AUDI AG does not gu with respect to the correctness of information in this document



#### Driving in stop sleeve without shoulder as far as tool stop

Gearbox housing bolted to clutch housing



#### Pulling needle bearing for reverse shaft out of gearbox housing


A - Internal puller 23.5 ... 30 mm, e.g. -Kukko 21/4-

B - Counter-support, e.g. -Kukko 22/2-




#### Note

The needle bearing is destroyed during removal and must be renewed.




#### Pressing needle bearing into gearbox housing

- Before pressing in, place reverse shaft thrust washer -B- on needle bearing -A-.
- Place tube -VW 416 B- directly under bearing mounting to support gearbox housing.




#### Pulling out selector shaft bush

- Hold spindle of assembly tool -3290- tight and turn nut -B-.
- A Internal puller 14.5 ... 18.5 mm, e.g. -Kukko 21/2-




#### Driving in selector shaft bearing bush

- Drive in selector shaft bush -A- until flush.



#### **Driving out plug**

Drive out plug -1- from inside of gearbox housing -arrow-.




Protected by copyright. Copying for private or comme permitted unless authorised by AUDI AG. AUDI AG with respect to the correctness of information in th



#### Driving in plug

Drive in plug -1- using punch -3264- to a depth of approx. 3 mm (distance -a- below surface of housing).





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

## 17 Exploded view - clutch housing

## 1 - Bearing bush for selector rods

- □ Pulling out ⇒ page 197
- □ Driving in ⇒ page 198

# 2 - Reverse gear selector fork shaft

- ☐ Installed up to gearbox manufacturing date 24 05 9 ⇒ page 196
- Shaft cannot be removed with workshop tools
- Up to gearbox manufacturing date 24 05 9: press in new shaft if a new clutch housing is fitted ⇒ page 198
- □ Discontinued from gearbox manufacturing date 25 05 9 onwards; reverse gear selector fork is then mounted together with selector fork for 5th/6th gear ⇒ page 179
- ☐ For correct version, refer to ⇒ Electronic parts catalogue

# 3 - Reverse shaft needle bearing

- Always renew after removing
- □ Pulling out ⇒ page 198
- □ Pressing in⇒ page 198

#### 4 - Dowel sleeve

□ 2x

#### 5 - Clutch housing

☐ If renewed: Adjust output shafts and differential ⇒ page 274

#### 6 - Input shaft oil seal

□ Renewing ⇒ page 198

#### 7 - Oil seal


- Between gearbox and bevel box
- □ Renewing with manual gearbox installed ⇒ page 253
- ☐ Can be removed using sleeve -30 21- when gearbox is dismantled
- ☐ When gearbox has been dismantled, it can be driven in onto stop using thrust piece -T40007-.

#### 8 - Shim

- For differential
- ☐ Installation position: Shoulder on inside diameter faces towards oil seal ⇒ Item 7 (page 195)

#### 9 - Tapered roller bearing outer race

For differential



Removing and installing <u>⇒ page 267</u>
If renewed: adjust differential ⇒ page 274

#### 10 - Oil deflector plate

☐ Installation position: Shoulder on drilling faces towards output shaft

#### 11 - Tapered roller bearing outer race

- ☐ For 1st 4th gear output shaft
- □ Removing and installing ⇒ page 220
- ☐ If renewed: Adjust 1st 4th gear output shaft <u>⇒ page 230</u>

#### 12 - Tapered roller bearing outer race

- ☐ For 5th/6th and reverse gear output shaft
- □ Removing and installing ⇒ page 237
- ☐ If renewed: Adjust 5th/6th and reverse gear output shaft <u>⇒ page 245</u>

#### 13 - Shim

- ☐ For 5th/6th and reverse gear output shaft
- □ 0.65 mm thick

#### 14 - Roller bearing

- For input shaft
- □ Removing and installing ⇒ page 211

#### 15 - Magnet


☐ Held in place by joint surface of housing

#### 16 - Cap

☐ Only fitted in clutch housing for 4-cylinder engine

#### Reverse gear selector fork shaft in gearboxes manufactured up to 24 05 9

Fit reverse gear selector fork -1- on shaft -2- behind selector rod for 5th/6th gear -3-.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### 17.1 Servicing clutch housing

#### Special tools and workshop equipment required


- ♦ Press tool -VW 407-
- Sleeve -30 21-
- ♦ Drift -T10168-
- Thrust piece -T40008-
- -1- Kukko internal puller 21/2 and 21/4
- -4- Kukko counter-support 22/1 and 22/2



#### Pulling out bearing bush for selector rod


A - Counter-support, e.g. -Kukko 22/1-

B - Internal puller 14.5 ... 18.5 mm , e.g. -Kukko 21/2-



#### Driving in selector rod bush

- Drive in bush until tool contacts stop.



#### Pulling needle bearing out of clutch housing


A - Counter-support, e.g. -Kukko 22/2-

B - Internal puller 23.5 ... 30 mm, e.g. -Kukko 21/4-




#### Note

The needle bearing is destroyed during removal and must be renewed.




#### Pressing needle bearing into clutch housing

Before pressing in, place reverse shaft thrust washer -B- on needle bearing -A-.



#### Pressing reverse gear selector fork shaft into clutch housing



#### 17.2 Renewing input shaft oil seal

Special tools and workshop equipment required

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


◆ Extractor tool -T20143/1-




♦ Thrust piece -T40008-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.





♦ Sealing grease -G 052 128 A1-

#### **Procedure**


- Gearbox removed ⇒ page 82.
- Remove clutch slave cylinder with release bearing ⇒ page 36 .
- Pry out input shaft oil seal using extractor tool -T20143/1- .




#### Note


Take care not to damage contact surface for oil seal on input shaft.

- Pack space between sealing lip and dust lip -arrow- half-full with sealing grease -G 052 128 A1- .
- Lightly oil outer circumference of new oil seal.





- Drive in oil seal until flush using thrust piece -T40008- .
- Install clutch slave cylinder with release bearing ⇒ page 36.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Exploded view - selector mechanism in gearbox 18




Note

Lubricate all bearings and moving surfaces with grease -G 000 450 02-.




#### 18.1 Renewing oil seal for selector shaft

Special tools and workshop equipment required



Extractor tool -T20143/1-



Sealing grease -G 052 128 A1-

#### **Procedure**

Remove air cleaner housing completely ⇒ Rep. Gr. 23 or ⇒
Protected by copyright. Copying for private or comm Rep. Gr. 24. nercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability

with respect to the correctness of information in this doc

#### Plastic gate relay lever -1-:

- Pull locking mechanism forwards in direction of -arrow 1- onto stop and then turn to left in direction of -arrow 2- to lock.
- Press gate relay lever forwards (in direction of -arrow 3-) and at the same time pull gate selector cable out of cable endpiece.
- Removing gate relay lever (with detent catch) <u>⇒ page 75</u>
- Removing gate relay lever (with clip) ⇒ page 75

# N34-10891

#### Metal gate relay lever:

Detach circlip -2- and push gate relay lever -3- sideways out of bearing.


#### Continued for all vehicles:




#### Note

If the gearbox bracket makes it impossible to remove the gate relay lever, remove the gate selector cable from the gate relay lever. Guide the slide block out of gearbox selector lever.


Remove nut -4- and take out gearbox selector lever -1-.



Pry out oil seal using extractor tool -T20143/1-.



- Lightly oil outer circumference of new oil seal.
- Drive in new oil seal onto stop (take care to keep oil seal straight).
- Pack space between sealing lip and dust lip -arrow- half full with sealing grease -G 052 128 A1- .



- Drive in oil seal using tube -VW 423-
- Install gearbox selector lever and gate relay lever ⇒ page 70 / ⇒ page 72 .




#### Note

The gearbox selector lever can only be installed in one position.

Install air cleaner housing ⇒ Rep. Gr. 23 or ⇒ Rep. Gr. 24.

Protected by copyright. Copying for private or commercial purposes, in part or in where permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept a with respect to the correctness of information in this document. Copyright by AUD




#### 18.2 Removing and installing selector shaft

#### Removing

Remove air cleaner housing completely ⇒ Rep. Gr. 23 or ⇒ Rep. Gr. 24.

#### Plastic gate relay lever -1-:

- Pull locking mechanism forwards in direction of -arrow 1- onto stop and then turn to left in direction of -arrow 2- to lock.
- Press gate relay lever forwards (in direction of -arrow 3-) and at the same time pull gate selector cable out of cable endpiece.
- Removing gate relay lever (with detent catch) <u>⇒ page 75</u>
- Removing gate relay lever (with clip) ⇒ page 75



#### Metal gate relay lever:

Detach securing clip -2- and push gate relay lever -3- sideways out of bearing.

#### Continued for all vehicles:



#### Note

If the gearbox bracket makes it impossible to remove the gate relay lever, remove the gate selector cable from the gate relay lever. Guide the slide block out of gearbox selector lever.

- Remove nut -4- and take out gearbox selector lever -1-.
- Put selector shaft in neutral position.



#### Caution

Make sure that the selector shaft is not locked in position by the angled rod -arrow- when carrying out the following steps.

- Remove reversing light switch -F4- -1-.
- Remove locking bolt -2-.
- Remove bolts -3-.
- Pull selector shaft with selector mechanism cover -4- out of gearbox housing.

#### Installing


- Tightening torques <u>⇒ page 156</u>, <u>⇒ page 201</u>
- Now push selector shaft -1- against stop sleeve -2- in direction of -arrow- and run selector finger -3- down through selector forks and onto stop.
- Selector mechanism cover -4- should be parallel to joint surface on gearbox housing.
- Selector shaft should move up and down easily (gate selector movement).





#### Note

If the selector mechanism cover is not parallel with the joint surface, the selector shaft is not seated in its bottom mounting.

> Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.








- Tighten bolts -3- for selector mechanism cover -4-.
- Screw in locking bolt -2-; angled rod -arrow- must be released.
- Install reversing light switch -F4- -1-.
- Install gearbox selector lever and gate relay lever <u>⇒ page 70</u> / ⇒ page 72



#### Note

The gearbox selector lever can only be installed in one position.

- Install air cleaner housing ⇒ Rep. Gr. 23 or ⇒ Rep. Gr. 23 or ⇒ Rep. Gr. 24 or ⇒ Rep. Gr. 25 or ⇒ Rep. with respect to the correctness of information in this document. Copyright by AUDI AG.



#### 19 Exploded view - selector forks

#### 1 - Damper rubber


- Can be pulled out of and inserted into selector rod by hand
- 2 Selector rod with selector fork for 1st and 2nd gear
- 3 Selector rod with selector fork for 3rd and 4th gear

#### 4 - Selector rod with selector fork for 5th and 6th gear

☐ From gearbox manufacturing date 25 05 9 onwards: also serves as bearing for reverse gear selector fork

#### 5 - Reverse gear selector fork

- Ball sleeve is not fitted from gearbox manufacturing date 06 03 6 ⇒ Item 6 (page 206)
- Gradually discontinued
- □ Different types of reverse gear selector forks are fitted according to version
- □ From gearbox manufacturing date 25 05 9 onwards: mounted on selector rod for 5th/6th gear selector fork
- □ Identification of different types of reverse gear selector forks ⇒ page 207
- ☐ For correct version, refer to ⇒ Electronic parts catalogue




#### 6 - Ball sleeve

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not

- Discontinued on gearboxes manufactured from 06103 be onwards mation in this document. Copyright by AUDI AG.
- □ Gradually discontinued
- ☐ For correct version, refer to ⇒ Electronic parts catalogue
- □ Pulling out ⇒ page 208
- □ Pressing in ⇒ page 208


Dimension "a" (mm)	Gearbox manufactur- ing date	Reverse gear selector fork	Mounting	
24	Up to 05 03 6	With ball sleeve	On reverse gear selector fork	
18	From 06 03 6 to 24 05 9	Without ball sleeve	shaft <u>⇒ page 196</u>	
15	From 25 05 9 onwards	Without ball sleeve	On selector rod with selector fork for 5th and 6th gear ⇒ page 179	



#### Dismantling and assembling selector forks 19.1

#### Special tools and workshop equipment required


- Press tool -VW 411-
- Tube -VW 423-
- Press tool -VW 431-
- -1- Kukko internal puller 21/3
- -4- Kukko 22/1 countersupport




#### Pulling out ball sleeve for reverse gear selector fork

A - Internal puller 18 ... 23 mm, e.g. -Kukko 21/3-

B - Counter-support , e.g. -Kukko 22/1-



#### Pressing in ball sleeve for reverse gear selector fork



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

## Gears, shafts

## Exploded view - input shaft



#### Note

- ♦ Mounting gearbox on assembly stand ⇒ page 125
- Refer to technical data when installing new gears ⇒ page 2.
- Lubricate all bearings on input shaft with gear oil before installing.

#### 1 - Circlip

- □ For grooved ball bearing on input shaft
  - ⇒ Item 6 (page 210)
- □ Removing and installing ⇒ page 159

#### 2 - Spacer


- ☐ Outside diameter = 78.6
- ☐ Can only be fitted on modified gearbox housing (from gearbox manufacturing date 10 04 6 to approx. 20 01 8) ⇒ page 215
- ☐ For correct version, refer to ⇒ Electronic parts catalogue

#### 3 - Gearbox housing

- ☐ From gearbox manufacturing date 10 04 6 to approx. 20 01 8: modified in area of seat for grooved ball bearing ⇒ Item 6 (page 210) to match spacers ⇒ Item 2 (page 209) and ⇒ Item 4 (page 209) ⇒ page 215
- ☐ From gearbox manufacturing date approx. 21 01 8 onwards, grooved ball bearing and bearing seat have flattened sides ⇒ page 215
- ☐ For correct version, refer to ⇒ Electronic parts catalogue

#### 4 - Spacer

- ☐ Outside diameter = 85 mm
- Can only be fitted on modified gearbox housing (from gearbox manufacturing date 10 04 6 to approx. 20 01 8) <del>⇒ page 215</del>
- ☐ For correct version, refer to ⇒ Electronic parts catalogue



_		O: !!	
5	_	Circli	n
v			•

When grooved ball bearing <u>⇒ Item 6 (page 210)</u> or input shaft <u>⇒ Item 8 (page 210)</u> are renewed: determine thickness of required circlip <u>⇒ page 214</u>

#### 6 - Grooved ball bearing

- Always renew
- □ Pulling off ⇒ page 212
- □ Installation position ⇒ page 213
- □ Pressing on ⇒ page 213
- ☐ From gearbox manufacturing date approx. 21 01 8 onwards, grooved ball bearing and bearing seat have flattened sides ⇒ page 215

#### 7 - 5th gear wheel

- ☐ Pressing off ⇒ page 213
- ☐ Installation position: Circular slot -arrow- faces towards grooved ball bearing ⇒ Item 6 (page 210)
- □ Pressing on ⇒ page 213

#### 8 - Input shaft

☐ With 3rd/4th and 6th gear wheels

#### 9 - Roller bearing

- With circlip
- □ Pulling out ⇒ page 214
- □ Pressing in ⇒ page 214
- Installation position: Circlip in bearing faces towards input shaft

#### 10 - Clutch housing




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### 1.1 Dismantling and assembling input shaft


#### Special tools and workshop equipment required

- ♦ Thrust plate -VW 401-
- Thrust plate -VW 402-
- Press tool -VW 407-
- Press tool -VW 412-
- Press tool -VW 431-
- Press tool -VW 432-






- Press tool -VW 454-
- Mandrel -30 505-
- Thrust plate -40 105-
- Tube -2040-
- -1- Kukko internal puller 21/5
- -2- Puller 18/1
- -3- Splitter 17/1 and 17/2
- -4- Kukko 22/2 countersupport




# Pulling off grooved ball bearing opyright. Copying for private or commercial purposes, in permitted unless authorised by AUDI AG. AUDI AG does not guarantee Remove circlip on input shaft to the correctness of information in this document. Copying

- Before setting up puller, position press tool -VW 431- and thrust plate -40 105- on input shaft.
- Apply splitter -B- at circular slot for circlip in bearing.
- A Puller , e.g. -Kukko 18/1-
- B Splitter 12...75 mm, e.g. -Kukko 17/1-




#### Pressing off 5th gear wheel

A - Splitter 22...115 mm, e.g. -Kukko 17/2-




#### Pressing on 5th gear wheel

Slot -arrow- on gear wheel must face upwards.




### Pressing on grooved ball bearing with rubber ring

If grooved ball bearing is fitted with a rubber ring -arrow-, press tool -VW 454- must be applied so that shoulder -A- faces towards press tool -VW 412- .



#### Installation position of grooved ball bearing

- Installation position of grooved ball bearing: Slot for circlip faces upwards -arrow A- and shoulder -arrow B- must face towards 5th gear wheel.
- Then determine thickness of required circlip ⇒ page 214 and install circlip.




Protected by copyright. Copying for private or commercial purposes, in part or in who permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept an with respect to the correctness of information in this document. Copyright by AUDI

#### Determining thickness of circlip

- Install a 1.86 mm thick circlip -A- in slot on input shaft and press circlip upwards.
- Measure gap between grooved ball bearing -B- and fitted circlip -A- using feeler gauge -C-.
- Remove circlip fitted for measurement.
- Determine thickness of required circlip according to table; for part number refer to ⇒ Electronic parts catalogue.


The following circlips are available:

Measured value (mm)	Circlip thickness (mm)	Axial clearance (mm)
0.01 0.05	1.86	0.01 0.05
0.05 0.07	1.89	0.01 0.05
0.07 0.10	1.92	0.01 0.05
0.10 0.13	1.95	0.01 0.05
0.13 0.16	1.98	0.01 0.05



#### Pulling roller bearing out of clutch housing


- When pulling out, compress circlip -arrow- for roller bearing using pliers -C-.
- A Counter-support, e.g. -Kukko 22/2-
- B Internal puller 30 ... 37 mm , e.g. -Kukko 21/5-



Protected by copyright. Copying for priv permitted unless authorised by AUDI A with respect to the correctness of inf

#### Pressing roller bearing into clutch housing

- When pressing in, compress circlip -arrow- for roller bearing using pliers -A-.
- Remove pliers before roller bearing seats in its final position.
- The circlip must engage in the groove in the clutch housing.




#### 1.2 Modifications in area of grooved ball bearing

#### From gearbox manufacturing date 10 04 6 to approx. 20 01 8:

One spacer above and one spacer below bearing seat for grooved ball bearing ⇒ Item 6 (page 210).

#### Above bearing seat:

Bearing seat		Spacer above bear- ing seat
Up to gearbox man- ufacturing date 09 04 6	Dimension "a" = 10 mm	No
From gearbox man- ufacturing date 10 04 6 to 20 01 8	Dimension "a" = 10.7 mm	Yes
From gearbox man- ufacturing date ap- prox. 21 01 8 on- wards	Below bearing seat: Flattened side for grooved ball bearing	No




#### Below bearing seat -arrow-:

From gearbox manufacturing date 10 04 6 to approx. 20 01 8 slightly deeper

The bearing seat for the grooved ball bearing -arrow- is slightly deeper to accommodate the spacer below the bearing ⇒ Item 6 (page 210)

Below bearing seat		Spacer below bear- ing seat
Up to gearbox man- ufacturing date 09 04 6	Not modified	No
From gearbox man- ufacturing date 10 04 6 to 20 01 8	Slightly deeper	Yes
From gearbox manufacturing date approx. 21 01 8 onwards	Flattened side -B- for grooved ball bearing -A-	No






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

From gearbox manufacturing date approx. 21 01 8 onwards, grooved ball bearing -A- and bearing seat -B- have flattened sides

If sides are flattened, a spacer must not be fitted above or below grooved ball bearing.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### 2 Exploded view - output shaft for 1st - 4th gear



- ♦ Mounting gearbox on assembly stand ⇒ page 125.
- Carry out output shaft adjustment ⇒ page 230 if the output shaft or tapered roller bearings have been renewed.
- Refer to technical data page 2 when installing new gears or a new output shaft.
- Always renew both tapered roller bearings together.



#### 10 - Outer ring for 2nd gear

- ☐ Fit on synchro-ring ⇒ Item 9 (page 217)
- ☐ Renew if scored or if there are visible traces of wear
- ☐ Installation position ⇒ page 226

#### 11 - 2nd gear synchro-ring

- ☐ Checking for wear ⇒ page 226
- ☐ Installation position ⇒ page 226

12 - I	Locking collar with synchronising hub for 1st and 2nd gear
	Press off together with 2nd speed selector gear after removing circlip <u>⇒ Item 13 (page 218)</u> ⇒ page 225
	Dismantling ⇒ page 227
	0 0 , 0 = 0
	Installation position <u>⇒ page 227</u>
	Pressing on <u>⇒ page 227</u>
13 - (	Circlip
	1st gear synchro-ring
	Checking for wear ⇒ page 226
	Assemble so that the recesses engage on the locking pieces on the locking collar ⇒ Item 12 (page 217)
	Outer ring for 1st gear
	Insert in synchro-ring <u>⇒ Item 14 (page 218)</u> ; installation position <u>⇒ page 228</u>
	Renew if scored or if there are visible traces of wear
	Synchro-ring
	(Inner ring for 1st gear)
	Checking for wear <u>⇒ page 226</u> Check lugs for scoring
	Installation position ⇒ page 228
	Needle bearing
	For 1st gear
	1st speed selector gear
	Installation position ⇒ page 228
	Thrust washers
	For 1st and 4th gear
	2x Insert lug on thrust washer in hole on output shaft
	Circlip
	Holds thrust washers <u>⇒ Item 19 (page 218)</u> in position on output shaft
21 - I	Needle bearing
	For 4th gear
22 - 4	4th speed selector gear
23 - 4	4th gear synchro-ring
	Checking for wear <u>⇒ page 229</u>
24 - I	Locking collar with synchronising hub for 3rd and 4th gear
	Pull off together with 4th speed selector gear after removing circlip <u>⇒ Item 25 (page 218)</u> <u>⇒ page 225</u>
	Dismantling ⇒ page 227
	Installation position: Locking collar/synchronising hub ⇒ page 228
	Assembling locking collar/synchronising hub <u>⇒ page 227</u> and <u>⇒ page 227</u> Pressing on <u>⇒ page 229</u>
25 _ (	Circlip
	3rd gear synchro-ring  Checking for wear ⇒ page 226  Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability
	with respect to the correctness of information in this document. Copyright by AUDI AG.
۱ - ر ت	Outer ring for 3rd gear Insert in synchro-ring <u>⇒ Item 26 (page 218)</u> ; installation position <u>⇒ page 228</u>
	Renew if scored or if there are visible traces of wear
_	


28 - S	Synchro-ring
	(Inner ring for 3rd gear)
	Checking for wear ⇒ page 226
	Check lugs for scoring
	Installation position ⇒ page 228
29 - N	Needle bearing
	For 3rd gear
30 - 3	ard speed selector gear
	Installation position <u>⇒ page 228</u>
31 - T	apered roller bearing inner race
	Pulling off ⇒ page 224 pyright. Copying for private or commercial purposes, in part or in whole, is not
	Pressing on ⇒ page 229 the correctness of information in this document. Copyright by AUDI AG.
32 - C	Circlip Circlip
	When tapered roller bearing <u>⇒ Item 31 (page 219)</u> or output shaft <u>⇒ Item 6 (page 217)</u> are renewed: determine thickness of required circlip <u>⇒ page 229</u>
33 - T	apered roller bearing outer race
	Pulling out ⇒ page 230
	Pressing in ⇒ page 230
34 - S	Shim
	Determining thickness <u>⇒ page 230</u>

35 - Gearbox housing

#### Dismantling and assembling output shaft for 1st - 4th gear 2.1

#### Special tools and workshop equipment required


- Thrust plate -VW 401-
- Thrust plate -VW 402-
- Press tool -VW 407-
- Press tool -VW 408A-
- Press tool -VW 412-
- Tube -VW 415A-






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- ♦ Support plate -VW 309-Support clamp -VW 313-
- ♦ Gearbox support -VW 353-
- Press tool -VW 431-
- Press tool -VW 433-
- ♦ Press tool -VW 454-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


- Thrust pad -VW 512-
- Tube -VW 516-
- Tube -VW 519-
- Multi-purpose tool -VW 771-
- Support plate -VW 801-
- Thrust plate -40 105-







Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- Sleeve from engine and gearbox support supplement -VW 540/1 B-
- ◆ Drift sleeve -40 20-
- Press tool -40 21-
- Thrust piece -2050-
- Tapered roller bearing puller -V.A.G 1582-
- ♦ Adapter -V.A.G 1582/7-



-1- Kukko internal puller 21/7 and 21/8






- ♦ -2- Puller 18/2
- -3- Splitter 17/2
- -4- Kukko 22/2 counter-support

Pulling dished washer -A- out of output shaft

#### Pressing dished washer into output shaft onto stop


Dimension -a- = 2 mm



#### Pulling out tapered roller bearing outer race

A - Counter-support, e.g. -Kukko 22/2-

B - Internal puller 56 ... 70 mm , e.g. -Kukko 21/8-




#### Pressing tapered roller bearing outer race into clutch housing

Support clutch housing with drift sleeve -40 - 20- directly below bearing mounting.

VW 408A 2050 Protected by copyrig ot any liability permitted unless ar with respect to th N35-0251


#### Pulling off tapered roller bearing inner race

- Remove circlip.
- Before setting up puller, position press tool -VW 431- and thrust plate -40 105- on input shaft.



#### Pulling off 3rd and 4th gear synchronising hub/locking collar with 4th speed selector gear


- Remove circlip before pulling off.
- A Puller , e.g. -Kukko 18/2-
- B Splitter 22...115 mm, e.g. -Kukko 17/2-



#### Pressing off 1st and 2nd gear locking collar and synchronising hub


- Remove circlip.
- Press off selector gear and locking collar/synchronising hub together.

Protected by copyright. Copying for private or commercial permitted unless authorised by AUDI AG. AUDI AG does with respect to the correctness of information in this doc




#### Pressing off tapered roller bearing inner race

A - Splitter 22...115 mm, e.g. -Kukko 17/2-




#### Pressing on tapered roller bearing inner race



#### Checking inner ring for 1st, 2nd and 3rd gear for wear

Press inner ring onto tapered seat on selector gear and measure gap -a- using a feeler gauge.


Gap -a-	Installation depth	Wear limit
1st, 2nd and 3rd gear	0.751.25 mm	0.3 mm



#### Checking 1st, 2nd and 3rd gear synchro-rings for wear


Press synchro-ring, outer ring and inner ring onto tapered seat on selector gear and measure gap -a- using a feeler gauge.

Gap -a-	Installation depth	Wear limit
1st, 2nd and 3rd gear	1.21.8 mm	0.5 mm



#### Installation position of outer ring, inner ring and synchro-ring of 2nd gear

- Place inner ring -A- on 2nd speed selector gear.
- The angled lugs -arrows 1- point towards outer ring -B-.
- Fit outer ring -B-.
- Lugs -arrows 2- engage in slots -arrows 3- on selector gear.
- Fit synchro-ring -C-.
- Slots -arrows 4- engage on lugs -arrows 1- on inner ring -A-.



Protected by copyright. Copying for priva permitted unless authorised by AUDI A


with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Dismantling and assembling 1st/2nd gear and 3rd/4th gear locking collar/synchronising hub

- Take off springs -1- before dismantling.
- 1 -Spring
- 2 -Locking piece
- Locking collar
- Synchronising hub
- To assemble, slide locking collar over synchronising hub.
- On 3rd and 4th gear the wider collar of the synchronising hub and the shoulder on the locking collar face in the same direction.
- Installation position: Narrower recesses in synchronising hub align with recesses in locking collar

#### Assembling 1st/2nd gear and 3rd/4th gear locking collar/synchronising hub


- Locking collar is pushed over synchronising hub.
- Insert locking pieces and install springs offset at 120°.
- Angled end of spring must locate in hollow locking piece.



Protected by copyright. Copying for private or co permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information


#### Installation position of 1st and 2nd gear locking collar/synchronising hub

Identification groove -arrow 1- and narrow shoulder -arrow 2on synchronising hub point towards 1st gear.




### Pressing on 1st and 2nd gear locking collar/synchronising hub

Then install circlip.




#### Installation position of 1st or 3rd gear outer ring

Lugs -arrows- face towards synchronising hub/locking collar -A-.



#### Installation position of synchro-ring -A- (inner ring for 1st or 3rd gear)


Lugs -arrows 1- locate in the recesses -arrows 2- in the synchro-ring -B-.



Protected by copyright. Copying for private or comm permitted unless authorised by AUDI AG. AUDI AG with respect to the correctness of information in t


#### Installation position of 1st and 3rd speed selector gear

The higher shoulder -A- faces towards 2nd or 4th gear -B-. The recesses in the shoulder -arrows- engage on the lugs on the outer ring ⇒ page 228.




#### Installation position of 3rd and 4th gear locking collar/synchronising hub

The wider shoulder on the synchronising hub -arrow- faces towards 3rd gear.



## Pressing on 3rd and 4th gear synchronising hub with locking col-

Then install circlip.



#### Checking synchro-ring for 4th gear for wear

Press synchro-ring onto tapered seat on selector gear and measure gap -a- with a feeler gauge.


Gap -a-	Installation depth	Wear limit
4th gear	1.01.7 mm	0.5 mm

Protected by copyright. Copying for private or commercial

purposes, in part or in whole, is not not guarantee or accept any llability permitted unless authorised by AUDI AG. AUDI AG does not guarantee with respect to the correctness of information in this document. Copyright by AUDI AG

#### Pressing on tapered roller bearing inner race

Determine thickness of required circlip <u>⇒ page 229</u> and install circlip.




#### **Determining thickness of circlip**

- Determine the thickest circlip that will just fit and install it. For part number refer to ⇒ Electronic parts catalogue.


The following circlips are available:

Circlip thickness (mm)		
1.79	1.83	1.86
1.89	1.92	1.95
1.98		




#### Pulling tapered roller bearing outer race out of gearbox housing

- A Counter-support, e.g. -Kukko 22/2-
- B Internal puller 46 ... 58 mm , e.g. -Kukko 21/7-



#### Pressing tapered roller bearing outer race into gearbox housing

- Fit shim below outer race.
- Support gearbox housing with thrust piece -2050- directly below bearing mounting.



### 2.2 Adjusting output shaft for 1st - 4th gear

The output shaft must be re-adjusted when the following components have been renewed:

- Gearbox housing
- Clutch housing
- ♦ Output shaft for 1st 4th gear
- ◆ Tapered roller bearings for output shaft


Table of adjustments ⇒ page 274




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Special tools and workshop equipment required

- Universal dial gauge bracket -VW 387-
- ♦ Press tool -VW 407-
- Press tool -VW 433-
- Assembly tool -VW 792-
- Support plate -VW 801-
- Thrust piece -2050-




♦ Dial gauge -VAS 6080-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


-1- Kukko internal puller 21/7



♦ -4- Kukko 22/2 counter-support


#### **Adjusting**

- Mounting gearbox on assembly stand <u>⇒ page 125</u>.
- Sealing surfaces of clutch and gearbox housings must be free of sealant.
- When taking measurements, install only the shaft to be measured.
- Press tapered roller bearing outer race with shim (thickness 1.70 mm) into gearbox housing. Support gearbox housing with thrust piece -2050- directly below bearing mounting.
- Fit complete 1st to 4th gear output shaft into clutch housing.



Protected by copyright. Copying for private or commercial pur permitted unless authorised by AUDI AG. AUDI AG does not with respect to the correctness of information in this docun

Fit gearbox housing and tighten bolts -A- and -B- diagonally to correct torque.




- Set up measuring tools and secure with bolt -arrow- to clutch housing.
- Set dial gauge -VAS 6080- (3 mm measuring range) to "0" with 1 mm preload.
- Loosen clutch housing/gearbox housing securing bolts diagonally until output shaft is free to move in gearbox housing.
- Read off play on gauge and note reading (example: 0.14 mm).



#### Note

If no play is indicated on the dial gauge when the clutch housing/ gearbox housing securing bolts are loosened, fit a 1.95 mm shim (part number -084 409 383 AS- ), or if necessary a 2.20 mm shim "(part number -084 409 383 BD-) for performing the measurement.



#### **Determining thickness of shim**

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not The specified bearing preload is attained by subtracting the meas-authorised by AUDI AG. AUDI AG does not guarantee or accept any liability ured value (0.14 mm) from the inserted shim (1.70 mm) randpect to the correctness of information in this document. Copyright by AUDI AG. adding a constant value for preload (0.20 mm).

#### **Example:**

Inserted shim	1.70 mm
<ul> <li>Measured value</li> </ul>	0.14 mm
+ Preload (constant value)	0.20 mm
Thickness of shim	1.76 mm


Select a shim of the required thickness from the table. For part number refer to ⇒ Electronic parts catalogue.

The following shims are available:


Thickness of shims in mm			
1.45	1.70	1.95	2.20
1.50	1.75	2.00	2.25
1.55	1.80	2.05	
1.60	1.85	2.10	
1.65	1.90	2.15	

The exact shim thickness required can be obtained by combining shims of different thicknesses.

- Detach gearbox housing and pull tapered roller bearing outer race out of gearbox housing.
- A Counter-support, e.g. -Kukko 22/2-
- B Internal puller 46 ... 58 mm, e.g. -Kukko 21/7-
- Remove inserted shim (1.70 mm thick) from gearbox housing.



Press in tapered roller bearing outer race together with the correct shim (in example 1.75 mm). Support gearbox housing with thrust piece -2050- directly below bearing mounting.




hole, is not any liability

Protected by copyrig permitted unless aut with respect to the

#### Checking adjustment


- Required shim installed (thickness as determined above)
- Set up measuring tools and secure with bolt -arrow- to clutch housing.
- Set dial gauge -VAS 6080- (3 mm measuring range) to "0" with 1 mm preload.
- Loosen clutch housing/gearbox housing securing bolts diagonally until output shaft is free to move in gearbox housing.
- If the correct shim has been selected, the dial gauge should now indicate a value between 0.15 and 0.25 mm.



#### 3 Exploded view - output shaft for 5th, 6th and reverse gear



- ♦ Mounting gearbox on assembly stand <u>⇒ page 125</u>.
- Carry out output shaft adjustment ⇒ page 245 if the output shaft or tapered roller bearings have been renewed.
- Refer to technical data ⇒ page 2 when installing new gears or a new output shaft.
- Always renew both tapered roller bearings together.



- 10 Reverse selector gear
- 11 Sleeve
  - ☐ Press off with reverse selector gear ⇒ page 241
  - ☐ Installation position: Wide shoulder of sleeve faces towards reverse selector gear
  - □ Pressing on ⇒ page 243
- 12 Circlip
- 13 Needle bearing
  - ☐ For 6th gear

6-speed manual gearbox 02Q, four-wheel drive - Edition 10.2009
14 - 6th speed selector gear
15 - 6th gear synchro-ring
☐ Checking for wear <u>⇒ page 243</u>
16 - Locking collar with synchronising hub for 5th and 6th gear
<ul> <li>Press off together with 6th speed selector gear after removing circlip ⇒ Item 17 (page 236)</li> <li>⇒ page 241</li> </ul>
☐ Dismantling ⇒ page 243
Assembling locking collar/synchronising hub ⇒ page 243 and ⇒ page 243
□ Pressing on ⇒ page 244
17 - Circlip  Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability
with respect to the correctness of information in this document. Copyright by AUDI AG.  18 - Needle bearing
☐ For 5th gear
19 - 5th gear synchro-ring
☐ Checking for wear <u>⇒ page 243</u>
20 - 5th speed selector gear
21 - Tapered roller bearing inner race
□ Pulling off <u>⇒ page 241</u>
☐ Pressing on ⇒ page 244
22 - Circlip
When tapered roller bearing ⇒ Item 21 (page 236) or output shaft ⇒ Item 5 (page 235) are renewed: determine thickness of required circlip ⇒ page 244
23 - Tapered roller bearing outer race
☐ Pulling out <u>⇒ page 245</u>
□ Pressing in ⇒ page 245
24 - Shim
Determining thickness ⇒ page 245
25 - Gearbox housing

26 - Spring

27 - Locking collar 28 - Synchronising hub 29 - Locking pieces (3x)


☐ Installation position <u>⇒ page 243</u>

☐ Installation position ⇒ page 243

#### Dismantling and assembling output shaft for 5th, 6th and reverse gear 3.1


#### Special tools and workshop equipment required

- ♦ Thrust plate -VW 401-
- Thrust plate -VW 402-
- Press tool -VW 407-
- Press tool -VW 408 A-
- Press tool -VW 412-
- Tube -VW 415 A-






- Press tool -VW 431-
- Installing sleeve -VW 455-
- Thrust pad -VW 510-
- Tube -VW 516-
- Tube -VW 519-
- Thrust plate -30 11-



- ♦ Thrust plate -40 105-
- Drift sleeve -40 20-
- Thrust piece -2050-
- Tube -3296-
- Tapered roller bearing puller -V.A.G 1582-
- ♦ Adapter -V.A.G 1582/4-






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.



- Adapter -V.A.G 1582/7-
- Press tool -VW 433-
- Press tool -VW 454-
- Support rails -VW 457-
- Support plate -VW 801-
- -1- Kukko internal puller
- -3- Splitter 17/2
- -4- Kukko 22/2 countersupport



#### Pulling out tapered roller bearing outer race


A - Counter-support, e.g. -Kukko 22/2-

B - Internal puller 46...58 mm, e.g. -Kukko 21/7-




#### Note

After pulling out, check shim for damage and renew if necessary.




#### Pressing tapered roller bearing outer race into clutch housing

- Fit shim below outer race.
- Support clutch housing with drift sleeve -40 20- directly below bearing mounting.




#### Pulling off tapered roller bearing inner race

- Remove circlip.
- Before setting up puller, position press tool -VW 431- and thrust plate -40 105- on output shaft.




#### Pressing off 5th and 6th gear synchronising hub/locking collar with 6th speed selector gear

Remove circlip before pressing off.



#### Pressing off sleeve -A- with reverse selector gear


Remove circlip before pressing off.



Protected by copyright. Copying for private or commercial purposes, in permitted unless authorised by AUDI AG. AUDI AG does not guarantee with respect to the correctness of information in this document. Cop


#### Pressing off reverse gear synchronising hub

- Remove circlip before pressing off.
- A Splitter 22...115 mm , e.g. -Kukko 17/2-




#### Pulling off tapered roller bearing inner race

Before applying puller, place thrust plate -30 - 11- on output shaft.




#### Installation position of reverse gear synchronising hub

Stop -arrow A- for reverse gear locking collar faces towards gear teeth on output shaft -arrow B-.



#### Pressing on reverse gear synchronising hub


Then install circlip.



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Pressing on sleeve -A-


- Installation position: Wide shoulder faces towards reverse selector gear
- Then install circlip.



#### Checking 5th and 6th gear synchro-ring for wear

Press synchro-ring onto tapered seat on selector gear and measure gap -a- with a feeler gauge.

Gap -a-	Installation depth	Wear limit
5th and 6th gear	1.01.7 mm	0.5 mm





#### Dismantling and assembling 5th and 6th gear-locking/collar/and/or private synchronising hub synchronising hub with respect to the correctness of inform

- Take off springs -1- before dismantling.
- 1 -Spring
- 2 -Locking piece
- 3 -Locking collar
- Synchronising hub
- To assemble, slide locking collar over synchronising hub.
- Installation position: Narrower recesses for locking pieces in synchronising hub align with recesses in locking collar

#### Assembling 5th and 6th gear locking collar/synchronising hub


- Locking collar is pushed over synchronising hub.
- Insert locking pieces and install springs offset at 120°.
- Angled end of spring must locate in hollow locking piece.






#### Pressing on 5th and 6th gear locking collar/synchronising hub

- Then install circlip.



#### Pressing on tapered roller bearing inner race

 Then determine thickness of required circlip ⇒ page 244 and install circlip.




#### Determining thickness of circlip


 Determine the thickest circlip that will just fit and install it. For part number refer to ⇒ Electronic parts catalogue .

The following circlips are available:

Circlip thickness (mm)			
1.79	1.83	1.86	
1.89	1.92	1.95	
1.98			




### Pressing on tapered roller bearing inner race



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.


#### Pulling tapered roller bearing outer race out of gearbox housing

- A Counter-support, e.g. -Kukko 22/2-
- B Internal puller 46...58 mm , e.g. -Kukko 21/7-



#### Pressing tapered roller bearing outer race into gearbox housing

Place thrust piece -2050- directly under bearing mounting to support gearbox housing.



#### 3.2 Adjusting output shaft for 5th, 6th and reverse gear

The output shaft must be re-adjusted when the following components are renewed:


- Gearbox housing
- Clutch housing
- ♦ Output shaft for 5th, 6th and reverse gear
- ◆ Tapered roller bearings for output shaft

Table of adjustments ≤ page 274te or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




#### Special tools and workshop equipment required


- Universal dial gauge bracket -VW 387-
- Press tool -VW 407-
- Press tool -VW 433-
- Assembly device -VW 792-
- Support plate -VW 801-
- Thrust piece -2050-



Dial gauge -VAS 6080-




◆ -1- Kukko internal puller 21/7




◆ -4- Kukko 22/2 counter-support

#### **Adjusting**

- Gearbox removed ⇒ page 82 and mounted on assembly stand ⇒ page 125 .
- Sealing surfaces of clutch and gearbox housings must be free of sealant.
- When taking measurements, install only the shaft to be measured.
- Press tapered roller bearing outer race with shim (thickness 1.70 mm) into gearbox housing. Support gearbox housing with thrust piece -2050- directly below bearing mounting.
- Now insert complete 5th/6th/reverse/geargoutput/shaft/int or commercial clutch housing. permitted unless authorised by AUDI AG. AUDI AG does with respect to the correctness of information in this do



Fit gearbox housing and tighten bolts -A- and -B- diagonally to correct torque.



- Attach measuring equipment. Put washers of a total thickness of 8 mm on bolt -arrow- securing assembly device -VW 792to clutch housing.
- Set dial gauge -VAS 6080- (3 mm measuring range) to zero with 1 mm preload.
- Loosen clutch housing/gearbox housing securing bolts diagonally until output shaft is free to move in gearbox housing.
- Read off play on gauge and note reading (example: 0.25 mm).



#### Note

If no play is indicated on the dial gauge when the clutch housing/ gearbox housing securing bolts are loosened, fit a 1.95 mm shim (part number -084 409 383 AS- ), or if necessary a 2.20 mm shim (part number -084 409 383 BD- ) for performing the measurement.



The specified bearing preload is attained by subtracting the measured value (0.25 mm) from the inserted shim (1.70 mm) and adding a constant value for preload (0.20 mm).

#### Example:

Inserted shim		1.70 mm	
<ul> <li>Measured value</li> </ul>		0.25 mm	
+ Preload (constant value	e)	0.20 mm	
Thickness of shim		1.65 mm	X

Select a shim of the required thickness from the table. For part number refer to ⇒ Electronic parts catalogue.


The following shims are available:


Thickness of shims in mm				
1.50	1.70	1.90	2.10	
1.55	1675tted unles	1.90 pyright. Copying for privals authoride95 AUDI A	G. AUDI <b>2</b> G <b>1</b> 5es not gi	
1.60	1.80 respect	to the correctness of info	rmation in this docume	
1.65	1.85	2.05	2.25	

s, in part or in whole, is not rantee or accept any liability Copyright by AUDI AG.


The exact shim thickness required can be obtained by combining shims of different thicknesses.

- Detach gearbox housing and pull tapered roller bearing outer race out of gearbox housing.
- A Counter-support, e.g. -Kukko 22/2-
- B Internal puller 46...58 mm, e.g. -Kukko 21/7-
- Remove inserted shim (1.70 mm thick) from gearbox housing.






Press in tapered roller bearing outer race together with the correct shim (in example 1.65 mm). Support gearbox housing with thrust piece -2050- directly below bearing mounting.



#### Checking adjustment

- Required shim installed (thickness as determined above)
- Attach measuring equipment. Put washers of a total thickness of 8 mm on bolt -arrow- securing assembly device -VW 792to clutch housing.
- Set dial gauge -VAS 6080- (3 mm measuring range) to zero with 1 mm preload.
- Loosen clutch housing/gearbox housing securing bolts diagonally until output shaft is free to move in gearbox housing.
- If the correct shim has been selected, the dial gauge should now indicate a value between 0.15 and 0.25 mm.






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Final drive - front differential 39 –

# Exploded view - flange shaft and oil seals on gearbox

#### 1 - Oil seal


- Between bevel box and gearbox
- Renewing with manual gearbox installed ⇒ page 253
- 2 Oil seal for selector shaft
  - □ Renewing ⇒ page 201
- 3 Gearbox selector lever
- 4 Nut
  - ☐ Tightening torque ⇒ Item 8 (page 70)
- 5 Oil seal for flange shaft (leftside)
  - □ Renewing ⇒ page 251
- 6 Flange shaft (left-side)
  - □ Removing and installing ⇒ page 250
- 7 Bolt
  - □ 33 Nm
  - □ Renew



#### Removing and installing flange shaft 1.1 (left-side)

Special tools and workshop equipment required

◆ Used oil collection and extraction unit -V.A.G 1782-



#### Removing

- Remove drive shaft (left-side) ⇒ Rep. Gr. 40.
- Place used oil collection and extraction unit -V.A.G 1782- below gearbox.
- Remove bolt securing flange shaft (left-side). To do so, screw two bolts into flange and counterhold flange shaft with suitable lever.
- Pull out flange shaft and spring.

#### Installing

• Tightening torque <u>⇒ page 250</u>


Installation is carried out in reverse sequence; note the following:

- Push flange shaft in against spring pressure securing bolt.
- Install drive shaft (left-side) ⇒ Rep. Gr. 40.
- Check gear oil level in manual gearbox and top up as required <u>⇒ page 138</u> .


#### 1.2 Renewing oil seal for flange shaft (leftside)

#### Special tools and workshop equipment required


♦ Thrust piece -3305-



Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




Extractor tool -T20143/2-




♦ Sealing grease -G 052 128 A1-

#### **Procedure**


- Gearbox in vehicle
- Remove flange shaft (left-side) ⇒ page 250 .
- Pull out flange shaft oil seal using extractor tool -T20143/2- .



- Lightly oil outer circumference of new oil seal.
- Drive in new oil seal onto stop (take care to keep oil seal straight) rotected by copyright. Copying for private or commercial purposes, in part or in whole, permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any li with respect to the correctness of information in this document. Copyright by AUDI AG




- Pack space between sealing lip and dust lip -arrow- half full with sealing grease -G 052 128 A1- .
- Install flange shaft (left-side) ⇒ page 250 .
- Check gear oil level in manual gearbox and top up as required <u>⇒ page 138</u>




#### 1.3 Renewing oil seal for bevel box with gearbox installed

Special tools and workshop equipment required

♦ Used oil collection and extraction unit -V.A.G 1782-




◆ Extractor tool -T20143/2-



Thrust piece -T10243-




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.




#### **Procedure**

- Bevel box removed ⇒ page 140 .
- Place drip tray -VAS 6208- underneath.
- Pry out oil seal for bevel box using extractor tool -T20143/2or oil seal extractor lever -VW 681- .

- Pack space between sealing lip and dust lip -arrow- half-full with sealing grease -G 052 128 A1- .
- Lightly oil outer circumference of new oil seal.



- Drive in oil seal onto stop.
- Check gear oil level in manual gearbox and top up as required <u>⇒ page 138</u>





Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Exploded view - flange shaft and oil seals on bevel box 2

#### 1 - Nut

- □ 480 Nm
- □ Renew

#### 2 - Output flange on bevel box

#### 3 - Output flange cap

□ Renew if damaged

#### 4 - Oil seal

- ☐ For output flange on bevel box
- □ Renewing ⇒ page 262

#### 5 - Oil seal on bevel box

- Between gearbox and bevel box
- □ Renewing ⇒ page 260

#### 6 - Bevel box

□ Removing and installing ⇒ page 140

#### 7 - Screw plug

- ☐ For oil drain hole on bevel box
- □ 60 Nm

#### 8 - Oil seal

- ☐ For flange shaft (rightside) on bevel box (out-
- □ Renewing ⇒ page 258

#### 9 - Screw plug

- ☐ For oil filler hole at bevel box
- ☐ Tightening torque ⇒ page 150

#### 10 - Bolt

- Bevel box to gearbox
- ☐ 40 Nm and then turn 45° further
- □ 4x
- □ Renew

## 11 - Breather pipe

### 12 - Breather cap

#### 13 - Bolt


- □ 33 Nm
- ☐ Renew

#### 14 - Flange shaft (right-side)

□ Removing and installing ⇒ page 256

#### 15 - Oil seal

□ Renew



16	- Needle	bearing	(polygon	bearing)
----	----------	---------	----------	----------

- Does not turn easily when flange shaft is removed; this does not indicate a fault
- □ Acoustic check can only be performed when installed
- ☐ Check for damage such as cracking in outer race
- □ Renewing ⇒ page 259

#### 17 - Needle bearing (polygon bearing)

- Does not turn easily when flange shaft is removed; this does not indicate a fault
- ☐ Acoustic check can only be performed when installed
- ☐ Check for damage such as cracking in outer race
- ☐ Renewing ⇒ page 259


#### 18 - Circlip

□ Renew

## 2.1 Removing and installing flange shaft (right-side)


# Special tools and workshop equipment required

- Used oil collection and extraction unit -V.A.G 1782-
- ♦ Puller -T10037-
- Socket and extended bit -T10107 A-



#### Removing

- Mark installation position of nuts -arrows- with a felt-tip pen.
- Remove drive shaft (right-side) ⇒ Rep. Gr. 40.




Unbolt heat shield for drive shaft (right-side) from bevel box -arrows-.




#### Note

Illustration shows 3.2 ltr. MPI engine.



- Place used oil collection and extraction unit -V.A.G 1782- below gearbox.
- Using socket and extended bit -T10107 A-, remove bolt -arrow 1- securing flange shaft (right-side). To do so, screw two bolts into flange and counterhold flange shaft with suitable lever.






- Attach puller -T10037- to flange shaft (right-side).
- Use knurled nut -T10037/1- and lower support -A- to align puller -T10037- parallel with flange.
- Pull out flange shaft.

#### Installing

Tightening torque ⇒ page 255

Installation is carried out in reverse sequence; note the following:


- Carefully drive in flange shaft (while turning).
- Secure flange shaft.
- Install heat shield for drive shaft (right-side) ⇒ page 122.
- Install drive shaft (right-side) ⇒ Rep. Gr. 40.
- Check gear oil level in manual gearbox and top up as required ⇒ page 138



#### 2.2 Renewing flange shaft oil seal (rightside) at bevel box (outer seal)


### Special tools and workshop equipment required

♦ Thrust piece -T10049-




#### **Procedure**

- Gearbox in vehicle
- Remove flange shaft (right-side) ⇒ page 256 .
- Pry out flange shaft oil seal using assembly lever.
- Lightly oil outer circumference of new oil seal.
- Pack space between sealing lip and dust lip -arrow- half full with sealing grease -G 052 128 A1- .




- Drive oil seal in onto stop using thrust piece -T10049-.
- Install flange shaft (right-side) ⇒ page 256.
- Check gear oil level in bevel box and top up as required ⇒ page 138



#### 2.3 Renewing needle bearings (polygon bearings) for flange shaft (right-side)


#### Special tools and workshop equipment required

- ♦ Thrust plate -VW 401-
- Thrust plate -VW 402-
- Press tool -VW 407-
- Press tool -VW 412-
- Assembly tool -VAS 3253-
- Clamp -T10047-




#### **Procedure**

- Remove flange shaft (right-side) ⇒ page 256.
- Assemble assembly tool -T10047-, as shown in illustration.
- Marks "B" on both parts of tool face each other.
- The stepped shoulders -arrows- must then be below the bear-
- Screw parts together as far as stop.




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

- Remove circlip -A-.
- Rotate shaft when pressing off -arrow- to prevent contact surface of needle bearings on shaft from being damaged.




- Rotate shaft when pressing on -arrow- to prevent contact surface of needle bearings on shaft from being damaged.
- Secure needle bearings in position with new circlip.
- Install flange shaft (right-side) ⇒ page 256.



#### 2.4 Renewing oil seal between gearbox and bevel box (on bevel box)

Special tools and workshop equipment required

◆ Extractor tool -T20143-




Thrust piece -T10298-

Protected by copyright. Copying for private or commercial purposes, in part or i permitted unless authorised by AUDI AG. AUDI AG does not guarantee or acc with respect to the correctness of information in this document. Copyright by




#### **Procedure**

- Bevel box removed ⇒ page 140 .
- Pry out oil seal from bevel box with extractor tool -T20143/1or -T20143/2-.




Protected by copyright. Copying for private or commercial purposes, in part or in whole,

- Lightly oil outer circumference of new oil seals not guarantee or accept any with respect to the correctness of information in this document. Copyright by AUDI A
- Pack space between sealing lip and dust lip -arrow- half full with sealing grease -G 052 128 A1- .




- Drive in oil seal as far as stop using thrust piece -T10298- .




# 2.5 Renewing oil seal for output flange on bevel box

# Special tools and workshop equipment required


- ♦ Support clamp -VW 313-
- ♦ Tube -VW 516-
- ◆ Thrust plate -40-105-
- ♦ Thrust piece -T10049-
- ♦ Gearbox support -T10108-
- ◆ Support plate -T10108/1-




- ◆ Tapered roller bearing pull-er -V.A.G 1582-
- ♦ Adapter -V.A.G 1582/6A-
- Torque wrench -V.A.G 1601-
- -1- Two-arm puller Kukko 20/10
- Three-arm puller Kukko 45/2




Multi-purpose:tool: bVWy76/11 € opying for private or commercial purposes, in part or in will permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept with respect to the correctness of information in this document. Copyright by AU



Extractor tool -VW 771/31-




♦ Used oil collection and extraction unit -V.A.G 1782-




- Bolt M10x30 (2x)
- Nut M12x10 (4x)

#### **Procedure**


- Tightening torque <u>⇒ page 255</u>
- Bevel box removed ⇒ page 140 .
- Place nut M12x10 -item A- between bevel box and gearbox support -T10108- and fit bevel box on hole marked "4" -arrow- in gearbox support.
- Then align the bevel box with the three remaining holes and secure (place nuts -A- in between).
- Place used oil collection and extraction unit -V.A.G 1782- underneath.
- Drain gear oil out of bevel box.



- Lock output flange for bevel box in position using support plate -T10108/1- and bolts M10x30 (2x) -arrows-.
- Unscrew nut for output flange.
- A 36 mm socket for 3/4" drive
- Swing bevel box so that output flange points upwards.



- Remove output flange from shaft bevel gear of bevel box.
- A Three-arm puller Kukko 45/2







#### Note

When pulling off the output flange, the tapered roller bearing inner race remains fitted on the output flange and must be pulled off the output flange separately.


- Place thrust plate -40 105- on output flange.
- Pull off inner race for tapered roller bearing from output flange using tapered roller bearing puller -V.A.G 1582- and adapter -V.A.G 1582/6A- .




- Pull out oil seak Athoroutpub flangerivate or commercial purposes, in part or in we permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept
- Clean residual/locking fluid from thread of shaft bevel gearvight by AU



- Make sure that the shim -2- adjusting the bearing preload of the shaft bevel gear -1- is still fitted.
- Insert inner race for tapered bearing roller -3- into outer race in bevel box.
- Lightly lubricate outer circumference of new oil seal -4- for output flange.




- Drive in oil seal as far as stop using thrust piece -T10049-
- Pack space between sealing lip and dust lip half-full with sealing grease -G 052 128 A1- .




Protected by copyright. Copying for pr permitted unless authorised by AUDI with respect to the correctness of in

- Apply puller hooks to bottom of pinion housing and draw in output flange.
- A Two-arm puller Kukko 20/10



- Coat thread of new nut for output flange with locking fluid and tighten; for locking fluid refer to ⇒ Electronic parts catalogue.
- Top up gear oil after installing bevel box ⇒ page 151.



#### 3 **Exploded view - differential**



- Mounting gearbox on assembly stand <del>⇒ page 125</del>.
- Heat tapered roller bearing inner race to 100°C before installing.
- Always renew both tapered roller bearings together.
- Adjust differential if tapered roller bearings, differential cage, gearbox housing or clutch housing are renewed *⇒ page 274 .*

#### 1 - Gearbox housing

#### 2 - Shim

- For differential
- Determining thickness ⇒ page 274

#### 3 - Tapered roller bearing outer race

- Pulling out <u>⇒ page 272</u>
- Pressing in ⇒ page 273

#### 4 - Tapered roller bearing inner race

- □ Pulling off ⇒ page 271
- Pressing on ⇒ page 272

#### 5 - Differential cage

■ With riveted final drive gear

# 6 - Tapered roller bearing inner

- □ Pulling off ⇒ page 272
- Pressing on ⇒ page 272

# 7 - Tapered roller bearing outer

- □ Pulling out ⇒ page 271
- Pressing in ⇒ page 271

### 8 - Shim

- □ 0.65 mm thick
- Installation position:

Shoulder on inside diameter faces towards bevel box ⇒ Item 14 (page 268)


### 9 - Clutch housing

#### 10 - Oil seal

- ☐ For flange shaft (right-side)
- ☐ Renewing with gearbox installed <u>⇒ page 258</u>

#### 11 - Bolt

- □ 40 Nm
- □ Renew




12 - E	Bolt
	Screws into threaded piece <u>⇒ Item 19 (page 268)</u>
	Tightening torque ⇒ Item 13 (page 255)
13 - F	Flange shaft (right-side)
	Removing and installing <u>⇒ page 256</u>
14 - E	Bevel box
	Removing and installing (with gearbox installed) ⇒ page 140
	Removing and installing (with gearbox removed) <u>⇒ page 159</u>
15 - 8	Sun wheel
	Installing <u>⇒ page 273</u>
16 - [	Differential pinion pin
	Removing <u>⇒ page 273</u>
	Installing <u>⇒ page 273</u>
17 - 9	Spring pin
	Secures differential pinion pin
	Removing <u>⇒ page 273</u>
	Drive new spring pin in flush <u>⇒ page 273</u>
18 - F	Planet pinion
	Removing and installing <u>⇒ page 273</u>
19 - 1	Threaded piece
	Installing <u>⇒ page 273</u>
20 - 0	One-piece thrust washer
	Lubricate with gear oil before installing
21 - 0	Circlip
	Holds tapered ring, thrust washer and spring in position when flange shaft is removed
22 - 1	Tapered ring
	With grooves to engage on thrust washer
	Installation position: Taper towards differential cage
23 - 1	Thrust washer
	Installation position: Shoulder towards spring, lugs towards tapered ring
24 - 9	Spring for flange shaft (left-side)
	Installed behind flange shaft (left-side)
25 - F	Flange shaft (left-side)
	Removing and installing <u>⇒ page 250</u>
26 - 0	Dil seal
	For flange shaft (left-side)
	Renewing with gearbox installed <u>⇒ page 251</u>

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

#### Dismantling and assembling differential 3.1


#### Special tools and workshop equipment required

- ♦ Thrust plate -VW 402-
- Press tool -VW 408 A-
- ♦ Press tool -VW 411-
- Press tool -VW 412-
- Extension -30 23-
- Thrust plate -40-105-






- Thrust plate -3005-
- Tube -3259-
- Tube -3296-
- Assembly tool -3301-
- Tube -3345-
- -1- Kukko internal puller
- -2- Kukko 18/1 puller
- -3- Splitter 17/1
- -4- Kukko 22/2 countersupport






Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

-3- Puller Kukko 204/2





#### Pulling tapered roller bearing outer race out of clutch housing

rotected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

A - Counter-support, e.g. -Kukko 22/2-

B - Internal puller 46 ... 58 mm, e.g. -Kukko 21/7-

Clamp internal puller -B- firmly between tapered roller bearing outer race and shim.




#### Note

After pulling out, check shim for damage and renew if necessary.

#### Pressing tapered roller bearing outer race into clutch housing

- First install shim.
- Collar on inside diameter of thrust plate -3005- faces towards outer race.




### Pulling off tapered roller bearing inner race

- Fit thrust plate -40-105- onto differential cage.
- Clamp jaws of puller (e.g. -Kukko 204/2-) under inner race on flat surfaces of differential cage.



#### Note


When pulling off the inner race ensure that the hooks do not bend outwards, if necessary tighten screw -arrow-.




### Pressing on tapered roller bearing inner race

Pulling of tapered roller bearing inner descriptions, in part or in whole, is not pulling in tapered roller bearing inner descriptions. A - Puller , e.g. -Kukko 18/1-


B - Splitter 12...75 mm , e.g. -Kukko 17/1-





### Pressing on tapered roller bearing inner race


Fit sleeve -3301/3- of assembly device -3301- onto tapered roller bearing inner race with recess -arrow- (larger inner diameter) facing downwards.



#### Pulling tapered roller bearing outer race out of gearbox housing


A - Counter-support, e.g. -Kukko 22/2-

B - Internal puller 46 ... 58 mm , e.g. -Kukko 21/7-



#### Pressing tapered roller bearing outer race into gearbox housing

Support gearbox housing with tube -3345- directly below bearing mounting.




#### Removing differential pinion pin and spring pin for differential pinion pin

- First drive spring pin -1- into differential pinion pin -2- so it is flush.
- Fit differential under press, with spring pin -arrow- facing towards extension -30 - 23- .
- Now press out differential pinion pin.



#### Note

Remove any sheared off parts of the spring pin from the differential cage.




#### Installing bevel gears

- Lubricate one-piece thrust washer with gear oil and install.
- Install both sun wheels and secure (e.g. with flange shaft).
- Insert planet pinions (180° apart) and pivot into position.
- Push differential pinion pin -arrow A- in as far as first planet pinion.
- Fit threaded pieces -arrows B- in sun wheels.
- Installation position: Stepped shoulder towards sun wheel
- Drive differential pinion pin into final position and secure with spring pin ⇒ page 273.

#### Installing spring pin

Use a punch -1- to drive new spring pin -arrow- in flush with differential cage. Protected by copyright. Copying for private

permitted unless authorised by AUDI AG. with respect to the correctness of inform



# AUOI

## 3.2 Table of adjustments



#### Note

If repairs have been carried out on the gearbox, it is only necessary to adjust the output shaft for 1st - 4th gear, the output shaft for 5th, 6th and reverse gear or the differential if components have been renewed which have a direct effect on the adjustment of the gearbox. Refer to the following table to avoid unnecessary adjustment work:

Components renewed:	Components requiring adjustment:		
permitted unless authorised	by AUDI AG. AUDI AG does r	Output shaft for 5th, 6th and re- urposeversetgearhole, is ot gu <b>zzrpage 245</b> any lia	bility
Gearbox housing	hess of information in this dod ${\sf X}$	ument. Copyright by AUDI AG X	X
Clutch housing	Х	х	х
Output shaft for 1st - 4th gear	Х		
Output shaft for 5th, 6th and reverse gears		х	
Differential cage			х
Tapered roller bearings for 1st - 4th gear output shaft	Х		
Tapered roller bearings for 5th/6th and reverse gear output shaft		х	
Tapered roller bearings for differential			х

# 3.3 Adjusting differential


The differential has to be readjusted when the following components are renewed:

- Gearbox housing
- Clutch housing
- ♦ Differential cage
- Tapered roller bearings for differential

Table of adjustments <u>⇒ page 274</u>


# Special tools and workshop equipment required

- Gearbox support -VW 353-
- End measuring plate VW 385/17-
- Universal dial gauge bracket -VW 387-
- ♦ Thrust plate -VW 402-
- Press tool -VW 408 A-
- ♦ Thrust plate -3005-






- Tube -3259-
- Tube -3345-
- Torque wrench -V.A.G 1331-
- -1- Kukko internal puller
- -4- Kukko 22/2 countersupport




Dial gauge -VAS 6080-




Dial gauge extension, 30 mm

#### **Procedure**

- Press tapered roller bearing outer race with shim into clutch housing.
- Collar on inner diameter of thrust plate -3005- faces towards outer race.



- Press tapered roller bearing outer race without shim into gearbox housing.
- Install differential in clutch housing.
- Fit gearbox housing and tighten 5 bolts to specified torque  $\Rightarrow$  Item 11 (page 156) and  $\Rightarrow$  Item 12 (page 156).
- Press differential towards clutch housing; hold in this position and turn eight times.
- Press differential towards gearbox housing; hold in this position and turn eight times.



- Attach dial gauge and set to "0" with a preload of 1 mm.
- A Dial gauge extension, 30 mm
- Move differential up and down and note play indicated on dial gauge (in this example: 0.70 per littled unless authorised by AUDI AG. AUDI AG does


#### Determining thickness of shim

The specified bearing preload is obtained by adding a constant figure (0.25 mm) to the reading indicated.

#### Example:

Measured value	0.70 mm
+ Preload (constant value)	0.25 mm
Thickness of shim =	0.95 mm


- Take off gearbox housing.



- Pull tapered roller bearing outer race out of gearbox housing.
- A Counter-support, e.g. -Kukko 22/2-
- B Internal puller 46 ... 58 mm , e.g. -Kukko 21/7-
- Select a shim of the required thickness from the table. For part numbers refer to ⇒ Electronic parts catalogue.
- Insert shim of correct thickness.


The following shims are available:


Thickness of shims in mm				
0.65	0.85	1.05	1.25	
0.70	0.90	1.10		
0.75	0.95	1.15		
0.80	1.00	1.20		



If the size of the shim required is larger than those listed in the table, install two shims amounting to the correct value, insert the snot thicker shim firsts authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

Press in outer race again and secure gearbox housing ⇒ page 156 .





#### **Propshaft** 4

Description of propshaft  $\Rightarrow\,$  Rear final drive 02D, 0AV, 0BR and 0BY; Rep. Gr. 39 .



permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

# 5 Rear final drive

Description of rear final drive  $\Rightarrow$  Rear final drive 02D, 0AV, 0BR and 0BY; Rep. Gr. 39 .

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.